

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Swingball MK7293

Swingball All Surface Tetherball Tennis Set Instruction Manual

Model: MK7293

PRODUCT OVERVIEW

The Swingball All Surface Tetherball Tennis Set is a versatile 5-in-1 outdoor game designed for active play for kids and adults. This portable set allows for multiple game modes including Swingball, Soccer Swingball, Tailball, Volleyball, and Fling Disc, making it suitable for various outdoor and indoor environments.

Its all-surface base ensures stability on different terrains, and all components conveniently store within the base for easy transport and compact storage.

5 IN 1 MULTIPLAY SET

■ SWINGBALL

■ SWINGBALL SOCCER

■ TAILBALL

■ VOLLEYBALL

■ FLING DISC




Figure 1: Overview of the 5-in-1 Multiplay Set capabilities.

COMPONENTS LIST

Before assembly, ensure all the following components are present:

- 6" Soccer Ball
- Rubber Tennis Ball
- 2 Bats (Paddles)
- Swingball Spiral Head
- Tailball
- Pump
- Y Net
- Plastic Tube for Y Net & Swingball
- Fling Disc

- All Surface Base (2 parts)

AGES 6 YEARS AND UP

SET INCLUDES

6" SOCCER BALL

PUMP

RUBBER TENNIS BALL

Y NET

2 BATS

PLASTIC TUBE FOR Y NET & SWINGBALL

SWINGBALL SPIRAL HEAD

FLING DISC

TAILBALL



Figure 2: All components included in the Swingball 5-in-1 Set.

SETUP INSTRUCTIONS

Follow these steps to set up your Swingball All Surface Tetherball Tennis Set for play.

1. Prepare the Base

The two-part base provides stability. For optimal performance, fill the base with water or sand.

1. Separate the two parts of the base.
2. Locate the fill opening on the base.
3. Carefully fill the base with water or sand until full.
4. Securely close the fill opening with the provided plug. Ensure the lid is correctly oriented with its "front" and "back" to ensure a secure fit.

5. Re-attach the two parts of the base if they were fully separated, ensuring they click into place.



Figure 3: Filling the base with water for stability.

2. Assemble Game Modes

The set supports three main assembly modes for different games:

1. **Swingball/Tetherball Mode:** Insert the adjustable pole into the central opening of the base. Attach the Swingball spiral head to the top of the pole. The rubber tennis ball is pre-attached to the spiral head.
2. **Soccer Swingball Mode:** Insert the adjustable pole into the central opening. Attach the soccer ball to the designated attachment point on the pole.
3. **Tailball/Volleyball/Fling Disc Net Mode:** Assemble the Y-net frame using the plastic tubes and connect it to the base. This creates a net for games like Tailball and Volleyball.

3 MODES IN 1 BASE




Figure 4: The three main assembly modes for the game set.

OPERATING INSTRUCTIONS (GAME PLAY)

The Swingball All Surface Set offers five distinct games. Ensure the set is assembled in the correct mode for your chosen game.

1. Swingball (Tetherball Tennis)

This classic game involves two players hitting a tennis ball attached to a spiral head on a pole. The objective is to hit the ball so that the cord wraps around the pole in your favor.

- Assemble the set in Swingball mode (adjustable pole with spiral head).
- Each player uses a paddle.
- Players stand on opposite sides of the pole and hit the ball, aiming to wrap the cord around the pole in their direction.
- The game ends when the cord is fully wrapped around the pole.



Figure 5: Children engaged in a game of Tailball, demonstrating the net setup.

2. Soccer Swingball

Similar to Swingball, but played with a soccer ball, allowing for kicking instead of hitting with paddles.

- Assemble the set in Soccer Swingball mode (adjustable pole with soccer ball attachment).
- Players kick the soccer ball, aiming to wrap the cord around the pole.



Figure 6: The soccer ball and pump included in the set.

3. Tailball

A variation of tennis played over the Y-net with a unique tailball and paddles.

- Assemble the set with the Y-net.
- Players use paddles to hit the tailball over the net.
- The tail on the ball provides a unique flight path, making it easier to hit for beginners.

4. Volleyball

Use the Y-net for a simplified game of volleyball, suitable for younger players or smaller spaces.

- Assemble the set with the Y-net.
- Players hit a lightweight ball (not included, or use the soccer ball) over the net, aiming to ground it on the opponent's side.

5. Fling Disc (Disc Toss)

The included fling disc can be used for casual throwing and catching games.

- No specific assembly required for this game.
- Use the provided fling disc for throwing and catching.

MAINTENANCE

Proper maintenance will extend the life of your Swingball set.

- **Cleaning:** Wipe down all plastic components with a damp cloth and mild soap as needed. Avoid harsh chemicals.
- **Draining Base:** If storing for an extended period or in freezing temperatures, drain water from the base to prevent damage.
- **Storage:** All components, including the pole sections, balls, and paddles, can be stored inside the base when not in use. This compact storage helps protect parts and saves space.

PACKS INTO THE BASE



Figure 7: All components pack neatly into the base for compact storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Base is unstable or tips over easily.	Base not filled sufficiently with water or sand.	Ensure the base is completely filled with water or sand for maximum stability.
Pole does not stay securely in the base.	Pole not fully inserted or base lid not properly secured.	Push the pole firmly into the designated recess. Ensure the two parts of the base are correctly aligned and securely latched, and the fill plug is tightly closed.
Ball does not bounce well (for tennis/soccer).	Ball may be under-inflated.	Use the provided pump to inflate the ball to the recommended pressure.

Problem	Possible Cause	Solution
Components do not fit into the base for storage.	Incorrect packing order or components not fully disassembled.	Refer to the storage diagram (Figure 7) and ensure all pole sections are separated and items are placed correctly.

SPECIFICATIONS

Attribute	Detail
Brand	Swingball
Model Name	Swingball 5n1 21
Model Number	MK7293
Material	Plastic
Color	Tailball Tennis - Blue/Yellow
Age Range (Description)	6 years and up
Item Weight	3.4 Kilograms
Item Dimensions (LxWxH)	70.85 x 16.25 x 37.75 inches (assembled)
Number of Items	1 (set)
Included Components	Swingball 5n1 (as listed in Components List)

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided on the product packaging or visit the official Swingball website. Keep your purchase receipt as proof of purchase.

For additional assistance, you may contact National Sporting Goods - Toys, the manufacturer of this product.