

[Manuals.plus](#) /

› [BELLEZE](#) /

› BELLEZE 72" Tall Kitchen Pantry Assembly and User Manual (Model 014-HG-43510-BLA)

BELLEZE 014-HG-43510-BLA

BELLEZE 72" Tall Kitchen Pantry Assembly and User Manual

Model: 014-HG-43510-BLA

INTRODUCTION

Thank you for choosing the BELLEZE 72" Tall Kitchen Pantry. This manual provides essential information for the safe assembly, operation, and maintenance of your new storage cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

WARNING: Do not exceed weight limits. Ensure proper installation to avoid tipping. Keep items that can cause injury out of reach of children.

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use.
- Do not allow children to climb on or play with the cabinet.
- Distribute weight evenly across shelves and drawers to maintain stability.
- If wall anchoring hardware is provided, it is highly recommended to use it to prevent tipping.

PARTS LIST AND HARDWARE

Before assembly, carefully unpack all components and verify against the included parts list in your packaging. Ensure all parts and hardware are present and undamaged. If any parts are missing or damaged, please contact customer support immediately.



Figure 1: Product Dimensions and Internal Measurements. Refer to this diagram for an overview of the cabinet's size and internal storage capacities.

SETUP AND ASSEMBLY

The BELLEZE 72" Tall Kitchen Pantry is designed for straightforward assembly. A detailed, step-by-step instruction manual with diagrams is included in your product packaging. Please follow those instructions precisely for correct and safe assembly.

Key Assembly Tips:

1. Identify all parts and hardware before starting.
2. Use the correct tools as specified in the manual.
3. Do not overtighten screws to avoid damaging the engineered wood.
4. Assemble with at least two people for easier handling and safety, especially for larger components.



Figure 2: Fully Assembled BELLEZE Kitchen Pantry. This image provides a visual reference for the completed product.

OPERATING INSTRUCTIONS

Using the Drawers:

The upper section of the pantry features two built-in drawers. These are designed for smooth operation. To open, gently pull the gold aluminum alloy handles. To close, push firmly until the drawer is fully seated.



White with gold aluminum alloy handles, exuding sophistication and style.

Enhances the luxurious feel of living space, perfectly suited for contemporary, minimalist settings

Two Spacious Drawers
Provides ample storage space, making it easy to organize and keep your home neat and tidy.



Figure 3: Detail of Drawers and Handles. This image illustrates the design and functionality of the drawers.

Adjusting Shelves:

Both the upper and lower cabinets include adjustable shelves. To adjust a shelf, carefully remove any items, then lift the shelf and reposition the shelf pins to the desired height. Ensure all four pins are securely inserted into the corresponding holes before placing the shelf back. Distribute weight evenly on each shelf, not exceeding the maximum weight capacity of 25 pounds per shelf.



With Adjustable Shelves

Flexible design to meet various storage needs. Multiple height adjustments enhance functionality and adaptability.

Black Lacquered Slot Design

The lower cabinet slot coated in black lacquer adds depth and visual dimension, enhancing the modern and refined look of the piece.

Figure 4: Adjustable Shelves and Design Detail. This image demonstrates the adjustable shelf feature and the aesthetic detail of the lower cabinet.

MAINTENANCE

To ensure the longevity and appearance of your BELLEZE pantry, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the engineered wood.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading.
- **Humidity:** Maintain a stable humidity level in the room to prevent warping or cracking.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.

TROUBLESHOOTING

Common Issues and Solutions:

- **Cabinet feels unstable:** Ensure all assembly screws are fully tightened. Verify the cabinet is on a level surface. If applicable, use the provided wall anchoring hardware.
- **Drawers do not slide smoothly:** Check for any obstructions in the drawer glides. Ensure the drawer is correctly aligned on its tracks. Avoid overloading drawers.
- **Doors are misaligned:** Adjust the hinges if necessary. Refer to the assembly manual for hinge adjustment instructions.

If you encounter issues not covered here or require further assistance, please contact BELLEZE customer support.

SPECIFICATIONS

Feature	Detail
Brand	BELLEZE
Model Number	014-HG-43510-BLA
Color	White
Material	Engineered Wood
Product Dimensions (D x W x H)	16.7"D x 33.7"W x 72"H
Item Weight	129.9 pounds
Number of Drawers	2
Adjustable Shelves	Yes
Weight Capacity (Maximum per shelf)	25 pounds
Mounting Type	Floor Mount (Freestanding)
Included Components	Kitchen Pantry, User Manual, Assembly Hardware

WARRANTY AND SUPPORT

Manufacturer Warranty:

BELLEZE products come with a **1-year warranty** from the date of delivery. This warranty covers manufacturing defects and issues arising from normal use. Please retain your proof of purchase for warranty claims.

Customer Support:

For any product issues, missing parts, or warranty inquiries, please contact BELLEZE customer support through Amazon buyer-seller messaging. We are committed to your satisfaction and will assist you promptly.

Seller: [Align Inc.](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question