

[manuals.plus](#) /› [XLEADER](#) /› [XLEADER SoundAngel Mate Pro \(2nd Gen\) Shower Speaker User Manual](#)

XLEADER USMATEG-A

XLEADER SoundAngel Mate Pro (2nd Gen) Shower Speaker User Manual

Model: USMATEG-A

Brand: XLEADER

1. INTRODUCTION

Thank you for choosing the XLEADER SoundAngel Mate Pro (2nd Gen) Shower Speaker. This manual provides essential information for the safe and efficient operation of your new device. This certified IPX7 waterproof Bluetooth speaker delivers 8W crystal sound with rich bass, offering up to 12 hours of playtime. It features a strong suction cup and a silicone lanyard for versatile placement, making it ideal for use in showers, by the pool, at the beach, or during kayaking activities.

8W Crystal Sound & Rich Bass

Features high-fidelity driver and DSP Bass Chip.



Image 1: XLEADER SoundAngel Mate Pro speaker in a bathtub.

2. PACKAGE CONTENTS

Please check the package for the following items:

- 1x XLEADER SoundAngel Mate Shower Speaker
- 1x Suction Cup (pre-attached or separate)
- 1x USB-C Charging Cable
- 1x Hook Clip
- 1x Multilingual User Manual
- 1x Warranty Card

Gift box packaging



Image 2: Contents of the XLEADER SoundAngel Mate Pro package.

3. PRODUCT OVERVIEW

The XLEADER SoundAngel Mate Pro features an intuitive control panel and a robust design for various environments.



Image 3: XLEADER SoundAngel Mate Pro speaker with control buttons.

Control Buttons:

- **Power Button (PW):** Press and hold to power on/off.
- **Play/Pause Button (PA):** Press to play or pause music.
- **Volume Up / Next Track Button (VU):** Short press for next track, long press for volume up.
- **Volume Down / Previous Track Button (VD):** Short press for previous track, long press for volume down.
- **Call Button (CB):** Press to answer/end calls, press and hold to reject calls.

Ports:

- **USB-C Charging Port:** Located under a waterproof flap.



Image 4: Side view with charging port and dimensions.

4. SETUP

4.1 Charging the Speaker

Before first use, fully charge the speaker. Open the waterproof flap on the side of the speaker and connect the provided USB-C charging cable to the charging port. Connect the other end to a USB power adapter (not included). The charging indicator light will illuminate. A full charge takes approximately 3 hours and provides 8-12 hours of playtime at 50-80% volume.

4.2 Mounting the Speaker

The speaker comes with a strong suction cup and a silicone lanyard for flexible mounting options.

- **Using the Suction Cup:** Ensure the surface (e.g., shower wall, glass, tile) is clean and smooth. Press the suction cup firmly against the surface until it adheres securely.
- **Using the Silicone Lanyard:** Attach the silicone lanyard to the designated loop on the speaker. Use the lanyard to hang the speaker from a hook or secure it to other objects like a kayak or backpack.



Image 5: Silicone lanyard for hanging the speaker.

With Upgraded Suction Cup and Silicone Lanyard

Use them together to ensure they never fall again!



Image 6: Speaker mounted in a shower using the suction cup.

4.3 Bluetooth Pairing

- Power On:** Press and hold the Power Button until you hear an audible prompt and the LED indicator flashes blue, indicating it's in pairing mode.
- Activate Bluetooth:** On your smartphone or other Bluetooth-enabled device, go to the Bluetooth settings and turn on Bluetooth.
- Select Device:** Look for "SoundAngel Mate Pro" in the list of available devices and select it.
- Confirm Connection:** Once successfully paired, you will hear a confirmation sound, and the LED indicator will turn solid blue. The speaker will automatically reconnect to the last paired device when powered on.



TOP Bluetooth & One Step Pairing

auto pair with the phone in 3s

Image 7: Bluetooth 5.3 connectivity and features.

Your browser does not support the video tag.

Video 1: Demonstration of XLEADER SoundAngel Mate Pro speaker features and pairing.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- **To Power On:** Press and hold the Power Button for 2-3 seconds.
- **To Power Off:** Press and hold the Power Button for 2-3 seconds.

5.2 Music Playback

- **Play/Pause:** Press the Play/Pause Button.
- **Next Track:** Short press the Volume Up / Next Track Button.
- **Previous Track:** Short press the Volume Down / Previous Track Button.
- **Volume Up:** Long press the Volume Up / Next Track Button.
- **Volume Down:** Long press the Volume Down / Previous Track Button.

5.3 Call Management

The built-in microphone allows for hands-free calling.

- **Answer/End Call:** Press the Call Button.
- **Reject Call:** Press and hold the Call Button.

Your browser does not support the video tag.

Video 2: Demonstration of the speaker's waterproof capabilities and call management.

5.4 True Wireless Stereo (TWS) Pairing

For an enhanced audio experience, you can pair two XLEADER SoundAngel Mate Pro speakers together for True Wireless Stereo sound.

1. Ensure both speakers are powered off and not connected to any other Bluetooth devices.
2. Power on both speakers. They will automatically enter pairing mode.
3. On one of the speakers (this will be your primary speaker), double-press the Play/Pause button. The speakers will attempt to pair with each other.
4. Once successfully paired, you will hear a confirmation tone, and the LED indicator on the primary speaker will flash blue, while the secondary speaker's LED will remain solid blue.
5. Now, connect your device to the primary speaker via Bluetooth as described in section 4.3. Both speakers will play music synchronously.

6. CARE AND MAINTENANCE

- After use in saltwater or chlorinated water, rinse the speaker with fresh water to prevent corrosion.
- Ensure the charging port's waterproof flap is securely closed before exposing the speaker to water.
- Clean the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the speaker in a cool, dry place when not in use.
- Avoid extreme temperatures and direct sunlight for prolonged periods.

Certified IPX7 Waterproof

| Precision construction and piano finish



Image 8: Speaker demonstrating IPX7 waterproof capability.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair with device.	Bluetooth not enabled on device, speaker not in pairing mode, or too far from device.	Ensure Bluetooth is on, speaker is in pairing mode (flashing blue LED), and device is within 66ft. Try restarting both devices.
No sound or low volume.	Volume too low on speaker or device, or speaker not connected.	Increase volume on both speaker and device. Re-pair the speaker if necessary.
Sound is distorted.	Volume too high, or device is too far from speaker.	Lower the volume. Move the device closer to the speaker.

8. SPECIFICATIONS

Feature	Detail
Model Name	USMATEG-A
Speaker Type	Shower Speaker
Waterproof Rating	IPX7 (fully immersible up to 1 meter for 30 minutes)
Bluetooth Version	5.3
Wireless Range	Up to 66 feet
Speaker Output Power	8 Watts
Battery Capacity	1200mAh Polymer Battery
Playtime	8-12 hours (at 50-80% volume)
Charging Time	3 hours
Charging Port	USB-C
Special Features	Built-in Microphone, True Wireless Stereo (TWS) support
Mounting Type	Suction Cup, Silicone Lanyard
Product Dimensions	3.15"D x 3.15"W x 2.76"H
Item Weight	4.9 ounces (138 Grams)



Image 9: Speaker dimensions and available colors.

2025 New Upgrade

	2nd Gen	Old Vision
Release Date	Oct,2025	2020
Bluetooth Vision	V5.4	V5.0
DSP Bass Chip	Yes(Rich Bass)	No(Weak Bass)
Speaker Power	8W	5W
Battery Capacity	1200mAh	1000mAh
Charging Port	Popular USB-C	Old Mini USB
Suction Cup	Screw interface	Plastic interface
Accessories	Silicone lanyard	No
Warranty	5 Years	3 Years




Image 10: Feature comparison: 2nd Gen vs. Old Version.

9. WARRANTY AND SUPPORT

The XLEADER SoundAngel Mate Pro (2nd Gen) Shower Speaker comes with a **3-year warranty**. For any support inquiries, troubleshooting assistance, or warranty claims, please refer to the contact information provided on the warranty card included in your package or visit the official XLEADER website.

© 2025 XLEADER. All rights reserved.

Related Documents - USMATEG-A



XLeader Sport3 Pro Wireless Headphones: User Manual & Specifications

Comprehensive user manual and technical specifications for the XLeader Sport3 Pro wireless sports headphones, detailing features like IPX7 waterproofing, 48-hour playtime, and Bluetooth connectivity.

XLEADER SoundAngel X8 & X8 Pro Model Difference

Information regarding the model differences between the XLEADER SoundAngel X8 and SoundAngel X8 Pro portable Bluetooth speakers, noting shared circuitry and RF modules.

	<p>KONG Lanyard 2006 User Manual: Lanyards & Adjustable Work Positioning Lanyards</p> <p>Official user manual for KONG Lanyard 2006 series, covering Lanyards and Adjustable Work Positioning Lanyards. Includes safety, usage, maintenance, and technical details for professional and recreational applications.</p>
	<p>INTIMINA Ziggy Cup 2 User Manual</p> <p>User manual for the INTIMINA Ziggy Cup 2, a next-generation flat-fit menstrual cup. Learn about its features, how to use, fold, insert, remove, clean, and choose the right size. Includes safety information and warnings.</p>
	<p>i-PRO Wi-Fi USB Adapter User Guide</p> <p>This guide provides information on using the i-PRO Wi-Fi USB Adapter with compatible i-PRO cameras, including setup, connection, and troubleshooting.</p>