

[Manuals.plus](#) /

› [Wellspeed](#) /

› Wellspeed Modern Ceiling Fan with Lights Instruction Manual

Wellspeed DY1132-5B/52

Wellspeed Modern Ceiling Fan with Lights

Model: DY1132-5B/52

INTRODUCTION

Thank you for choosing the Wellspeed Modern Ceiling Fan. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new ceiling fan. Designed for year-round comfort, this fan features a reversible DC motor, 6-speed settings, and a 3CCT dimmable LED light, making it ideal for various indoor and outdoor spaces like bedrooms, living rooms, and patios. Please read this manual thoroughly before beginning installation to ensure proper setup and optimal performance.

IMPORTANT SAFETY INSTRUCTIONS

- Always turn off electricity at the main power box before commencing work. Remove the fuse or turn off the circuit breaker to cut off power before installing or servicing the fan.
- Ensure all electrical connections are in compliance with local laws, regulations, and national electrical codes.
- Make sure that ceiling joists are strong enough and of adequate size to support the weight of the fan (approximately 35 kg).
- If you are not familiar with electrical installation and wiring, please hire a qualified electrician or consult the wiring manual.
- Do not bend the blade holders when installing, balancing the blades, or cleaning the fan.
- Do not insert foreign objects between rotating fan blades.
- The fan must be installed with a minimum of 7 feet (2.1 meters) clearance from the floor to the blades.

PACKAGE CONTENTS

Verify that all parts listed below are included in your package:

Component	Quantity
Motor Assembly	1
Canopy	1
Coupling Cover	1
Downrod	1
Bracket	1
Light Kit (LED Panel)	1
Lampshade	1
Hardware Bag (screws, washers, wire nuts, etc.)	1
Remote Control	1
Blade Arms	5
Blades	5
Installation Manual	1



Image: All components of the Wellspeed ceiling fan laid out for assembly.

SETUP & INSTALLATION

Follow these steps carefully for proper assembly and installation. It is recommended to watch the official installation tutorial video for visual guidance.

Your browser does not support the video tag.

Video: Official Installation Tutorial for Wellspeed Ceiling Fans with Lights. This video provides a step-by-step guide for assembling and mounting the fan.

1. Preparing the Blades

Attach each blade to its corresponding blade arm using the provided screws and washers from the hardware bag. Ensure they are securely fastened.



Image: Reversible fan blades, showing both wood grain and black finishes.

2. Assembling the Motor and Downrod

Carefully feed the wires from the motor assembly through the downrod. Secure the downrod to the motor

assembly using the provided pin and screws. Ensure the downrod is firmly attached to prevent wobbling.

3. Mounting the Bracket

Secure the mounting bracket to your ceiling electrical box. Ensure the electrical box is rated for ceiling fan support. Use appropriate screws and anchors for your ceiling type. The bracket must be securely fastened to a ceiling joist or a fan-rated support brace.

4. Wiring and Hanging the Fan

Carefully lift the fan assembly and hang it on the mounting bracket. Connect the electrical wires from the ceiling to the fan's wiring according to the wiring diagram in the manual (typically black to black, white to white, and green/bare copper to ground). Use the provided wire nuts to secure connections. Tuck all wires neatly into the electrical box.

5. Attaching the Light Kit

Connect the light kit's wires to the corresponding wires from the motor assembly. Secure the LED panel to the motor assembly using the designated screws. Finally, attach the lampshade by twisting or locking it into place.



No screen flicker, we care about your eyes

Image: The fan's LED light is designed to be flicker-free for eye comfort.

OPERATING INSTRUCTIONS

Your Wellspeed Ceiling Fan comes with a convenient remote control for easy operation of all its features.



Image: The ceiling fan and its remote control.

Remote Control Functions:

- **Light On/Off:** Press the 'LIGHT ON/OFF' button to toggle the light.
- **Light Dimming:** Use the '+' and '-' buttons to adjust the brightness of the LED light (100%-20%).
- **Color Temperature (3CCT):** Press 'WW' (Warm White 3000K), 'NW' (Neutral White 4000K), or 'DW' (Daylight White 6500K) to change the light color.
- **Fan Speed (6-Speed):** Select speeds 1-6. Speed 1 is a gentle breeze, while Speed 6 provides strong airflow.
- **Reverse Function:** Press the 'REV' button to change the direction of the fan blades. Use downdraft mode for cooling in summer and updraft mode for circulating warm air in winter.
- **Timer:** Set the fan to turn off automatically after 1H, 3H, or 6H.

Your browser does not support the video tag.

Video: Demonstrates the various light and fan speed settings, including the reversible function, controlled by the remote.

Expand Your Lighting Options



Brightness Dimmable 100%-20%



Image: Expand your lighting options with 3CCT dimmable LED.

6 wind speeds, meet your different needs



1-2 Speed
Comfortable Wind



3-4 Speed
Natural Wind



5-6 Speed
Strong Wind



Image: Six wind speeds to meet different needs.

REVERSIBLE MOTOR

Multi-seasonal applications-not just for summer



Image: Reversible motor for multi-seasonal applications.

MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To avoid scratching the finish, clean the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.

- **Blade Care:** Periodically check the blade screws for tightness. Over time, they may loosen due to fan vibration.
- **Motor:** The DC motor is designed for quiet operation and requires no lubrication.
- **Light Kit:** The integrated LED light panel is designed for long-term use and does not require bulb replacement.

TROUBLESHOOTING

If you experience issues with your fan, consult the table below for common problems and solutions.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low.	Check circuit breaker/fuse; Ensure all wires are securely connected; Replace remote control batteries.
Fan wobbles	Loose blade screws; Improperly mounted bracket; Unbalanced blades.	Tighten all blade screws; Ensure mounting bracket is secure; Use balancing kit (if provided) to balance blades.
Light does not work	Loose wire connection to light kit; LED panel issue.	Check light kit wiring connections; Contact customer support if LED panel is faulty.
Remote control not working	Low battery; Not paired correctly.	Replace batteries; Re-pair remote control following pairing instructions in the manual.
Fan is noisy	Loose screws; Motor issue.	Check and tighten all screws; Ensure fan is installed correctly; Contact customer support if noise persists.



Bring Quiet to New Heights

Whisper
20dB

Chatting
46dB

Our
Ceiling Fan
30dB

Image: The fan operates quietly at approximately 30dB.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Wellspeed

Feature	Detail
Model Name	DY1132-5B/52
Color	Black
Size	52 inch (with downrod)
Product Dimensions	42"D x 42"W x 10"H (approximate, may vary by installation)
Item Weight	15.2 pounds
Power Source	DC Motor
Special Features	Quiet Operation, LED Light (3CCT Dimmable), Reversible Airflow, Remote Control, Timer
Room Type	Kitchen, Bedroom, Living Room, Home Office, Dining Room
Indoor/Outdoor Usage	Indoor




Image: Product dimensions for the 52-inch fan.

WARRANTY AND CUSTOMER SUPPORT

Wellspeed has over 10 years of experience in the manufacture of ceiling fans and specializes in the field. We are committed to providing high-quality products and excellent customer service.

Wellspeed will replace your parts in brand new condition without any cost if you experience a malfunction of accessories during use, such as lampshades, LED panels, or remote controls. For any questions, concerns, or

warranty claims, please contact Wellspeed customer support through your original purchase platform or visit the official Wellspeed store.