

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HORLAT](#) /

› [HORLAT Projector Tripod Stand TP-01 User Manual](#)

HORLAT TP-01

HORLAT Projector Tripod Stand TP-01 User Manual

Model: TP-01

INTRODUCTION

Thank you for choosing the HORLAT Projector Tripod Stand TP-01. This stand is specifically designed to provide stable and adjustable support for your HORLAT W10/W11 projectors. It features a 180° rotational capability, allowing for flexible projection angles. Please read this manual carefully before use to ensure proper installation and operation.

Note: This product is a projector stand. The projector itself is not included.

IMPORTANT SAFETY INFORMATION

- Ensure the stand is placed on a stable, level surface to prevent tipping.
- Do not overload the stand beyond its intended capacity. This stand is designed for HORLAT W10/W11 projectors only.
- Keep the stand away from heat sources, direct sunlight, and moisture.
- Do not attempt to modify or disassemble the stand.
- Keep out of reach of children to prevent accidents.

PACKAGE CONTENTS


Please check the package for the following items:

- HORLAT Projector Tripod Stand TP-01
- Adapter

Note: The term "Adapter" is listed in the product's package contents. This may refer to a specific mounting adapter for the projector.

PRODUCT OVERVIEW

The HORLAT TP-01 stand is designed for ease of use and stability. It features a sturdy base and a rotatable platform for your projector.



Conception Pliable

Image: The HORLAT Projector Tripod Stand TP-01, showcasing its sleek design and stable structure.



Image: Diagram illustrating the 90-degree and 45-degree rotation capabilities of the projector stand's platform.

SETUP INSTRUCTIONS

- 1. Unpack the Stand:** Carefully remove all components from the packaging.
- 2. Place the Stand:** Position the stand on a flat, stable surface where you intend to use your projector. Ensure there is enough space for the projector and its cables.
- 3. Mount the Projector:** Gently place your HORLAT W10 or W11 projector onto the stand's platform. Ensure it is centered and stable.

HORLAT

Support pour Projecteur



Exclut Le Projecteur HORLAT


Image: A HORLAT projector securely placed on the TP-01 stand, demonstrating proper mounting.

4. **Connect Cables:** Connect all necessary power and video cables to your projector. Route cables neatly to avoid obstruction or tripping hazards.

OPERATING THE STAND

The HORLAT TP-01 stand allows for easy adjustment of your projector's position and angle.

1. **Adjusting Rotation:** The projector platform can be rotated up to 180 degrees. Gently hold the projector and rotate the platform to achieve the desired projection angle. The stand is designed to hold the projector securely at various angles.



Conception pliable

Image: Diagram showing the 90-degree rotation capability of the projector stand, allowing for versatile positioning.

2. **Positioning:** Once the desired angle is set, ensure the stand remains stable. The design allows for flexible placement on various surfaces while maintaining stability.

MAINTENANCE

- **Cleaning:** To clean the stand, wipe it with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the finish.
- **Storage:** When not in use, store the stand in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check the stand for any signs of wear or damage. If any damage is found, discontinue use and contact customer support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Stand is unstable.	Uneven surface; projector not centered.	Place the stand on a flat, level surface. Ensure the projector is centered on the platform.
Difficulty rotating the platform.	Excessive force applied; obstruction.	Ensure no cables or other objects are obstructing the rotation. Apply gentle, even pressure. Do not force rotation.
Stand appears damaged.	Physical impact; manufacturing defect.	Discontinue use immediately. Contact HORLAT customer support for assistance.

SPECIFICATIONS

Feature	Detail
Brand	HORLAT
Model Number	TP-01
Compatible Devices	HORLAT W10/W11 Projectors
Mounting Type	Tripod (Desktop Stand)
Special Feature	180° Rotational Platform
Warranty	1 Year Manufacturer Warranty

WARRANTY AND CUSTOMER SUPPORT

The HORLAT Projector Tripod Stand TP-01 comes with a **1 Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact HORLAT customer service through the retailer where you purchased the product or visit the official HORLAT website for contact information.

Please have your model number (TP-01) and proof of purchase ready when contacting support.