Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RUSTOWN PDBL6070

RUSTOWN Rattan Bathroom Wall Cabinet - Instruction Manual

Model: PDBL6070

1. Important Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Always follow the assembly instructions carefully.
- Use appropriate safety gear when wall mounting the cabinet.
- Be cautious when adjusting the shelves to prevent injury.
- Do not overload the cabinet as it may cause it to tip over or damage the shelves.

2. Product Overview

The RUSTOWN Rattan Bathroom Wall Cabinet is designed for versatile storage in various rooms. It features a rustic oak finish, arched rattan doors, and metal knobs. The cabinet includes adjustable shelves and a sliding door mechanism for convenient access.




Image 2.1: Front view of the RUSTOWN Rattan Bathroom Wall Cabinet.

3. Package Contents

Before beginning assembly, ensure all parts and hardware are present and undamaged. Refer to the detailed assembly manual included in the packaging for a complete list of components and clearly labeled accessories. Extra spare parts are provided in case of accidents.

4. Assembly Instructions

Assembly of the RUSTOWN Rattan Bathroom Wall Cabinet is required. A detailed assembly manual with step-by-step instructions and diagrams is included with your product. Follow these instructions carefully for proper assembly.

1. Unpack all components and verify against the parts list in the manual.
2. Assemble the main frame of the cabinet according to the provided diagrams.

3. Install the sliding door track.
4. Attach the rattan door and handle.
5. Insert the adjustable shelves into the desired positions.



Image 4.1: Detail showing adjustable shelves and their height adjustment mechanism.

5. Installation (Wall Mounting)

This cabinet is designed for wall mounting. Ensure you have the appropriate tools and hardware for your wall type (e.g., drywall anchors, stud finder). It is recommended to have two people for safe installation.

1. Choose a suitable location on your wall, ensuring it is level and can support the weight of the cabinet and its contents.
2. Mark the drilling points accurately using a level and the provided template (if any).
3. Drill pilot holes and insert wall anchors if necessary.
4. Securely attach the cabinet to the wall using the provided mounting hardware.



Image 5.1: The cabinet installed above a toilet, demonstrating typical placement.

6. Operation

6.1 Sliding Door

The cabinet features a single sliding door with an arched rattan panel. To open or close, gently slide the door along its track using the metal handle. The design allows for a half-open, half-hidden configuration, providing flexible access to items while maintaining a tidy appearance.



Image 6.1: Close-up of the sliding door and its handle.

6.2 Adjustable Shelves

The cabinet includes three adjustable shelves. These shelves can be repositioned to different heights to accommodate items of varying sizes. To adjust a shelf, carefully remove it, align it with the desired shelf pin holes, and reinsert it securely.

7. Care and Maintenance

To ensure the longevity and appearance of your RUSTOWN cabinet, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Rattan Care:** The hand-woven rattan can be gently dusted with a soft brush or cloth. Avoid excessive moisture.
- **Moisture:** While designed for bathroom environments, avoid prolonged exposure to excessive moisture or direct water contact. Promptly wipe away any spills.
- **Inspection:** Periodically check all hardware and connections to ensure they remain tight. Tighten as needed.

8. Troubleshooting

8.1 Loose Sliding Door

If the sliding door feels loose or wiggles, ensure that the top and bottom tracks are securely fastened and free from obstructions. Check that the door is properly seated within both tracks. If the issue persists, inspect the door rollers for any damage or misalignment.

8.2 Missing or Damaged Parts

If any parts are missing or damaged upon arrival, please contact RUSTOWN customer support immediately for assistance. Refer to the contact information provided in your purchase documentation.

9. Specifications

Detailed product specifications for the RUSTOWN Rattan Bathroom Wall Cabinet (Model PDBL6070).



Image 9.1: Product dimension diagram showing height, width, and depth measurements.

Feature	Detail
Brand	RUSTOWN
Model Number	PDBL6070
Color	Natural Oak
Material	Engineered Wood
Product Dimensions (D x W x H)	7.9"D x 22.8"W x 23.6"H
Item Weight	9.8 Kilograms
Number of Shelves	3 (Adjustable)
Number of Doors	1 (Sliding Rattan Door)
Installation Type	Wall Mount
Required Assembly	Yes

Handle Material	Metal

10. Warranty and Support

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official RUSTOWN website. If you have any questions regarding assembly, parts, or product functionality, do not hesitate to contact RUSTOWN customer service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DRYRDDYZ

More documents and user manuals: **https://manuals.plus/**