

iPhanmis X17

iPhanmis X17 Smart Watch with Earbuds User Manual

Model: X17

1. INTRODUCTION

Thank you for choosing the iPhanmis X17 Smart Watch with integrated earbuds. This device combines the functionality of a smartwatch with the convenience of true wireless stereo (TWS) earbuds, offering health monitoring, fitness tracking, communication features, and music playback. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance and user experience.

Please read this manual thoroughly before using the product and retain it for future reference.

2. SAFETY INFORMATION

- Do not attempt to disassemble, repair, or modify the device. This may cause damage, electric shock, or fire.
- Keep the device away from extreme temperatures, direct sunlight, and high humidity.
- Avoid exposing the device to strong impacts or dropping it.
- Use only the provided charging cable. Using unauthorized chargers may damage the device or cause fire.
- Consult a medical professional before starting any new exercise regimen or if you have any health concerns. The health monitoring features are for reference only and should not be used for medical diagnosis or treatment.
- Keep the earbuds out of reach of children to prevent accidental ingestion.

3. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x X17 Smart Watch with Earbuds
- 1 x Charging Cable
- 1 x User Manual

4. PRODUCT OVERVIEW

The iPhanmis X17 features a 1.27-inch round AMOLED touch display and houses two TWS earbuds within its design. The watch body is constructed from glass and zinc aluminum alloy.



Image: The iPhanmis X17 Smart Watch in gold, showcasing its round display and the integrated earbuds compartment.

more function

Satisfy various needs of life




Sedentary reminder



weather forecast



Alarm clock
reminder



Physiological cycle



Photo control



Exercise timing



Health management



Search for
mobile phone

Image: Detailed view of the X17 Smart Watch with the earbud compartment open, showing the earbuds and their charging contacts.

5. GETTING STARTED

5.1 Charging the Device

Before first use, ensure both the smartwatch and earbuds are fully charged.

- **Smart Watch:** Connect the provided charging cable to the charging contacts on the back of the watch and to a USB power adapter (not included). The watch battery capacity is 205mAh. Charging time is approximately 1-2 hours.
- **Earbuds:** Place the earbuds into their designated slots within the smartwatch. The watch will automatically charge the earbuds. The earbuds have a 25mAh battery each and can be charged for approximately 2 cycles by the watch.

5.2 App Installation (FitCloudPro)

To access all features and synchronize data, download the 'FitCloudPro' application on your smartphone.

1. Scan the QR code provided in the manual or on the watch display (if available) or search for 'FitCloudPro' in your phone's app store (Google Play Store for Android, Apple App Store for iOS).
2. Install the application.
3. Ensure your phone's Bluetooth is enabled.

Watch APP download and connection

Android phones can scan the QR code or search for "FitCloudPro" to install during app duration
Apple phones can scan QR codes or search for "FitCloudPro" in the App Store
Download and install



Take out the headphones and put them in the watch
Bluetooth will automatically turn on

Open your phone
Bluetooth in settings


Find the watch
Available devices "X-Audio-i"
click to pair



Bluetooth and mobile phone connection



Open the mobile app "FitCloudPro"



Add devices on the "Devices" page



Search for device model "X17_mini"
Then click on the connection



After successful connection,
under the device of the APP
Connect model devices

Image: Instructions for downloading the FitCloudPro app via QR code or app store, and the subsequent steps for connecting the watch via Bluetooth within the app.

5.3 Watch-Phone Pairing

The watch uses Bluetooth 4.0 for connection.

1. Open the 'FitCloudPro' app on your smartphone.
2. Navigate to the 'Device' section or 'Add Device' option within the app.

3. The app will search for available devices. Select 'X17_mini' from the list to connect.
4. Confirm the pairing request on both your phone and the watch if prompted.

5.4 Earbuds-Phone Pairing

The earbuds use Bluetooth 5.0 for connection.

1. Take the earbuds out of the watch. They will automatically enter pairing mode.
2. Open your phone's Bluetooth settings.
3. Search for new devices. The earbuds will appear as 'X-Audio-1' (or similar).
4. Select the earbuds to pair.

6. SMART WATCH FUNCTIONS

6.1 Basic Operation

- **Touch Screen:** The 1.27-inch AMOLED display is fully touch-sensitive. Swipe left/right, up/down, and tap to navigate menus and select options.
- **Power Button:** Typically located on the side of the watch, used for waking the screen, returning to the home screen, or powering on/off (long press).

6.2 Customizing Watch Faces

The watch supports multiple exquisite dials to suit various styles.

- From the home screen, long-press the watch face to enter the watch face selection menu.
- Swipe left or right to browse available watch faces.
- Tap to select and apply a new watch face.
- Additional watch faces may be available for download through the 'FitCloudPro' app.

It understands you very well Women's Health Management

Based on smarter deep learning algorithms,
combined with physical sign data obtained from watches
Comprehensive prediction helps women easily cope with menstrual periods
During ovulation and easy pregnancy,
intimate reminders and care can also be provided.

Safety period

Easy pregnancy

menstrual period
Day 2

S	M	T	W	T	F	S
29	30	1	2	3	4	5
6	7	8	9	10	11	12
13	14	15	16	17	18	19
20	21	22	23	24	25	26
27	28	29	30	31		

Watches hide hidden 'mysterious' mechanisms

When you want to use headphones,
press both buttons at the same time to open the watch cover
At the same time, it avoids the problem of accidental contact
causing the headphones to shake out



Press both buttons
simultaneously to open

Heart rate
monitoring

Blood oxygen
monitoring

sleep
monitoring



Image: A collage showing various watch face designs and icons representing different sports modes like running, riding, walking, skipping, climbing, and tennis.

6.3 Health Monitoring

The X17 Smart Watch offers various health monitoring features:

- **Heart Rate Monitoring:** Continuous 24-hour heart rate tracking.
- **Sleep Monitoring:** Tracks sleep patterns and quality.
- **Blood Oxygen Monitoring:** Measures blood oxygen levels.
- **Female Cycle Tracking:** Provides intimate reminders and care based on physiological data.

Multiple exquisite dials Funds are here for you

There are multiple exquisite dials in the dial market to meet your versatile style and different occasions
Different dials can be easily converted, making you stand out every moment




Image: Illustrates the Women's Health Management feature with a calendar view, along with displays for heart rate and blood oxygen monitoring on the watch face.

Multiple sports modes

Better outdoor sports experience



6.4 Sports Modes

The watch supports multiple sports modes to track your exercise records, including pedometer, calories burned, and mileage.

- Access sports modes from the main menu.
- Select your desired activity (e.g., Running, Riding, Walking, Skipping, Climbing, Tennis).
- The watch will begin tracking your activity.

6.5 Notifications and Calls

- **Bluetooth Call:** Make and receive calls directly from the watch when connected to your phone.
- **Call Reminder/Rejection:** Receive notifications for incoming calls and choose to answer or reject them from the watch.
- **Information Alert:** Receive notifications from your smartphone apps (e.g., messages, social media) on your watch.

6.6 Other Features

- **Weather:** View current weather conditions and forecasts.
- **Alarm Clock:** Set alarms directly on the watch.
- **Shake and Take Photos:** Use the watch as a remote shutter for your phone's camera.
- **Find Phone:** Locate your paired smartphone.
- **Sedentary Reminder:** Receive alerts to move after periods of inactivity.
- **Multi-language Support:** The watch supports 24 languages, including English, German, French, Spanish, Japanese, and more.

exceeding one's expectations Headphones hidden in the watch

Intelligent sports 2-in-1 watch, headphone charging case



25 mAh
Earphone battery
3.5 hours
Duration of use



205 mAh
Watch battery
8-12 days
standby time
About 2 cycles
Charge the earphones

Fingertip agility, one touch control

The touch contact surface is wider,
allowing for easy touch
without accidentally switching between playing songs
Functions such as switching songs and disconnecting calls



Four clicks before switching
between Chinese and English pairing



Press the button for 2 seconds before
turning on the device



Press the button for 3 seconds
before shutting down



Click 4 times to wake up SIRI



Disconnect the headphones, double-click and
hold for 5 seconds to restore factory settings



touch area

Call mode



Press the button for 1.5 seconds
to reject the call



Double click the button
to answer



Double click the button
to end the call



Music Mode



Double click the button to play/pause



Click 3 times on the left or right
to switch to the previous/next track

Image: A visual representation of various smartwatch functions including sedentary reminder, weather forecast, alarm clock, physiological cycle tracking, photo control, exercise timing, health management, and 'search for mobile phone'.

7. EARBUDS FUNCTIONS

The integrated TWS earbuds offer touch control for various functions.

7.1 Earbud Touch Button Functions

- **Power On:** Press and hold the touch area for 2 seconds.
- **Power Off:** Press and hold the touch area for 3 seconds.
- **Answer/Hang Up Call:** Double-click the touch area.
- **Reject Call:** Press and hold the touch area for 1.5 seconds.
- **Play/Pause Music:** Double-click the touch area.
- **Previous Track:** Triple-click the left earbud's touch area.
- **Next Track:** Triple-click the right earbud's touch area.
- **Wake Up Voice Assistant (SIRI/Android Voice Assistant):** Four times of keystrokes.
- **Chinese/English Language Switch:** Four times of keystrokes**before pairing**.

7.2 Resetting Earbuds to Original Settings

If the earbuds encounter pairing issues, you can reset them:

1. Disconnect the earbuds from your phone's Bluetooth settings.
2. Take the earbuds out of the watch.
3. Quickly double-tap and hold the earbud touch area for 5 seconds.

8. MAINTENANCE AND CARE

- **Cleaning:** Wipe the watch and earbuds with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and dry thoroughly. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The watch earbuds are IP67 waterproof. This means they are protected from dust and can withstand immersion in water up to 1 meter for up to 30 minutes. However, avoid hot water, steam, or prolonged immersion.
- **Storage:** Store the device in a cool, dry place when not in use.

9. TROUBLESHOOTING

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
- **Earbuds not pairing:** Ensure earbuds are charged. Try resetting the earbuds as described in Section 7.2. Ensure phone Bluetooth is on and disconnect from other devices.
- **App not connecting to watch:** Ensure Bluetooth is enabled on your phone and the watch. Restart both the app and your phone. Try unpairing and re-pairing the watch through the 'FitCloudPro' app.
- **Inaccurate health data:** Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensor on the back of the watch.
- **Notifications not appearing:** Check app permissions on your phone to ensure 'FitCloudPro' has access to notifications. Verify notification settings within the 'FitCloudPro' app.

10. SPECIFICATIONS

Feature	Specification
Screen	1.27 inch 360*360 AMOLED touch display

Main Shell Material	Glass lens + Zinc aluminum alloy
Watch Battery	205mAh polymer battery
Earbuds Battery	25mAh polymer battery (each)
Music Time (Earbuds)	3.5 hours
Charging Time	1-2 hours
Earbuds Bluetooth Version	Bluetooth 5.0
Watch Bluetooth Version	Bluetooth 4.0
Compatible Systems	Android 4.4 and above; iOS 8.0 and above
Companion App	FitCloudPro
Item Weight	4.9 ounces
Memory Storage Capacity	128 MB
Water Resistance	Earbuds IP67 waterproof

11. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer. Keep your proof of purchase for warranty claims.

© 2024 iPhanmis. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DRZ225HS>

More documents and user manuals: <https://manuals.plus/>