

XTREME DIGITAL LIFESTYLE ACCESSORIES XBS9-1076-BLK

Xtreme 32-inch Bluetooth Soundbar User Manual

Model Number: XBS9-1076-BLK

INTRODUCTION

The Xtreme 32-inch Bluetooth Soundbar is designed to enhance your home entertainment system by delivering powerful, immersive audio. This soundbar produces clear, crisp highs and deep, resonating bass, bringing movies, music, and games to life. Its True Wireless Stereo (TWS) technology ensures seamless Bluetooth connectivity for a clean, wire-free setup and an enhanced stereo soundstage. This manual provides detailed instructions for setting up, operating, and maintaining your soundbar to ensure optimal performance.



Image: The Xtreme 32-inch Bluetooth Soundbar, showcasing its sleek design and the Xtreme Home Theater branding.

PACKAGE CONTENTS

Please ensure all items are present in the package:

- Xtreme 32-inch Bluetooth Soundbar
- IR Remote Control
- Power Adapter (12V AC)
- Mounting Bracket

PRODUCT OVERVIEW

Front and Top Panel Controls

The soundbar features convenient built-in controls on its top panel for easy access to essential functions:

- **Power Button:** Turns the soundbar on or off.
- **Mode Button:** Cycles through input modes (Bluetooth, AUX, Optical, Coaxial).
- **Play/Pause Button:** Controls media playback in Bluetooth mode.
- **Volume Down Button:** Decreases the volume level.
- **Volume Up Button:** Increases the volume level.



Image: A detailed view of the soundbar's top panel, highlighting the built-in controls and icons representing sound quality and power adapter.

Rear Panel Connections


The rear panel provides various input ports for connecting to your audio sources:

- **On/Off Switch:** Main power switch for the unit.
- **DC Power Input:** Connects to the included 12V AC power adapter.
- **Aux 3.5mm Input:** For connecting devices with a 3.5mm audio cable.
- **Digital Optical Input:** For connecting devices with an optical audio cable.

- **Digital Coaxial Input:** For connecting devices with a coaxial audio cable.
- **Power LED:** Indicates power status.

Rear of Soundbar

- On/Off Switch • DC Power Input • Aux 3.5mm Input • Digital Optical Input
- Digital Coaxial Input • Power LED



Mountable Design

Image: The rear panel of the soundbar, illustrating the various audio input ports and the integrated mounting points.

Mounting Options

The soundbar includes a mounting bracket, allowing for flexible placement options such as under your TV or on a wall, providing a sleek and space-saving setup.



BLUETOOTH® HOME THEATER SOUNDBAR



Image: The Xtreme Soundbar with an inset highlighting its mountable design for easy installation.

SETUP

Power Connection

1. Connect the included 12V AC power adapter to the DC Power Input port on the rear of the soundbar.
2. Plug the other end of the power adapter into a standard wall outlet.
3. Flip the On/Off switch on the rear panel to the 'On' position. The Power LED will illuminate.

Audio Connection Options

The Xtreme Soundbar offers multiple ways to connect to your audio sources:

Bluetooth Pairing

1. Ensure the soundbar is powered on.
2. Press the 'Mode' button on the soundbar or remote until 'Bluetooth' mode is selected (indicated by a blue

LED). The soundbar will enter pairing mode.

3. On your Bluetooth-enabled device (e.g., smartphone, tablet), go to the Bluetooth settings and search for available devices.
4. Select "Xtreme Soundbar" from the list. Once connected, the soundbar will emit a confirmation tone.
5. You can now stream audio wirelessly from your device to the soundbar.



Image: A smartphone displaying a music app, with sound waves indicating a Bluetooth connection to the soundbar.

Wired Connections (Aux, Optical, Coaxial)

1. Identify the appropriate audio output port on your TV or audio source (Aux 3.5mm, Optical, or Coaxial).
2. Connect one end of the corresponding audio cable (not included) to your TV/source and the other end to the matching input port on the soundbar's rear panel.
3. Press the 'Mode' button on the soundbar or remote until the correct input mode (AUX, Optical, or Coaxial) is selected.
4. Ensure your TV/source audio output settings are configured to send audio through the selected port.

Placement and Mounting

For optimal sound performance, place the soundbar centrally below your TV. If mounting, use the included bracket and follow standard wall mounting procedures, ensuring the soundbar is securely fastened and level.



Image: The Xtreme 32-inch Soundbar positioned neatly under a television, demonstrating a typical home theater setup.

OPERATING INSTRUCTIONS

Basic Operation

- **Power On/Off:** Press the Power button on the soundbar or remote.
- **Volume Control:** Use the Volume Up (+) and Volume Down (-) buttons on the soundbar or remote to adjust the volume.
- **Mode Selection:** Press the Mode button on the soundbar or remote to switch between Bluetooth, AUX, Optical, and Coaxial inputs.

Using the IR Remote Control

The included IR remote control provides full functionality from a distance, allowing you to conveniently manage your soundbar's settings without needing to access the unit directly.

BLUETOOTH® HOME THEATER SOUNDBAR



Image: A family enjoying entertainment with the Xtreme Soundbar, demonstrating the use of the remote control for convenient operation.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your soundbar.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the soundbar. Do not use liquid cleaners or abrasive materials, as they may damage the finish.
- **Storage:** When not in use for extended periods, store the soundbar in a cool, dry place away from direct sunlight and extreme temperatures.
- **Ventilation:** Ensure the soundbar has adequate ventilation and is not placed in an enclosed space that could restrict airflow.

TROUBLESHOOTING

If you encounter issues with your Xtreme Soundbar, refer to the following table for common problems and their solutions.

Problem	Possible Cause	Solution
No power	Power adapter not connected; On/Off switch is off; Power outlet issue.	Ensure power adapter is securely connected to soundbar and wall outlet. Check that the On/Off switch on the rear is in the 'On' position. Try a different power outlet.
No sound	Incorrect input mode; Volume too low; Audio cable not connected properly; TV/source audio settings.	Press the 'Mode' button to select the correct input. Increase the volume. Ensure audio cables are securely connected. Check your TV/source audio output settings.
Bluetooth connection issues	Soundbar not in pairing mode; Device too far; Interference; Previously paired device.	Ensure soundbar is in Bluetooth pairing mode. Move device closer to soundbar. Avoid obstacles. Disconnect from other Bluetooth devices. Try re-pairing.
Distorted sound	Volume too high; Poor audio source quality; Loose cable connection.	Lower the volume. Try a different audio source. Check all cable connections for tightness.

SPECIFICATIONS

Detailed technical specifications for the Xtreme 32-inch Bluetooth Soundbar:

Feature	Detail
Model Name	Xtreme 32" Inch Bluetooth Soundbar
Speaker Type	Soundbar
Product Dimensions	3.25"D x 33.5"W x 3.5"H
Item Weight	1.5 pounds
Control Method	Remote, Built-in Controls
Speaker Maximum Output Power	40 Watts
Connectivity Technology	Bluetooth
Audio Output Mode	Stereo
Mounting Type	Shelf Mount (Mounting Bracket Included)

Feature	Detail
UPC	805106237264
Item Model Number	XBS9-1076-BLK

WARRANTY INFORMATION

The Xtreme 32-inch Bluetooth Soundbar comes with a **Limited Warranty**. For specific terms, conditions, and duration of the warranty, please refer to the warranty card included with your product packaging or visit the official XTREME DIGITAL LIFESTYLE ACCESSORIES website. Keep your purchase receipt as proof of purchase for any warranty claims.

SUPPORT

For further assistance, product information, or to explore other products from XTREME DIGITAL LIFESTYLE ACCESSORIES, please visit our official store:

[Visit XTREME DIGITAL LIFESTYLE ACCESSORIES
Store](#)

You may also refer to the product listing on Amazon for frequently asked questions and customer reviews.