

OtterBox 78-80872

OtterBox Wireless Charging Stand for MagSafe (MFi Approved - 15W) Instruction Manual

Model: 78-80872

INTRODUCTION

Thank you for choosing the OtterBox Wireless Charging Stand for MagSafe. This stand provides a sleek, compact, and efficient charging solution for your MagSafe-compatible iPhone and accessories. Designed for convenience and durability, it offers a fast and secure charging experience.

WHAT'S IN THE BOX

- OtterBox Wireless Charging Stand
- OtterBox 20W Wall Charger
- OtterBox 2M (6.6FT) USB-C to USB-C Cable

SETUP

1. **Connect the USB-C Cable:** Insert one end of the provided 2M USB-C to USB-C cable into the USB-C port located on the back of the OtterBox Wireless Charging Stand.
2. **Connect to Power:** Insert the other end of the USB-C cable into the OtterBox 20W Wall Charger.
3. **Plug into Outlet:** Plug the 20W Wall Charger into a functional power outlet. The stand is now ready for use.



Image: The OtterBox Wireless Charging Stand in Brilliant Opera (White), showcasing its sleek design. The stand features a magnetic charging pad and a stable base.

OPERATING INSTRUCTIONS

1. **Place Your Device:** Position your MagSafe-compatible iPhone or MagSafe case onto the magnetic charging pad of the stand. The strong magnetic alignment will securely attach your device.
2. **Charging Confirmation:** Your device will begin charging automatically. The 15W Qi wireless charger delivers optimal 7.5W charging speeds to your iPhone.
3. **Orientation:** The stand allows you to suspend your iPhone securely in any orientation (portrait or landscape) while charging, streaming, or connecting.
4. **Removal:** To remove your device, simply twist it off the magnetic pad. The no-slip, weighted base ensures the stand remains steady.



Image: An iPhone securely attached and charging wirelessly on the OtterBox Wireless Charging Stand, displaying the charging animation.

COMPATIBILITY

The OtterBox Wireless Charging Stand is compatible with:

- iPhone models with MagSafe capability.
- MagSafe cases, including:
 - Defender Series XT
 - Defender Series XT Pro
 - Symmetry Series+
 - Aneu Series
 - Figura Series
 - Commuter Series (MagSafe Edition)

- Defender Series (MagSafe Edition)

MAINTENANCE

To ensure optimal performance and longevity of your charging stand:

- Keep the charging pad clean and free of dust or debris. Use a soft, dry cloth for cleaning.
- Avoid exposing the stand to extreme temperatures or moisture.
- Do not attempt to disassemble or modify the stand.

TROUBLESHOOTING

If you experience issues with your charging stand, consider the following:

- **Device Not Charging:** Ensure the USB-C cable is securely connected to both the stand and the wall charger, and that the wall charger is properly plugged into a live power outlet.
- **Slow Charging:** Verify that you are using the included OtterBox 20W Wall Charger or another compatible power adapter that provides sufficient wattage (at least 20W) to enable optimal 15W charging.
- **Magnetic Attachment Issues:** Confirm that your iPhone is MagSafe-compatible or is housed in a MagSafe-compatible case. Remove any non-MagSafe accessories or thick cases that may interfere with the magnetic connection.
- **Stand Stability:** Ensure the stand is placed on a flat, stable surface. The weighted base is designed for stability, but excessive force or uneven surfaces may affect it.

SPECIFICATIONS

Product Dimensions	3.2 x 4.6 x 5.48 inches
Item Weight	1.36 pounds
Item Model Number	78-80872
Brand	OtterBox
Connector Type	USB Type C
Input Voltage	3 Volts
Total USB Ports	1

Wattage	15 watts
Special Feature	Magnetic, Magsafe Compatible
Color	Brilliant Opera (White)

WARRANTY & SUPPORT

The OtterBox Wireless Charging Stand is backed by an OtterBox limited lifetime warranty. This warranty is supported by hassle-free customer service.

For detailed warranty information and support, please visit the official OtterBox website or contact their customer service directly.