

[manuals.plus](#) /› [SwanScout](#) /› [SwanScout 703A Wireless Charging Station User Manual](#)

SwanScout 703A

SwanScout 703A Wireless Charging Station User Manual

Model: S10011

1. INTRODUCTION

Thank you for choosing the SwanScout 703A Wireless Charging Station. This device is designed to provide a convenient and efficient charging solution for your compatible iPhone, Apple Watch, and AirPods. Its foldable and portable design makes it ideal for both home and travel use. Please read this manual thoroughly to ensure proper setup and operation.



Image 1: The SwanScout 703A Wireless Charging Station in use, simultaneously charging an iPhone, Apple Watch, and AirPods.

2. PACKAGE CONTENTS

- 1 x SwanScout 703A Wireless Charging Station
- 1 x USB-C Charging Cable
- 1 x User Manual

Note: A 20W PD (Power Delivery) adapter is required for fast charging and is NOT included in the package.

3. PRODUCT FEATURES

- **3-in-1 Wireless Charging:** Simultaneously charges compatible iPhone, Apple Watch, and AirPods.
- **Foldable and Portable Design:** Easy to carry for travel or storage.
- **Adjustable Digital Clock:** Features a dimmable clock display for convenience without disturbing sleep.
- **Start/Stop Charging Button:** Allows control over phone charging, also functions as a phone stand when charging is paused.
- **Case-Friendly Charging:** Supports phone cases up to 5mm (0.19 inches) thick.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Connect Power:** Insert the provided USB-C charging cable into the charging port on the back of the SwanScout 703A. Connect the other end of the cable to a 20W PD power adapter (not included) and plug it into a wall outlet.
3. **Power On:** The digital clock display will illuminate, indicating the device is powered on and ready for use.



Image 2: Connecting the SwanScout 703A to a power adapter for operation.

Your browser does not support the video tag.

Video 1: A demonstration of the SwanScout 703A charging station's features and how to use it with an iPhone, Apple Watch, and AirPods.

5. OPERATING INSTRUCTIONS

5.1 Charging Devices

- **For iPhone:** Place your compatible iPhone vertically on the main charging pad. Ensure the phone is centered for optimal charging. Phone cases should be less than 5mm (0.19 inches) thick for effective wireless charging.
- **For Apple Watch:** Place your Apple Watch on the magnetic charging module located at the top. The watch will automatically align and begin charging.
- **For AirPods:** Place your AirPods (with wireless charging case) on the base charging area.

Fast Charging* for Apple Watch



1 Hour of Charging

Device	Charging Progress
Apple Watch 10	58% 
Apple Watch Ultra 2	47% 
Apple Watch 9	40% 

*Data from SwanScout Lab, tested with a Samsung 25W PD adapter.

Image 3: Illustration of fast charging capabilities for various Apple Watch models.

Dimmable Clock for Restful Nights



06:28

06:28

06:28

100%

50%

20%

OFF

Image 4: The charging area is designed to accommodate phones with raised camera modules, ensuring stable charging.

Foldable & Portable

Perfect for Travel



Image 5: The SwanScout 703A is suitable for various environments, including nightstands and office desks.

5.2 Adjustable Digital Clock

The integrated digital clock features adjustable brightness to suit your preference, especially in low-light environments.

- **Adjust Brightness:** Press the 'Brightness Touch Button' (represented by a sun icon) on the front of the station to cycle through brightness levels (100%, 50%, 20%, OFF).
- **Set Time:** Long press the 'Time Setting' button for 3 seconds to enter hour setting mode. Short press to adjust the hour. Short press again to switch to minute setting. Long press for 3 seconds to exit setting mode.
- **12/24H System Switch:** Short press the '12/24H' button once to switch between 12-hour and 24-hour display formats.



Image 6: The dimmable clock feature provides convenience without disrupting sleep.

Elegant Tech Gray Exterior

Metallic paint finish for an elegant look and feel



Image 7: Detailed view of the clock adjustment buttons and display.

5.3 Start/Stop Charging Button

The SwanScout 703A includes a button to control phone charging. When your phone is fully charged, press the button to stop charging. This transforms the station into a phone stand. Press it again to resume charging.



Image 8: The dedicated button for starting or stopping phone charging.

6. COMPATIBILITY

The SwanScout 703A is compatible with a wide range of devices. Please refer to the following for specific models:

6.1 Compatible Phones

- iPhone:** Air, 17 Pro Max/Pro/17, 16 Pro Max/Pro/Plus/16, 15 Pro Max/Pro/Plus/15, 14 Pro Max/Pro/Plus/14, 13 Pro Max/Pro/13, 12 Pro Max/Pro/12, 11 Pro Max/Pro/11, SE, XS MAX, X, XR, 8/8 Plus. (Note: Not for iPhone 12 mini/13 mini)
- Samsung:** S25/S24/S23/S22/S21/S20/S10 Series (including Ultra/FE models), Note 20/10/9, Z Flip 6/5/4/3/2, Z Fold 6/5/4/3/2.
- Google Pixel:** 9 Pro/8/7 (including Pro/XL models), 8a, 7a, 6 Pro/6, 5, 4 (XL), 3 (XL).
- And other Qi-enabled phones.



Image 9: Detailed compatibility list for various smartphone models.

6.2 Compatible Apple Watch Models

- 5W Fast Charging:** Apple Watch Ultra 3, Ultra 2, Ultra, SE 3, Series 11, Series 10, Series 9, Series 8, Series 7.
- 2.5W Charging:** Apple Watch SE (2nd generation), SE (1st generation), Series 6, Series 5, Series 4, Series 3, Series 2, Series 1.

Image 10: Compatibility and charging speeds for Apple Watch models.

6.3 Compatible Wireless Earbuds

- **AirPods:** Pro 3, 4 (with Active Noise Cancellation), Pro 2, 3rd generation, 2, 1, Pro.
- **Galaxy Buds:** 3 Pro, 3, 2 Pro, 2, Buds+, Pro, Live.
- **Google Pixel Buds:** Pro, 2.
- And all other wireless earbuds with a wireless charging case.

for Wireless Phones		
For iPhone	For Samsung	For Google
iPhone Air iPhone 17 iPhone 17 Pro (Max) iPhone 16 (Plus) iPhone 16 Pro (Max) iPhone 15 (Plus) iPhone 15 Pro (Max) iPhone 14 (Plus) iPhone 14 Pro (Max) iPhone 13 Pro (Max) iPhone 12 Pro (Max) iPhone 8 and above (Not for iPhone 12 mini/13 mini)	Galaxy S25 (+/Ultra) Galaxy S24 (+/Ultra/FE) Galaxy S23 (+/Ultra/FE) Galaxy S22 (+/Ultra/FE) Galaxy S21 (+/Ultra/FE) Galaxy S20 (+/Ultra/FE) Galaxy S10 (+) Note 20/10/10+/9 Z Flip 6/5/4/3/2 Z Fold 6/5/4/3/2	Pixel 9 (Pro) Pixel 9 Pro XL Pixel 8 (Pro) Pixel 8a Pixel 7 (Pro) Pixel 7a Pixel 6 (Pro) Pixel 5 Pixel 4 (XL) Pixel 3 (XL)

Image 11: Compatibility list for various wireless earbud models.

6.4 Phone Case Considerations

For optimal wireless charging, ensure your phone case is less than 5mm (0.19 inches) thick. Remove any magnetic pads, metal cases, credit cards, or metal rings from your phone case before charging, as these can interfere with the wireless charging function.

3.5W for Wireless Earbuds	
for Airpods Pro 3 for AirPods 4 (ANC) for AirPods Pro 2 for AirPods Pro for AirPods 3	for Galaxy Buds for Galaxy Buds + for Galaxy Buds Pro for Galaxy Buds Live
for Galaxy Buds 3 Pro for Galaxy Buds 3	for Google Pixel Buds Pro for Google Pixel Buds Pro 2
for Galaxy Buds 2 Pro for Galaxy Buds 2	and other earbuds with wireless charging case

Image 12: Guidelines for phone case compatibility with the wireless charger.

7. MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the surface of the charging station. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** When not in use, store the charging station in a cool, dry place, away from direct sunlight and extreme temperatures. Its foldable design allows for compact storage.

Friendly Design for Raised Phone Cameras



The charging area fits phones perfectly, ensuring efficient and stable charging.

Image 13: The foldable design makes the charging station easy to store and transport.

8. TROUBLESHOOTING

- **Device not charging:**

- Ensure the charging station is properly connected to a 20W PD power adapter and a working power outlet.
- Verify that your device is wirelessly charging compatible and correctly placed on the charging area.
- Check for any foreign objects or thick cases (over 5mm) that might be obstructing the charging connection.
- Try restarting the charging station by unplugging and re-plugging it.

- **Slow charging:**

- Confirm you are using a 20W PD power adapter. Lower wattage adapters may result in slower charging speeds.
- Ensure your device is properly aligned on the charging pad.

- **Clock display not working or incorrect:**

- Check if the charging station is powered on.
- Refer to section 5.2 for instructions on setting the time.

9. SPECIFICATIONS

Feature	Detail
Model Number	S10011
Package Dimensions	6.18 x 3.5 x 3.43 inches
Item Weight	8.7 ounces
Connector Type	USB Type C
Input Voltage	9 Volts
Amperage	2 Amps
Total USB Ports	1
Special Features	Fast Charging, Lightweight Design, Multi Device Charging, Portable for Travel, Wireless Charging
Color	Technology Gray

10. SAFETY INFORMATION

- Do not disassemble, modify, or repair the device yourself.
- Keep the device away from water, moisture, and high temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Use only the provided charging cable and a compatible power adapter (20W PD recommended).
- Keep out of reach of children.

11. WARRANTY AND SUPPORT

SwanScout is committed to providing high-quality products and customer satisfaction. If you encounter any issues or have questions regarding your SwanScout 703A Wireless Charging Station, please contact our customer service team. Refer to the contact information provided in your product packaging or visit the official SwanScout website for support.

Please retain your proof of purchase for any warranty claims.

