

- Manuals.plus /
- › BrickSoul /
 - › BrickSoul LED Light Kit for Lego Fortnite Supply Llama 77071 - Instruction Manual

BrickSoul 77071 Upgrade Design Light

BrickSoul LED Light Kit for Lego Fortnite Supply Llama 77071

Instruction Manual

Introduction	Safety Information	What's in the Box	Setup & Installation	Operation	Maintenance
Troubleshooting	Specifications	Warranty & Support			

1. INTRODUCTION

This manual provides detailed instructions for the installation and operation of your BrickSoul LED Light Kit, designed specifically for the Lego Fortnite Supply Llama 77071 building set. This lighting kit enhances your model by adding vibrant illumination, transforming it into a dynamic display piece. Please note that the Lego building set itself is **not included** with this lighting kit.

CREATE STUNNING VISUAL EFFECTS

MODEL FOR DISPLAY ONLY – NOT INCLUDED



Light Off



Lost in Darkness



VS

Light On



Lively and Impressive



Image: Comparison of the Lego Fortnite Supply Llama 77071 without lights (left) and with the BrickSoul LED Light Kit installed (right), showcasing the enhanced visual effect.

2. SAFETY INFORMATION

Please read and understand all safety information before installing or using the product.

- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age. Keep all components out of reach of small children.
- Ensure proper handling of wires to prevent damage. Do not bend wires excessively or apply undue force.
- Use only the recommended power input of 3-5V via USB. Using incorrect voltage may damage the lights or the model.
- Do not attempt to modify the electrical components of the kit.

3. WHAT'S IN THE BOX

Verify that all components listed below are present in your package:

- 77071 Supply Llama LED Light Up Kit components
- Battery Box (AAA batteries not included)
- Installation Guide (digital access via QR code/website)

Light Kit Only – Not Model

Package Include:



Light Kits



Instructions for Use



Battery Box
AAA not included

Image: The package contents, including the light kits, battery box, and instructions for use.

4. SETUP & INSTALLATION

The BrickSoul LED kit is designed for easy installation. Follow the detailed online instructions for a seamless setup.

4.1 Accessing Installation Instructions

A comprehensive, step-by-step installation guide is available online. This guide includes both video and PDF formats to assist you.

- Scan the QR code provided in your package or visit the BrickSoul website.
- Input the product model number (77071) to find the specific instructions for your kit.



Image: A tablet displaying the digital installation instructions for the 77071 light kit, accessible via QR code or website.

4.2 General Installation Tips

- **Preparation:** Carefully remove a few bricks from your Lego model as indicated in the online guide.
- **Wire Management:** The kit is designed for clean wiring. Route wires neatly to avoid tangles and ensure they do not interfere with the model's structure.
- **Component Placement:** Place LED components precisely according to the instructions to achieve the intended lighting effects.
- **Power Connection:** Connect the lighting kit to the provided battery box (requires AAA batteries, not included) or a USB power source (3-5V recommended).

BRINGING EVERY DETAIL TO LIFE

Model is for Display Use Only and NOT INCLUDED



Image: Detailed views of the LED lights integrated into various parts of the Lego model, highlighting the precise placement and illumination.

4.3 Installation Video Guide

For visual assistance, please refer to the official installation video:

Your browser does not support the video tag.

Video: Official installation guide for the BrickSoul LED light kit for Lego 77071, demonstrating the setup process.

5. OPERATING INSTRUCTIONS

Once installed, operating your BrickSoul LED Light Kit is straightforward.

- **Power On:** Ensure the battery box has fresh AAA batteries installed or the USB cable is connected to a compatible power source.
- **Activation:** Depending on your kit's design, activate the lights via a switch on the battery box or a connected USB power source.

- **Power Off:** Disconnect the USB cable or turn off the switch on the battery box when not in use to conserve power.



Image: The illuminated Lego Fortnite Supply Llama 77071 displayed in a room, showcasing the visual impact of the installed LED lights.

6. MAINTENANCE

To ensure the longevity and optimal performance of your BrickSoul LED Light Kit, follow these maintenance guidelines:

- **Cleaning:** Gently dust the LED components and wires with a soft, dry cloth. Avoid using liquid cleaners directly on the electrical parts.
- **Wire Inspection:** Periodically check wires for any signs of wear, fraying, or damage. Ensure all connections remain secure.
- **Battery Replacement:** If using the battery box, replace AAA batteries as needed to maintain consistent light output. Remove batteries if the kit will not be used for an extended period.
- **Storage:** When not on display, store the model with the light kit in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

If you encounter any issues with your BrickSoul LED Light Kit, refer to the following common solutions:

- **Lights Not Turning On:**
 - Check if the power source (USB or battery box) is properly connected and functioning.
 - If using batteries, ensure they are correctly inserted and not depleted.
 - Verify that all wire connectors are securely attached. Small connectors require careful handling.
- **Flickering Lights:**
 - Inspect wire connections for looseness.
 - Ensure the power source provides stable voltage.
- **Damaged Components:**
 - If you experience a bent connector or broken wire during installation, contact BrickSoul customer support for assistance.
- **Difficulty with Installation:**
 - Re-examine the online video and PDF guides carefully. Pay close attention to the numbered steps and visual cues.
 - Ensure you are using the correct components for each step.

If these steps do not resolve the issue, please contact BrickSoul customer support for further assistance.

8. SPECIFICATIONS

Feature	Detail
Product Model Number	BS-77071-cv
Compatible Lego Set	Fortnite Supply Llama 77071
Power Input	USB (3-5V recommended) or AAA Battery Box
Product Dimensions	5.18 x 6.1 x 1.18 inches
Item Weight	5 ounces
Manufacturer Recommended Age	14 years and up
Manufacturer	BrickSoul

9. WARRANTY & SUPPORT

BrickSoul is committed to providing high-quality products and excellent customer service.

9.1 Worry-Free Warranty

Your BrickSoul LED Light Kit comes with a worry-free warranty. If you experience accidental damage, such as a bent connector or broken wire, we offer quick and hassle-free replacements to ensure your building experience remains smooth.

9.2 Customer Support

For any questions, concerns, or support needs, please contact the BrickSoul support team. Our team is dedicated to ensuring a stress-free lighting experience for all our customers.

Please refer to the contact information provided in your package or on the official BrickSoul website for the most up-to-date support channels.

© 2026 BrickSoul. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question