

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Oilsky](#) /
- › [Oilsky 128GB Bluetooth 5.4 MP3 Player M1 User Manual](#)

Oilsky M1

Oilsky 128GB Bluetooth 5.4 MP3 Player M1 User Manual

Model: M1 | Brand: Oilsky

INTRODUCTION

Welcome to the user manual for your new Oilsky M1 128GB Bluetooth 5.4 MP3 Player. This guide provides essential information on how to set up, operate, and maintain your device, ensuring you get the best experience from its advanced features. Please read this manual thoroughly before using the product.

PRODUCT FEATURES

- **Bluetooth 5.4 Connectivity:** Enjoy a more stable connection and extended range with Bluetooth 5.4. The device features a Bluetooth memory function for automatic reconnection upon startup, optimizing power consumption and battery life.
- **High-Fidelity Audio:** Equipped with a professional digital noise reduction chip, this MP3 player delivers high-quality audio. It supports various common audio formats including MP3, WMA, APE, FLAC, WAV, and AAC. Organize your music by title, folder, artist, or album.
- **Generous 128GB Internal Memory:** The Oilsky M1 comes with 128GB of built-in memory, capable of storing approximately 16,000 lossless quality songs. It also includes a Micro-SD card slot, supporting expansion up to an additional 128GB (Micro-SD card not included).
- **Multi-functional Device:** Featuring a 2.4-inch touch screen for quick function selection, this MP3 player offers a range of features including music playback, FM radio, voice recorder, e-book reader, photo viewer, alarm clock, folder management, and calendar. It supports 29 languages, including English, German, French, Italian, and Spanish.
- **Long-lasting 300mAh Battery:** Enjoy up to 50 hours of lossless music playback on a single charge. The device fully recharges in approximately 2 hours, making it an ideal companion for travel or sports enthusiasts.
- **Important Note:** This device cannot connect to mobile phones or car audio systems via Bluetooth.

WHAT'S IN THE BOX

Verify that all items are present in the package:

- 1x Oilsky M1 MP3 Player

- 1x USB Charging Cable
- 1x Earphones
- 1x User Manual
- 1x Protective Case
- 1x Lanyard




Image: Contents of the product box, including the MP3 player, user manual, earphones, USB cable, protective case, and lanyard.

SETUP

1. Charging the Device

Before first use, fully charge your MP3 player. Connect the provided USB cable to the device's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The battery indicator on the screen will show charging status.

2. Power On/Off

- **To Power On:** Press and hold the power button until the screen lights up.
- **To Power Off:** Press and hold the power button until the power-off options appear, then select 'Power Off'.

3. Initial Language Selection

Upon first startup, you may be prompted to select your preferred language. Follow the on-screen instructions to choose from the available languages.

OPERATING INSTRUCTIONS

Basic Navigation

The Oilsky M1 features a 2.4-inch full touch screen for intuitive navigation. Swipe left/right or up/down to browse menus and tap icons to select functions. Use the back arrow icon to return to the previous screen.




Image: Easy navigation using the full touch screen interface.

Music Playback

1. **Transferring Music:** Connect the MP3 player to your computer using the USB cable. The device will appear as a removable disk. Drag and drop your music files (MP3, WMA, APE, FLAC, WAV, AAC) into the 'Music' folder on the device.
2. **Playing Music:** From the main menu, tap the 'Music' icon. You can browse your songs by title, artist, album, or folder. Tap a song to begin playback.
3. **Controls:** Use the on-screen controls for play/pause, next/previous track, volume adjustment, and repeat modes.

High-Quality Sound

Adapt to the most popular music formats: MP3, WMA, APE, FLAC, WAV, AAC, bringing you the best music experience.




Image: Enjoying high-quality sound with the MP3 player.

Bluetooth Connection

To connect to Bluetooth headphones or speakers:

1. Ensure your Bluetooth headphones/speaker are in pairing mode.
2. On the MP3 player, go to the main menu and tap the 'Bluetooth' icon.
3. Turn Bluetooth 'On'. The device will scan for available devices.
4. Select your desired device from the list to pair. Once paired, the device will automatically reconnect when turned on, if the paired device is within range.

Wireless Bluetooth 5.4



Image: Wireless Bluetooth 5.4 for stable audio streaming.

FM Radio

To use the FM Radio function, connect the wired earphones (included) as they act as the antenna. From the main menu, tap the 'FM Radio' icon. You can auto-scan for stations or manually tune.

Voice Recorder

Tap the 'Recordings' icon from the main menu. Use the on-screen controls to start, pause, and save recordings. The built-in microphone captures clear audio.

E-book Reader

Transfer TXT format e-books to the device. Tap the 'E-book' icon to access your library and read on the 2.4-inch screen.

Photo Viewer

Transfer JPEG or BMP image files to the device. Tap the 'Pictures' icon to view your photos.

Alarm Clock

Set alarms by tapping the 'Alarm' icon. You can customize alarm times and sounds.

Multi-Function Mp3 player

This mp3 player support: Music, Radio, Recorder, Pictures, Bluetooth, Folder, Alarm, Settings, Calendar, Ebook



Image: The MP3 player's multi-functional interface.

STORAGE MANAGEMENT

The Oilsky M1 comes with 128GB of internal storage. If you require more space, you can insert a Micro-SD card (up to 128GB, not included) into the designated slot. The device will automatically detect the external storage, allowing you to manage files across both internal and external memory.

128GB Internal Memory

Built -in 128GB memory also Support SD Card up to 128GB(not Included)



16000 songs
in the mp3 players



128GB
Support SD Card



Image: 128GB internal memory with Micro-SD card support.

SPECIFICATIONS

Model Number	M1
Brand	Oilsky
Screen Size	2.4 Inches
Display Technology	Touch Screen
Connectivity Technology	Auxiliary, Bluetooth 5.4, USB
Internal Storage Capacity	128 GB
Expandable Memory	Micro SD (up to 128GB)
Supported Audio Standards	MP3, WMA, APE, FLAC, WAV, AAC
Battery Type	1 Lithium-polymer (included)
Average Battery Life	Up to 50 hours (music playback)

Charging Time	Approx. 2 hours
Item Weight	63.5 Grams
Item Dimensions (L x W x H)	7 x 5 x 1 centimeters (approx. 2.75 x 1.98 x 0.4 inches)
Special Feature	Built-in Speaker
Compatible Devices	Personal Computer, Headphones, Smartphone (for file transfer)

TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. If the battery is depleted, connect it to a power source and allow it to charge for at least 10 minutes before attempting to power on again.
- **Cannot connect to Bluetooth devices:** Ensure both the MP3 player's Bluetooth and the target device's Bluetooth are enabled and in pairing mode. Remember, this MP3 player cannot connect to mobile phones or car audio systems via Bluetooth.
- **No sound:** Check the volume level. Ensure earphones are properly connected if not using Bluetooth. If using Bluetooth, ensure the device is correctly paired and connected to your audio output.
- **Files not appearing:** Ensure music files are in supported formats (MP3, WMA, APE, FLAC, WAV, AAC) and transferred to the correct folders. For e-books, ensure they are in TXT format.
- **Device frozen or unresponsive:** Press and hold the power button for about 10-15 seconds to force a restart.

SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Keep the device away from water and other liquids.
- Use only the provided USB cable for charging.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Listening to audio at high volumes for extended periods can cause hearing damage.

WARRANTY AND SUPPORT

For any questions or concerns regarding your Oilsky M1 MP3 Player, please do not hesitate to contact our customer support. We are committed to providing excellent service and will be happy to assist you. Manufacturer's warranty information is available upon request or from the point of purchase.

PRODUCT OVERVIEW VIDEO

Your browser does not support the video tag.

Video: An overview showcasing the Oilsky M1 MP3 Player's features, including Bluetooth connectivity, 128GB storage, touch screen interface, and multi-functional capabilities.