

[Manuals.plus](#) /

› [Koonie](#) /

› Koonie 10 Inch Camping Misting Fan F6201 Instruction Manual

Koonie F6201

Koonie 10 Inch Camping Misting Fan

MODEL: F6201 - INSTRUCTION MANUAL

Introduction

Thank you for choosing the Koonie 10 Inch Camping Misting Fan. This portable and versatile device is designed to provide powerful cooling and refreshing mist for various outdoor and indoor environments. Featuring a large water tank, long-lasting battery, multiple fan speeds, mist modes, and adjustable oscillation, this fan ensures comfort wherever you go. Please read this manual thoroughly before use to ensure proper operation and maintenance.

Package Contents

Verify that all items listed below are included in your package:

- Fan Unit with Water Bucket
- Type-C Charging Cable
- Remote Controller
- User Manual

Package List

Fan with Bucket

Type-C Cable

Remote Controller

User Manual



Image: The package contents including the fan unit, water bucket, Type-C cable, remote, and user manual.

Setup

Follow these steps to set up your Koonie Misting Fan:

- Separate Fan Unit from Water Tank:** Align the two blocks on the fan base parallel to the fan unit. Gently lift the fan unit from the water bucket.
- Fill Water Tank:** Remove the fan unit completely. Fill the 11L water tank with clean water. Do not exceed the 'MAX' fill line indicated inside the tank.
- Connect Water Hose:** Ensure the water hose from the fan unit is properly inserted into the water tank.
- Reattach Fan Unit:** Carefully place the fan unit back onto the water tank, ensuring the water hose is not pinched. Align the two blocks on the fan base vertically to the fan unit to lock it securely in place.

**Endless Refresh,
On Demand!**



Image: A person pouring water into the 11L water tank of the misting fan.

Timed Comfort

1 / 2 / 4 / 8H, or 0H for Non-Stop



Image: The fan unit is shown detached from the water tank, demonstrating how it can be tucked in for compact storage or separated for filling.

Video: A detailed user guide demonstrating the setup and basic functions of the Koonie 10 Inch Camping Misting Fan.

Operating Instructions

Your Koonie Misting Fan can be operated using the control panel on the unit or the included remote control.

Power On/Off

Press the power button () on the control panel or remote to turn the fan on or off. The LED display will show the current battery percentage when powered on.

Fan Speed Settings

Press the fan speed button () to cycle through 4 wind speed settings (F1-F4). F4 is the highest speed.




Image: The fan unit illustrating the four different wind speed settings for customized cooling.

Misting Modes

Press the mist button () to select from 3 misting modes: 1-hole, 3-holes, or 5-holes. Each press cycles to the next mode, increasing mist output.

5 Spray Misting

Heat to Instant Cool



Mist Output
0.24-1.2 L/H



Image: The fan operating with all five misting nozzles active, producing a visible spray.

Oscillation and Tilt

Press the oscillation button (🌀) to activate 45° or 90° oscillation. The fan head can also be manually tilted up to 10° to direct airflow.

Angle Your Cool

45°/90° Swing & 10° Manual Tilt



Image: An aerial view showing the fan's adjustable oscillation angles (45° and 90°) and 10° manual tilt feature, covering a wide area.

Timer Function

Press the timer button () to set an automatic shut-off timer for 1, 2, 4, or 8 hours. Selecting '0H' means the fan will operate continuously.

Stay Cool, All Day Long



Image: The fan unit displaying an 8-hour timer setting, providing timed comfort for users.

LED Display

The integrated LED display shows current settings such as fan speed, mist mode, timer, and battery percentage, allowing for easy monitoring.

Video: Demonstrates the misting function of the fan, highlighting its cooling capabilities with or without mist.

Features Overview

- **Powerful Cooling:** Combines 4 fan speeds with 3 misting modes for effective personal cooling.
- **Long-Lasting Operation:** Equipped with a 20000mAh battery and an 11L water tank, providing extended cooling without frequent refills or recharges.

- **Wide Coverage:** Features 45°/90° oscillation and 10° manual tilt to distribute cool air and mist over a broad area.
- **Dual Control:** Easily manage settings via the intuitive control panel or the convenient remote control.
- **Portable Design:** The fan unit tucks into the water tank for compact storage, and a built-in handle ensures easy transport.



Image: The fan displaying battery percentage and indicating long work times on a full charge.

Package List

Fan with Bucket

Type-C Cable

Remote Controller

User Manual



Image: A person carrying the portable misting fan by its integrated handle, highlighting its ease of transport.

Maintenance

Regular maintenance ensures optimal performance and longevity of your misting fan.

- **Cleaning Fan Blades:** Periodically wipe the fan blades with a soft, damp cloth to remove dust and debris. Ensure the fan is turned off and unplugged before cleaning.
- **Cleaning Mist Nozzles:** If mist output decreases, gently clean the mist nozzles with a soft brush or cotton swab to remove any mineral buildup.
- **Water Tank Cleaning:** Empty and rinse the water tank regularly, especially if not in use for extended periods, to prevent mold or mildew growth. Use mild soap and water if necessary, then rinse thoroughly.
- **Storage:** When storing the fan, ensure the water tank is empty and dry. The fan unit can be tucked into the water tank for compact storage.

Troubleshooting

If you encounter any issues with your Koonie Misting Fan, refer to the following common solutions:

- **Fan Not Turning On:** Check if the battery is charged. Connect the fan to a power source using the Type-C cable.
- **No Mist Output:** Ensure the water tank is filled with water. Check if the water hose is properly connected and not kinked. Clean the mist nozzles for any blockages.
- **Weak Airflow:** Increase the fan speed setting. Ensure the fan grille is free from obstructions.
- **Unusual Noise:** Turn off the fan and check for any foreign objects obstructing the fan blades.

Specifications

Brand	Koonie
Model Name	Koonie 10" Floor Misting Fan
Model Number	F6201
Color	Black
Power Source	Electric (Battery)
Battery Capacity	20000mAh
Water Tank Capacity	11 Liters
Number of Speeds	4
Misting Modes	3 (1-3-5 holes)
Oscillation	45°/90°
Tilt Angle	10° (Manual)
Timer Settings	1H/2H/4H/8H (0H for continuous)
Control Method	Remote Control, Push Button
Product Dimensions	8.6"D x 3.99"W x 11.4"H
Item Weight	5 Pounds
Material	Plastic
Connector Type	USB Type C

Misting Fan Working Time

Fan Mode	Level 1	Level 2	Level 3	Level 4
Fan Only	32 ± 2H	20 ± 1H	13 ± 1H	9.5 ± 0.5H
Fan + Swing	19 ± 1H	14.5 ± 1H	10 ± 1H	8 ± 0.5H
Fan + Swing + Spray (Mode 1)	13.5 ± 1H	11 ± 1H	8.5 ± 0.5H	8 ± 0.5H
Fan + Swing + Spray (Mode 2)	9 ± 0.5H	8 ± 0.5H	7 ± 0.5H	5.5 ± 0.5H
Fan + Swing + Spray (Mode 3)	6.5 ± 0.5H	6 ± 0.5H	5 ± 0.5H	4.5 ± 0.5H

Image: A table detailing the approximate working times of the misting fan under different fan modes, mist settings, and speed levels.

Warranty and Support

Koonie products are manufactured to high-quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or visit the official Koonie website. Please retain your proof of purchase for warranty claims.