

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HAWANA](#) /

› [HAWANA Portable Fan User Manual](#)

HAWANA TT-15

HAWANA Portable Fan User Manual

Model: TT-15

Brand: HAWANA

INTRODUCTION

This user manual provides detailed instructions for the HAWANA Portable Fan (Model: TT-15). This versatile device combines a powerful fan, an emergency light, and a power bank, designed for various indoor and outdoor applications, including camping, tents, BBQ, and fishing. Please read this manual thoroughly before operating the fan to ensure proper use and maintenance.

PRODUCT FEATURES

- 20000mAh Rechargeable Battery:** Provides 5-36 hours of operation depending on usage. Supports charging other devices (phones, GPS) while the fan is in use.
- Twin Turbines, Dual-Blade & Dual-Motor System:** Delivers significantly more airflow than standard fans, with 13-speed adjustable airflow for customized cooling.
- Integrated LED Lighting:** Features 4 ultra-bright LEDs with 3 adjustable brightness settings, suitable for tent lighting or emergency situations.
- 360° Airflow Coverage:** Offers wide-angle oscillation (45°/90° auto swing) and 270° manual vertical pivot for versatile air direction.
- Portable Design with Hanging Hook:** Equipped with a foldout hook for hanging in tents, on branches, or in RVs, and a portable handle for easy transport.
- Timer Function:** Customizable 1, 2, or 3-hour working time to conserve power.
- Night Mode:** Allows turning off indicator lights for undisturbed sleep.
- Durable Construction:** Rugged ABS construction designed to withstand drops, with a sealed rubber charge port for water and dust resistance.

PACKAGE CONTENTS


Upon opening the package, please verify that all items listed below are included:

- HAWANA 20,000mAh Camping Fan x 1
- 4ft USB-C Charging Cable x 1
- Remote Controller x 1

- User Manual x 1
- Packaging Box x 1

Packing List

20,000mAh
Camping Fan *1



Packaging Box *1

4ft USB-C Charging Cable *1

Remote Controller*1

User Manual *1

Image: Contents of the HAWANA Portable Fan package, including the fan, remote, charging cable, and manual.

SETUP

Initial Charging

Before first use, fully charge the fan. Connect the provided USB-C charging cable to the fan's charging port and plug the other end into a compatible USB power adapter (not included). The battery indicator lights will show charging progress. A full charge can take several hours.



Image: The fan's USB-C port being used to charge an external device, demonstrating its power bank capability.

Placement

The fan can be used freestanding on a flat surface or hung using its integrated hook. Ensure the fan is placed on a stable surface or securely hung to prevent tipping.

- **Freestanding:** Place the fan on a table, floor, or any stable flat surface.
- **Hanging:** Unfold the integrated hook located on the top of the fan and hang it from a tent pole, branch, or other suitable support.



Image: The HAWANA Portable Fan showcasing its versatile design, usable as a freestanding unit or hung from its integrated hook, alongside its remote control and power bank function.

OPERATING INSTRUCTIONS

Power On/Off

To turn the fan on or off, rotate the stepless speed control knob clockwise to turn on and increase speed, or counter-clockwise to decrease speed and turn off.

Fan Speed Adjustment

The fan features a stepless speed control knob. Rotate the knob to precisely adjust the wind speed from minimum to maximum (13 levels). The fan can also be controlled via the remote control.

Stepless Wind Speed

Just one spin to choose your perfect breeze from Wind Speed 1 to 13



Timer Mode
1H/2H/3H



Sleep Mode
Automatically turn off all lights

Image: The fan's stepless speed control knob and timer settings, demonstrating its quiet operation suitable for sleeping.

LED Light Operation

Press the light button on the control panel or remote control to cycle through the 3 brightness settings. Press again to turn the light off.

Emergency Essentials for Power Outages

20000mah battery power & 3 levels brightness



Image: The fan's integrated LED light providing illumination in a dark environment, with an illustration of its three brightness levels.

Oscillation and Manual Pivot

- **Auto Oscillation:** Press the oscillation button on the control panel or remote to activate 45° or 90° automatic horizontal swing. Press again to stop.
- **Manual Pivot:** The fan head can be manually adjusted 270° vertically (up and down) to direct airflow precisely.

360° Wide-Area Airflow

The wind that follows your moves



Image: The fan's wide-angle oscillation and manual pivot features, ensuring broad airflow coverage for multiple users.

Timer Function

Press the timer button on the control panel or remote to set the fan to operate for 1, 2, or 3 hours. The fan will automatically turn off after the selected time.

Night Mode

To activate night mode, which turns off all indicator lights for undisturbed sleep, refer to the specific instructions in the included user manual for the exact button sequence or setting.

Power Bank Function

The fan's 20000mAh battery can be used to charge other USB-powered devices. Locate the USB output port on the fan and connect your device using a compatible USB cable.

MAINTENANCE

Cleaning

- Always turn off the fan and unplug it before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- For the fan blades, use a dry cloth or a soft brush to gently remove dust. Do not immerse the fan in water or any other liquid.

Storage

When not in use for extended periods, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the battery is partially charged (around 50%) before storage to prolong its lifespan.

Battery Care

- Charge the fan regularly, even if not in frequent use, to maintain battery health.
- Avoid completely draining the battery before recharging.
- Do not expose the battery to high temperatures or direct heat.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is depleted.	Charge the fan using the provided USB-C cable.
	Power knob is not turned sufficiently.	Rotate the power knob clockwise past the 'off' position.
LED light does not turn on.	Light function is off or battery is low.	Press the light button to cycle through brightness settings. Charge the fan if battery is low.
Weak or no airflow.	Fan speed is set too low or blades are obstructed.	Increase fan speed using the knob or remote. Check for obstructions and clean blades if necessary.
Fan does not oscillate.	Oscillation function is not activated.	Press the oscillation button on the control panel or remote.
Device not charging from fan (power bank function).	Fan battery is low or cable is faulty.	Ensure the fan has sufficient charge. Try a different USB cable.

SPECIFICATIONS

Feature	Detail
Brand	HAWANA
Model Name	TT-15
Color	Black
Power Source	Battery Powered

Feature	Detail
Battery Type	Lithium Polymer (included)
Battery Capacity	20,000mAh
Product Dimensions	8"D x 5"W x 11"H
Item Weight	2.72 pounds
Wattage	12 Watt-hours
Voltage	5 Volts
Air Flow Capacity	14 Cubic Feet Per Second
Number of Blades	10
Number of Power Levels	13 (Stepless)
Control Method	Touch, Remote
Special Features	Remote Controlled, Portable, LED Light, Adjustable Tilt, Oscillating
Indoor/Outdoor Usage	Outdoor
Certifications	CE, FCC, RoHS, UKCA

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official HAWANA website. Keep your purchase receipt for warranty claims.