

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lafocuse](#) /

› [Lafocuse 10-inch LCD Digital Wall and Table Clock Instruction Manual](#)

Lafocuse ZH0152B

Lafocuse 10-inch LCD Digital Wall and Table Clock Instruction Manual

Model: ZH0152B

INTRODUCTION

This manual provides comprehensive instructions for the Lafocuse 10-inch LCD Digital Wall and Table Clock, model ZH0152B. It covers essential information regarding setup, operation, maintenance, and troubleshooting. Please read this manual thoroughly to ensure proper use and longevity of your device.



Image: Front view of the Lafocuse 10-inch LCD Digital Clock, showing its clear display with time, date, day of the week, temperature, and humidity.

SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.

- Avoid dropping the clock or subjecting it to strong impacts.
- Keep out of reach of children.
- Dispose of used batteries responsibly according to local regulations.
- Do not mix old and new batteries, or different types of batteries.

PACKAGE CONTENTS

Please check the package for the following items:

- Lafocuse 10-inch LCD Digital Clock (Model: ZH0152B)
- Instruction Manual (This document)

Note: 3 AAA batteries are required for operation and are not included in the package.

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of the clock.
2. Open the battery compartment cover.
3. Insert 3 new AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

3 AAA Batteries Operated

Batteries Not Included



Image: Illustration of battery installation, showing the open battery compartment for 3 AAA batteries.

2. Placement Options

The Lafocuse digital clock can be used as a wall clock or a table clock.

- **For Wall Mounting:** Use the integrated hanging hooks on the back of the clock. Ensure the wall fasteners (not included) are suitable for the clock's weight (approximately 320g).
- **For Tabletop Use:** Extend the sturdy support stand located on the back of the clock to place it on any flat surface.

Hanging



Placing



Image: Demonstrates the clock's versatility, showing it both hanging on a wall and placed on a table.

OPERATING INSTRUCTIONS

Familiarize yourself with the control buttons located on the top and back of the clock:

Overview



- 1 Set
- 2 Alarm
- 3 Snooze
- 4 Up
- 5 Down



- 6 Hook for Hanging
- 7 Battery Compartment
- 8 Stand for Placing

Image: Overview of the clock's buttons and features, including 'Set', 'Alarm', 'Snooze', 'Up', 'Down' buttons, hanging hooks, battery compartment, and stand.

1. Setting Time and Date

1. Press the **SET** button once to enter time setting mode. The hour digits will flash.
2. Use the **UP** or **DOWN** buttons to adjust the hour.
3. Press **SET** again to move to minute setting. Adjust with **UP** or **DOWN**.
4. Continue pressing **SET** to cycle through setting year, month, and day, adjusting each with **UP** or **DOWN**.
5. After setting the day, press **SET** one last time to exit setting mode.

2. Setting Alarm

1. Press the **ALARM** button once to enter alarm setting mode. The alarm hour digits will flash.
2. Use the **UP** or **DOWN** buttons to adjust the alarm hour.
3. Press **ALARM** again to move to alarm minute setting. Adjust with **UP** or **DOWN**.
4. Press **ALARM** one last time to confirm and activate the alarm. An alarm icon will appear on the display.
5. To deactivate the alarm, press the **ALARM** button until the alarm icon disappears.

3. Snooze Function

When the alarm sounds, press the large **SNOOZE** button on the top of the clock to temporarily silence the alarm for 5 minutes. The alarm will sound again after 5 minutes.

To stop the alarm completely, press any other button on the top of the clock (e.g., **SET**, **ALARM**, **UP**, or **DOWN**).



Image: A hand interacting with the large 'Snooze' button on the clock's top, illustrating the snooze function.

4. 12/24 Hour Mode Selection

While in normal time display mode, press the **UP** button to switch between 12-hour and 24-hour time formats.

5. Temperature Unit Selection (Celsius/Fahrenheit)

While in normal time display mode, press the **DOWN** button to switch between Celsius (°C) and Fahrenheit (°F) temperature units.

6. Day of the Week Language

The day of the week display supports 7 languages: English, Danish, Spanish, Dutch, French, Italian, and German. To change the language:

1. Enter time setting mode by pressing the **SET** button repeatedly until the day of the week starts flashing.
2. Use the **UP** or **DOWN** buttons to cycle through the available languages.
3. Press **SET** to confirm your selection and exit setting mode.




Image: A visual guide to the clock's multifunctional display, showing how time, temperature, humidity, date, and the day of the week (in multiple languages) are presented.

MAINTENANCE

- Cleaning:** Wipe the clock surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Battery Replacement:** Replace all 3 AAA batteries when the display dims or functions become erratic. Always replace with new batteries of the same type.
- Storage:** If storing the clock for an extended period, remove the batteries to prevent leakage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank or dim.	Batteries are low or incorrectly installed.	Replace with new AAA batteries, ensuring correct polarity.

Problem	Possible Cause	Solution
Time/Date is incorrect.	Not set correctly after battery installation or power interruption.	Follow the "Setting Time and Date" instructions to reset.
Alarm does not sound.	Alarm is not activated or set incorrectly.	Ensure the alarm icon is visible on the display and the alarm time is set correctly.
Temperature/Humidity readings seem inaccurate.	Environmental factors or sensor obstruction.	Ensure the clock is placed in a stable environment, away from direct heat sources or extreme drafts. Allow time for readings to stabilize.

SPECIFICATIONS

- Brand:** Lafocuse
- Model:** ZH0152B
- Display Type:** Digital LCD
- Dimensions:** 20.8 x 3.81 x 14 cm (approximately 8.2 x 1.5 x 5.5 inches)
- Weight:** 320 g (approximately 0.7 lbs)
- Material:** Plastic
- Power Source:** 3 x AAA Batteries (not included)
- Special Features:** Multifunctional display (Time, Date, Day, Temperature, Humidity), Large LCD, Wall and Table mountable, Alarm with Snooze, 7-language day display.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the retailer where the product was purchased or visit the official Lafocuse website. Keep your purchase receipt as proof of purchase.

Related Documents - ZH0152B

	<p>Comprehensive Product Catalog - Electronics, Home Goods, and Accessories</p> <p>A detailed catalog listing various products including electronics, home appliances, automotive accessories, personal care items, and more, with quantities, unit costs, total costs, and ASINs.</p>
---	--

