



**Manuals.plus /**

› **Joaxswe /**

› Joaxswe 18" Farmhouse Night Stands with Charging Station Instruction Manual

**Joaxswe B0DS2MSHXG**

# Joaxswe 18" Farmhouse Night Stands with Charging Station Instruction Manual

Model: B0DS2MSHXG

## INTRODUCTION

---

Thank you for purchasing the Joaxswe 18" Farmhouse Night Stands. This set of two nightstands features a rustic farmhouse design, ample storage with drawers and an open shelf, and a convenient built-in charging station. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and proper use of your new furniture.



Image: The Joaxswe 18" Farmhouse Night Stands, showcasing their design and placement versatility.

## IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or product damage. Keep this manual for future reference.

- **Assembly:** Ensure all parts are present and undamaged before beginning assembly. Do not use power tools for assembly unless specifically instructed, as overtightening screws can damage the wood.
- **Stability:** Always place the nightstand on a flat, level surface. Do not allow children to climb on the furniture. Consider using anti-tip hardware (not included) for added stability, especially if placing heavy items on top or in drawers.
- **Charging Station:**
  - Only connect the charging station to a grounded electrical outlet.
  - Do not overload the electrical outlets.

- Keep liquids away from the charging station to prevent electrical shock.
- If the power cord is damaged, do not use the charging station. Contact customer support for assistance.
- **Weight Capacity:** Do not exceed the maximum weight recommendation for the top surface or drawers. The unit has a maximum weight recommendation of 41.44 pounds.
- **Children:** Keep small parts and packaging materials away from children during assembly.

## SETUP AND ASSEMBLY

---

Assembly is required for this product. Please follow the steps below carefully. A screwdriver is recommended for assembly.

### Package Contents:

Verify that all parts and hardware listed in the included instruction manual are present before starting. Each nightstand comes with its own set of parts.

### Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches. Identify each part using the provided labels.
2. **Assemble Frame:** Attach the side panels to the top and bottom panels using the designated screws and connectors. Ensure all connections are secure.
3. **Install Back Panel:** Secure the back panel to the assembled frame.
4. **Assemble Drawers:** Construct each drawer by attaching the sides, front, and back panels, then securing the bottom. Install the metal drawer slides onto the drawer boxes and the corresponding tracks within the nightstand frame.
5. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots in the nightstand frame. Ensure they operate smoothly.
6. **Install Handles:** Attach the metal handles to the front of each drawer.
7. **Connect Charging Station (if applicable):** For models with a charging station, ensure the power cord is routed through the designated 2.3-inch round hole at the back for a tidy setup.
8. **Final Check:** Verify that all screws are tightened and the nightstand is stable.

*Note: Detailed diagrams and specific part numbers are typically found in the physical instruction manual included with your product. Refer to that document for precise assembly steps.*

## OPERATING INSTRUCTIONS

---

### Using the Charging Station:

1. **Plug In:** Connect the nightstand's power cord to a standard, grounded 120V AC wall outlet.
2. **Connect Devices:** Use the two standard AC sockets to power lamps or other small appliances. Use the two USB ports to charge compatible electronic devices such as smartphones or tablets.
3. **Cable Management:** Utilize the 2.3-inch round hole at the back of the nightstand to route charging cables, keeping the top surface organized.



Image: The 2-drawer nightstand with its charging station in use, demonstrating convenience.

### Using the Drawers and Open Shelf:

- **Drawers:** The drawers feature smooth metal slides for easy opening and closing. Store personal items, books, or other bedside essentials.
- **Open Shelf:** The open shelf provides convenient access for items like books, remote controls, or decorative pieces.
- **Weight Distribution:** Distribute weight evenly within drawers and on shelves. Avoid placing excessively heavy items in one area.



Image: The 2-drawer nightstand with its open shelf and drawers, illustrating storage capacity.



Image: Detailed view of the drawers, highlighting their storage potential.

## CARE AND MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.

- **Spills:** Clean up spills immediately to prevent staining or water damage.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Heat and Moisture:** Keep the nightstand away from direct heat sources and areas of high humidity. Use coasters under drinks to protect the top surface.
- **Hardware:** Periodically check and tighten all screws and fasteners to ensure the nightstand remains stable.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Nightstand is wobbly.	Loose fasteners; uneven floor.	Check and tighten all screws. Move to a level surface or use furniture pads to stabilize.
Drawers do not slide smoothly.	Drawer slides misaligned; obstruction in track.	Ensure drawer slides are correctly installed and aligned. Check for any debris or objects blocking the tracks.
Charging station not working.	Not plugged in; outlet issue; device not compatible; overloaded.	Ensure the nightstand's power cord is securely plugged into a working wall outlet. Test the outlet with another device. Check if the device requires a specific charging protocol. Do not exceed the charging station's capacity.
Missing parts during assembly.	Packaging oversight.	Contact Joaxswe customer support with your purchase details and the list of missing parts.

## PRODUCT SPECIFICATIONS

- **Brand:** Joaxswe
- **Model:** B0DS2MSHXG (Oak Set 2)
- **Product Dimensions (each unit):** 18"D x 18"W x 24.1"H
- **Frame Material:** Wood
- **Top Material Type:** Wood
- **Handle Material:** Metal
- **Color:** Oak
- **Number of Drawers:** This set includes one 2-drawer unit and one 3-drawer unit.
- **Maximum Weight Recommendation (per unit):** 41.44 Pounds
- **Charging Station:** 2 Standard AC Sockets, 2 USB Ports (on 2-drawer unit)
- **Assembly Required:** Yes
- **Recommended Tools for Assembly:** Screw Driver



Image: Dimensions of the 3-drawer nightstand unit.



Image: Dimensions of the 2-drawer nightstand unit with charging station and open shelf.



**✗ Difficult to clean cloth**    **✓ Exquisite high-end style**    **✓ Smooth metal slide rail**

Image: Illustration of drawer load capacity, demonstrating durability.

## WARRANTY AND CUSTOMER SUPPORT

For warranty information, missing parts, or any questions regarding your Joaxswe nightstands, please contact the manufacturer directly through your retailer's customer service portal or the Joaxswe brand store. Please have your purchase receipt and product model number (B0DS2MSHXG) available when contacting support.

**Joaxswe Brand Store:** Visit Joaxswe Store on Amazon

## PRODUCT VIDEOS

The following videos provide additional visual guidance on the product's features and assembly. Please note that specific creator type information was not available for verification, so these are included based on general relevance.

Your browser does not support the video tag.

Video: A short demonstration of product features or assembly steps (0:34 duration).

Your browser does not support the video tag.

Video: Another brief overview or instructional clip (0:40 duration).