

[Manuals.plus](#) /

› [AECOJOY](#) /

› AECOJOY Outdoor Patio Furniture Set User Manual

AECOJOY Patio Furniture Set

AECOJOY Outdoor Patio Furniture Set User Manual

Model: Patio Furniture Set

Brand: AECOJOY

INTRODUCTION

Thank you for choosing the AECOJOY Outdoor Patio Furniture Set. This 7-piece modern metal patio furniture set is designed to enhance your outdoor living space with comfort and durability. Featuring a heavy-duty iron frame with anti-corrosion coating, waterproof cushions, and an exquisite design, it is perfect for balconies, porches, lawns, and other outdoor areas. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure long-lasting enjoyment of your furniture set.



Image: The complete AECOJOY 7-piece outdoor patio furniture set, featuring a sectional sofa, a coffee table, and three ottomans, all with beige cushions, arranged on an outdoor rug.

Safety Information

Please read and understand all safety instructions before assembling or using this product. Failure to follow these instructions may result in injury or damage.

- Keep all children and pets away from the assembly area. Small parts can be a choking hazard.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten fasteners.
- Do not stand or jump on the furniture.
- Avoid placing hot items directly on the table surface without protection.
- Do not use abrasive cleaners or materials that could scratch the finish.
- In strong winds, secure or store cushions to prevent them from blowing away.
- The furniture is designed for outdoor use. Prolonged exposure to extreme weather conditions may affect its lifespan.

Children Safety



All metal Frame



Really Thick Cushions



Image: Illustration highlighting the "All metal Frame" and "Really Thick Cushions" for children's safety, showing a close-up of the beige cushion fabric.

PACKAGE CONTENTS

Your AECOJOY Patio Furniture Set is shipped in multiple boxes. Please verify all components are present before beginning assembly.

- Sectional Sofa Components (various frames and connectors)
- Coffee Table Components (tabletop and legs)
- Ottoman Components (frames and legs)
- Seat Cushions (beige)
- Back Cushions (beige)
- Assembly Hardware (bolts, washers, Allen wrench)
- Instruction Manual




Image: Detailed dimension diagram of the individual furniture pieces including sofa sections, ottomans, and the table, along with two possible layout configurations.

SETUP AND ASSEMBLY

Assembly typically requires two people and an estimated time of 1-2 hours. An Allen wrench is provided for assembly. Follow the numbered steps in the included instruction manual for detailed guidance.

- 1. Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches. Ensure all pieces and hardware are accounted for.
- 2. Assemble Sofa Sections:** Connect the metal frames of the sofa sections using the provided bolts and Allen wrench. Do not fully tighten bolts until all pieces are loosely connected.
- 3. Assemble Coffee Table:** Attach the legs to the tabletop. Ensure the adjustable mechanism for height is correctly aligned.
- 4. Assemble Ottomans:** Secure the legs to the ottoman frames.
- 5. Final Tightening:** Once all furniture pieces are assembled and in their desired configuration, fully tighten all bolts.
- 6. Place Cushions:** Position the seat and back cushions on the assembled frames. Note that some cushions may feature Velcro straps on the underside to secure them to the frame, preventing them from blowing off in windy conditions.

Tip: Having a second person greatly assists in aligning parts and holding them steady during assembly.

OPERATING INSTRUCTIONS

Your AECOJOY patio furniture set is designed for versatile outdoor use. Here are some key operational features:

- **Adjustable Coffee Table:** The coffee table features an adjustable height mechanism, allowing it to be raised for dining or lowered for casual lounging. Refer to the specific instructions for the table's adjustment mechanism.
- **Modular Design:** The sectional sofa pieces can be rearranged to suit your space and needs, offering flexibility in layout.
- **Cushion Placement:** Ensure cushions are properly seated on the frames. Utilize any integrated fasteners (e.g., Velcro) to secure cushions, especially in areas prone to wind.



DETAIL DESIGN



Anti-slip Seat Cushion



4 inch sponge



Thick & Soft Back Cushion

Image: Detailed view of the cushion features, including anti-slip straps, the thickness of the sponge, and the soft texture of the back cushions.

MAINTENANCE

Proper care will extend the life and appearance of your patio furniture set.

- **Cushion Care:** The cushion covers are removable and machine-washable. Use cold water and a gentle cycle. Air dry or tumble dry on low heat. Do not bleach.
- **Frame Cleaning:** The powder-coated metal frame requires minimal effort to clean. Simply wipe with a damp cloth and mild soap, then rinse thoroughly. Avoid harsh chemicals.
- **Weather Protection:** While the set is designed to be waterproof and rust-resistant, consider using furniture covers during heavy rain, snow, or prolonged periods of non-use to further protect it. Store cushions indoors during off-season or inclement weather.
- **Regular Inspection:** Periodically inspect all bolts and connections to ensure they remain tight. Re-tighten as necessary to maintain stability and safety.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Missing parts or hardware	Packaging error or lost during transit.	Contact AECOJOY customer support for replacement parts. Refer to the "Hassle-free Support" section.
Difficulty with assembly	Incorrect alignment of parts; bolts not fully tightened.	Ensure parts are correctly oriented as per the manual. Loosely assemble all parts before tightening any bolts. A second person can assist.
Cushions blowing off	Not secured to the frame.	Utilize the integrated Velcro straps on the underside of the cushions to secure them to the furniture frame.
Furniture feels wobbly	Loose bolts or uneven surface.	Check and tighten all bolts. Ensure the furniture is placed on a flat, level surface.

SPECIFICATIONS

- Brand:** AECOJOY
- Model:** Patio Furniture Set
- Material:** Metal frame, PU-coated fabric cushions, high-resilience sponge filling
- Color:** Beige cushions (frame is charcoal/dark gray)
- Product Dimensions:** 88.6 x 71.6 x 28 inches (L x W x H)
- Item Weight:** 146 pounds
- Weight Capacity:** Up to 800 lbs (reinforced structure)
- Features:** Windproof, Rust-Resistant, Waterproof PU-coated fabric, Removable/Machine-washable cushion covers, Adjustable height coffee table.

WARRANTY AND SUPPORT

AECOJOY is committed to providing high-quality products and customer satisfaction. Your patio furniture set is made with eco-friendly recyclable materials. For any issues, including damaged parts or inquiries, please contact AECOJOY customer support. We offer dedicated replacement services for damaged parts.

For support, please visit the official AECOJOY store or contact their customer service channels as provided at the point of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question