

[Manuals.plus](#) /

› [BolaButty](#) /

› BolaButty Outdoor Rock Speaker Instruction Manual

BolaButty S311

BolaButty Outdoor Rock Speaker Instruction Manual

Model: S311 | Brand: BolaButty

1. INTRODUCTION

Thank you for choosing the BolaButty Outdoor Rock Speaker. These speakers are designed to provide powerful, immersive audio for your outdoor spaces, blending seamlessly with your garden or patio environment. Featuring 60W deep bass, multi-sync technology for up to 100 speakers, auto-pairing, IPX7 waterproofing, and solar-powered convenience, they are perfect for any outdoor music entertainment.



Figure 1: BolaButty Outdoor Rock Speakers


2. WHAT'S IN THE BOX

Ensure all items are present and in good condition upon unboxing:

- Wireless Rock Speakers (2 units)
- Charging Cords (2 units)
- Quick Start Guide (1 unit)

Garden Rock Bluetooth Speaker

The ingenious design seamlessly blends the beauty of natural stone with integrated speaker technology, transforming your garden into a captivating audio oasis.



Quickly Double Click The Bluetooth  Button When Connecting



Figure 2: Package Contents

3. SETUP

3.1 Initial Charging

Before first use, it is recommended to fully charge your speakers. The speakers feature solar panels for convenient charging under sunlight. For faster charging or during periods of low sunlight, use the included power cords.

Additional Solar Power Rechargeable Panel

Our premium solar panels boast an impressive energy conversion efficiency of up to 35%, surpassing the industry standard by an outstanding 28%.



Figure 3: Solar Charging

Long-time Playing

Indulge in uninterrupted entertainment for up to 15 hours at 50% volume on a single charge, ensuring you can immerse yourself fully in the festivities with your loved ones without any concerns.

15H



Figure 4: Solar Panel Detail

3.2 Placement

Place the rock speakers in your desired outdoor location. Their design allows them to blend naturally into garden beds, patios, or poolside areas. Ensure the solar panel on top is exposed to direct sunlight for optimal charging.

Garden Rock Bluetooth Speaker

The ingenious design seamlessly blends the beauty of natural stone with integrated speaker technology, transforming your garden into a captivating audio oasis.




Figure 5: Optimal Outdoor Placement

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

To power on, press and hold the power button (usually located on the underside or back panel) for 2 seconds until you hear the "Power On" prompt. To power off, press and hold the power button again.

4.2 Bluetooth Pairing & Multi-Sync

The BolaButty Rock Speakers feature easy Bluetooth 5.4 connectivity and multi-sync technology, allowing you to connect up to 100 speakers for a synchronized audio experience.

1. **Primary Speaker Setup:** Power on one speaker. Double-click the Bluetooth button on this speaker. It will enter pairing mode and prompt "Bluetooth Pairing".

2. **Connect to Device:** On your smartphone or tablet, enable Bluetooth and select "Rock Stone" from the device list. After successful pairing, the panel indicator will state solid blue.
3. **Secondary Speakers (Multi-Sync):** Power on additional speakers. They will automatically enter Multi-Sync mode (TWS or Party mode) and sync with the primary speaker within 2-5 seconds, indicated by a "synced" prompt. This enables all speakers to play in sync.



Figure 6: Bluetooth Pairing and Multi-Sync Diagram

Video 1: How to Sync Up BolaButty Bluetooth Speaker model Rock Stone. This video demonstrates the step-by-step process of connecting and syncing your rock speakers.

4.3 Sound Performance

Each speaker delivers 30W of power, combining for a total of 60W with two units in stereo. The speakers are engineered for deep bass and immersive audio, suitable for various outdoor settings.

Bluetooth 5.4

Bluetooth 5.4 technology enables effortless streaming of your favorite party tunes and ensures quick, stable connections with a wide range of Bluetooth-enabled devices.



Figure 7: Powerful Stereo Sound

5. MAINTENANCE

5.1 Cleaning

Wipe the speakers with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish or solar panel.

5.2 Waterproof Features

The speakers are IPX7 waterproof, designed to withstand rain and splashes. A 5mm diameter drainage aperture at the base ensures swift water evacuation within 10-15 minutes post-heavy rainfall, preventing stagnation. Do not submerge the speakers for extended periods.

Powerful Stereo Sound Up to 60W

Link two 30-watt speakers together for an enhanced 60-watt surround sound experience.



Figure 8: IPX7 Waterproofing

5.3 Battery Care

The solar panels provide continuous charging during daylight hours. For prolonged use or during cloudy days, utilize the included charging cords to maintain optimal battery levels. Avoid fully depleting the battery frequently to prolong its lifespan.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker using the power cord or place it in direct sunlight.

Problem	Possible Cause	Solution
Unable to pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from device.	Double-click the Bluetooth button on the primary speaker. Ensure Bluetooth is enabled on your device. Move device closer to the speaker (within 33 feet).
Speakers not syncing (Multi-Sync).	Secondary speakers not powered on or too far from primary.	Ensure all speakers are powered on. Place secondary speakers within range of the primary speaker. Power cycle speakers if needed.
Poor sound quality or no sound.	Low volume; interference; speaker placement.	Increase volume on both speaker and connected device. Move speakers away from other electronic devices. Adjust speaker placement for optimal sound dispersion.

7. SPECIFICATIONS

Feature	Detail
Model Name	Rock Stone (S311)
Speaker Type	Outdoor
Speaker Maximum Output Power	60 Watts (30W per unit)
Wireless Communication Technology	Bluetooth 5.4
Bluetooth Range	33 Feet (10 meters)
Water Resistance Level	IPX7 Waterproof
Power Source	Battery Powered (Solar Rechargeable)
Battery Life (50% volume)	Up to 15 hours
Material	Aluminum, Thermoplastic Polyurethane (TPU), Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions	8.6"D x 9.6"W x 9.6"H
Item Weight	17.61 pounds (for 2 units)
Included Components	Power Cable, Quick Start Guide

8. WARRANTY & SUPPORT

Your BolaButty Outdoor Rock Speakers come with a limited warranty. For detailed warranty information, product support, or to purchase additional accessories, please visit the official BolaButty Store on Amazon or contact our customer service team.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question