



Manuals.plus /

› COLAMY /

› COLAMY Big and Tall Office Chair 500lbs Instruction Manual

## COLAMY 5207

# COLAMY Big and Tall Office Chair 500lbs Instruction Manual

Model: 5207 | Brand: COLAMY

## INTRODUCTION

---

Thank you for choosing the COLAMY Big and Tall Office Chair. This chair is designed for individuals requiring extra support and comfort, with a robust construction capable of supporting up to 500 pounds. It features premium bonded leather upholstery, a thick seat cushion, adjustable lumbar support, and a height-adjustable headrest to ensure a comfortable and ergonomic seating experience for long hours.

This manual provides essential information for the safe assembly, operation, and maintenance of your new office chair. Please read it thoroughly before use and retain it for future reference.

## IMPORTANT SAFETY INFORMATION

---

- **Weight Limit:** Do not exceed the maximum weight limit of 500 pounds to ensure the stability and safety of the chair.
- **Assembly:** Ensure all parts are correctly assembled and tightened before use. Regularly check all bolts and screws to ensure they remain secure.
- **Usage:** Use the chair on a level surface. Avoid standing on the chair or using it as a step stool.
- **Children:** Keep children away from the chair during assembly. Do not allow children to play with the chair.
- **Maintenance:** Follow the cleaning and maintenance instructions to prevent damage and ensure longevity.

## PARTS LIST

---

Please refer to the separate assembly guide included in your product packaging for a complete and detailed list of all components and hardware. Ensure all parts are present before beginning assembly.

**Included Components:** Caster wheels.

## SETUP AND ASSEMBLY

---

Detailed step-by-step assembly instructions are provided in the dedicated assembly manual included with your COLAMY office chair. Please follow those instructions carefully to ensure proper and safe setup.

### General Assembly Overview:

1. Unpack all components and verify against the parts list in your assembly manual.
2. Attach the caster wheels to the chair base.
3. Insert the gas lift cylinder into the center of the chair base.
4. Attach the seat mechanism to the bottom of the seat cushion.
5. Connect the backrest to the seat cushion.
6. Place the assembled seat and backrest onto the gas lift cylinder.

Ensure all connections are secure and stable before using the chair.

## OPERATING INSTRUCTIONS

---

Your COLAMY office chair offers several adjustable features to customize your seating experience for optimal comfort and support.

### 1. Seat Height Adjustment

To adjust the seat height, locate the lever on the right side, beneath the seat. While seated, pull the lever upwards to raise the seat. To lower the seat, pull the lever upwards while applying weight to the seat. Release the lever at the desired height.

Your browser does not support the video tag.

**Video:** Demonstrates seat height adjustment, along with other chair features. A person adjusts the chair's height using the lever under the seat.

### 2. Adjustable Lumbar Support

The chair features an inflatable lumbar airbag for customized lower back support. Locate the small pump on the side of the chair. Squeeze the pump repeatedly to inflate the lumbar area to your preferred firmness. To deflate, press the button on the pump to release air.

**Image:** Close-up view of the inflatable lumbar support system, showing the pump and the lumbar area of the chair.

### 3. Height Adjustable Headrest

The integrated padded headrest can be adjusted vertically to provide optimal neck and head support. Gently pull or push the headrest to move it to your desired height.




**Image:** Detail of the height-adjustable headrest, illustrating its vertical movement capability.

### 4. Rocking Function and Tilt Tension

The chair features a rocking function, allowing the backrest and seat to tilt together between 90 and 120 degrees. To activate the rocking function, pull the lever on the left side, beneath the seat, outwards. To lock the chair in an upright position, push the lever inwards.

The tilt tension can be adjusted using the round knob located under the front of the seat. Turn the knob clockwise to increase tension (making it harder to rock) or counter-clockwise to decrease tension (making it easier to rock).



**Image:** The office chair reclined, illustrating the rocking motion and the range of tilt.

### 5. Armrests

The chair is equipped with aesthetically pleasing and wide padded armrests for enhanced comfort and support.



Image: Detailed view of the chair's padded armrest, emphasizing its width and comfort.

## MAINTENANCE

---

To ensure the longevity and appearance of your COLAMY office chair, follow these simple maintenance guidelines:

- **Cleaning:** Wipe clean with a damp cloth. For bonded leather, use a mild soap solution if necessary, and then wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws, bolts, and connections to ensure they are tight. Re-tighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the bonded leather to fade or crack.
- **Weight Distribution:** Distribute your weight evenly on the chair to prevent undue stress on any single component.

## TROUBLESHOOTING

---

If you encounter any issues with your COLAMY office chair, please refer to the following common solutions:

- **Chair Squeaks:** Check and tighten all screws and bolts. A small amount of silicone lubricant can be applied to moving parts if the squeaking persists.
- **Chair Not Adjusting Height:** Ensure the gas lift lever is fully engaged. If the issue persists, the gas lift cylinder may need replacement.
- **Chair Wobbles:** Verify that the base and all connections are securely tightened and that the chair is on a level surface.

For problems not listed here or if solutions do not resolve the issue, please contact customer support.

## SPECIFICATIONS

# Product Dimension

WEIGHT CAPACITY  
**500LBS**



Image: Detailed product dimensions and weight capacity of the office chair.

Feature	Detail
Brand	COLAMY
Model Name	5207 Home Office Desk Chairs
Color	Black
Material	Leather, Foam
Product Dimensions (D x W x H)	33.07"D x 33.46"W x 45.87"H
Item Weight	68 Pounds
Maximum Weight Recommendation	500 Pounds
Seat Depth	20.5 inches
Chair Backrest Width	24.8 Inches
Additional Features	Adjustable Height, Arm Rest, Back Support, Ergonomic
Reclining Position Count	2 (90-120 degrees rocking)
Required Assembly	Yes

## WARRANTY AND SUPPORT

---

COLAMY is committed to customer satisfaction. While specific warranty details are typically provided with your purchase documentation, we strive to ensure the quality and durability of our products.

If you have any questions, concerns, or require assistance with your COLAMY Big and Tall Office Chair, please do not hesitate to contact our customer support team. Contact information is usually included in the product packaging or on our official website.

### Customer Support:

- **Email:** [Refer to product packaging for email address]
- **Website:** COLAMY Official Store on Amazon