

O32O

Generic Double Plastic Egg Drawer for Refrigerator - 32 Egg Capacity (Model O32O)

[User Manual](#)

1. PRODUCT OVERVIEW

The Generic Double Plastic Egg Drawer (Model O32O) is designed to efficiently organize and store up to 32 eggs within your refrigerator or kitchen space. Its compact, double-layer design helps optimize storage, keeping eggs secure and easily accessible. Constructed from durable plastic, this organizer is built for longevity and ease of cleaning.



Image 1.1: The Double Plastic Egg Drawer, Model O32O, shown with eggs stored inside.

2. SETUP

Follow these steps to set up your egg drawer:

1. **Unpack:** Carefully remove the egg drawer from its packaging. Inspect for any damage during transit.

2. **Clean:** Before first use, wash the egg drawer with mild soap and water. Rinse thoroughly and dry completely.
3. **Placement:** Place the egg drawer on a flat, stable surface inside your refrigerator or on a kitchen shelf. Ensure there is enough clearance above the unit for the top drawer to slide out smoothly.



Image 2.1: Two egg drawers, one demonstrating the drawer mechanism.

3. OPERATING INSTRUCTIONS

The egg drawer features a convenient pull-out design for easy access to your eggs.

1. **Loading Eggs:** Gently pull out either the top or bottom drawer. Place eggs individually into the designated slots. Each drawer holds up to 16 eggs, for a total capacity of 32 eggs.
2. **Closing Drawers:** Push the drawer back into the main unit until it is fully closed. Ensure it slides smoothly without obstruction.
3. **Accessing Eggs:** To retrieve an egg, simply pull out the corresponding drawer, select an egg, and push the drawer back in.



Image 3.1: Top-down view showing a drawer pulled out for loading or retrieving eggs.



Image 3.2: Both drawers extended, demonstrating full access to all 32 egg slots.

4. MAINTENANCE

Regular cleaning will ensure the longevity and hygiene of your egg drawer.

- **Cleaning:** The egg drawer is easy to clean. Remove all eggs. Wash the unit and its drawers with warm water and a mild dish soap. Avoid abrasive cleaners or scrubbers that could scratch the plastic.
- **Drying:** Ensure all parts are thoroughly dry before reassembling and placing eggs back into the unit. Air drying or wiping with a soft cloth is recommended.
- **Storage:** When not in use, store the egg drawer in a clean, dry place.

5. TROUBLESHOOTING

If you encounter any issues with your egg drawer, consider the following:

- **Drawer Sticking:** Ensure the drawer tracks are clean and free of debris. If the drawer is overloaded, remove some eggs to reduce weight.
- **Eggs Not Fitting:** The slots are designed for standard-sized chicken eggs. Larger eggs may not fit properly. Do not force eggs into slots.

- **Unit Instability:** Ensure the egg drawer is placed on a completely flat and level surface to prevent wobbling.

6. SPECIFICATIONS

Feature	Detail
Model Number	O32O
Brand	Generic
Capacity	32 Eggs (16 per drawer)
Material	High-Quality Plastic
Dimensions (L x W x H)	22.5 cm x 14 cm x 21.5 cm (8.86 in x 5.5 in x 8.46 in)
Color	Various (Clear with White Drawers)
Manufacturer	MHR




Image 6.1: Product dimensions for the egg drawer.

7. WARRANTY AND SUPPORT

This product is manufactured by MHR under the Generic brand. For any questions, concerns, or support needs regarding your Double Plastic Egg Drawer, please refer to the retailer's return policy or contact the seller directly through your purchase platform. Specific warranty details may vary by region and retailer.

