Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TESSAN TS-WRC01-US

TESSAN Wireless Remote Control Outlet Plug (TS-WRC01-US) Instruction Manual

Model: TS-WRC01-US

1. Introduction

Thank you for choosing the TESSAN Wireless Remote Control Outlet Plug. This device provides a convenient way to control your indoor appliances remotely, enhancing comfort and energy efficiency in your home. Please read this manual carefully before use to ensure proper operation and to maximize the product's lifespan.

2. Safety Information

- For indoor use only. Do not expose to rain or moisture.
- Do not exceed the maximum load rating of 15A/1875W. Overloading may cause damage to the unit and create a fire hazard.
- Ensure the device is fully inserted into the wall outlet.
- Do not disassemble or modify the product.
- Keep out of reach of children.
- If the product appears damaged, discontinue use immediately.

3. Package Contents

- 3 x TESSAN Wireless Remote Control Outlets
- 1 x TESSAN Remote Control
- 1 x 12V Battery (pre-installed in remote)
- 1 x Sticky Iron Piece (for remote mounting)
- 1 x User Manual



This image displays the complete TESSAN Wireless Remote Control Outlet Kit, featuring three compact white outlets and a matching white remote control. Each outlet is numbered 1, 2, or 3, corresponding to buttons on the remote.

4. Product Overview

The TESSAN Wireless Remote Control Outlet system allows you to control up to three individual electrical outlets with a single remote. Its compact design ensures that adjacent outlets remain accessible.

Key Features:

- **100ft RF Range:** Control devices from a significant distance, even through walls and doors.
- **High Power Rating:** Supports up to 15A/1875W, suitable for various household appliances.
- **Magnetic Remote:** The remote control features a magnetic back for convenient storage on metal surfaces. A sticky iron piece is included for non-metal surfaces.
- **Compact Size:** Designed to occupy only one wall socket without blocking others.
- **Plug and Play:** No complex setup or pairing required for initial use.



This graphic outlines the key features of the TESSAN 3-Pack Remote Control Outlet, including energy saving, remote control functionality, 100ft range, integrated switch, indoor use suitability, and a maximum power rating of 1875W.



An image highlighting the compact size of the TESSAN remote control outlets, showing their dimensions (1.18 inches depth, 2.17 inches width, 2.36 inches height) and how they fit without blocking adjacent outlets.




This image demonstrates the magnetic design of the TESSAN remote control, showing it conveniently attached to various surfaces like a refrigerator, a wall switch plate, and a wooden cabinet, ensuring easy storage and accessibility.

5. Setup Instructions

The TESSAN Wireless Remote Control Outlet system is designed for simple 'Plug and Play' operation.

1. **Plug into the socket:** Insert the TESSAN remote control outlet into any standard 120V AC wall socket.
2. **Press the switch:** The outlet has a manual ON/OFF button. Press it to ensure the outlet is functioning.
3. **Use the remote control:** The remote control is pre-paired with the outlets. Simply press the corresponding 'ON' or 'OFF' button for the desired outlet (1, 2, or 3) to control your connected appliance.



A visual guide demonstrating the 'Plug and Play' setup for the TESSAN remote control outlets. It shows plugging the outlet into a wall socket, pressing the manual switch, and then using the remote control.

6. Operating Instructions

Once set up, operating your TESSAN Wireless Remote Control Outlets is straightforward:

- Connect your appliance (e.g., lamp, fan, string lights) to one of the TESSAN remote control outlets.
- Ensure the appliance's own power switch is in the 'ON' position.
- Use the remote control to turn the connected appliance ON or OFF. Each button (1, 2, 3) on the remote corresponds to the numbered outlet.
- The 'ON' button will activate the corresponding outlet, and the 'OFF' button will deactivate it.



An illustration of the TESSAN remote control being used in a living room, highlighting its 100-foot operational range. The remote allows users to switch devices on and off from a distance, even through walls and doors.

7. Maintenance

- **Cleaning:** Wipe the outlets and remote with a dry, soft cloth. Do not use liquid cleaners or solvents.
- **Battery Replacement:** The remote control uses one 12V battery. If the remote's range decreases or it stops responding, replace the battery. To replace, open the battery compartment on the back of the remote, remove the old battery, and insert a new 12V battery, ensuring correct polarity.
- **Storage:** When not in use for extended periods, store the product in a cool, dry place away from direct sunlight.

8. Troubleshooting

- **Outlet not responding to remote:**
  - Check if the remote control battery needs replacement.

- Ensure the remote is within the 100ft operating range.
- Verify the outlet is securely plugged into the wall socket.
- Confirm the appliance connected to the outlet is powered on and functioning correctly when directly plugged into a standard outlet.

- **Appliance not turning on/off:**
  - Ensure the appliance's own power switch is in the 'ON' position.
  - Check if the outlet's manual ON/OFF button is working.
- **Reduced remote range:**
  - Replace the remote control battery.
  - Minimize obstructions between the remote and the outlet.

9. Specifications

Feature	Specification
Model Number	TS-WRC01-US
Product Dimensions	2.36 x 2.17 x 1.18 inches
Weight	10.86 ounces (total kit)
Voltage	120 Volts (AC)
Max Power Rating	15A / 1875W
RF Range	Up to 100 feet (line of sight)
Remote Battery	1 x 12V (included)
Material	Plastic
Connector Type	Plug In



An image illustrating the 1875W rated power of the TESSAN remote control outlets and examples of compatible household devices such as decorative lights, fans, desk lamps, humidifiers, routers, and fish tanks.

10. Warranty and Support

TESSAN products are designed for reliability and performance. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official TESSAN website. Please retain your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DS72F7YB

More documents and user manuals: **https://manuals.plus/**