

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOKSOM](#) /

› [TOKSOM 71-inch Kitchen Pantry Storage Cabinet User Manual](#)

## TOKSOM 6687

# TOKSOM 71-inch Kitchen Pantry Storage Cabinet User Manual

Brand: TOKSOM | Model: 6687

## 1. IMPORTANT SAFETY INFORMATION

---

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Always secure the cabinet to the wall using the provided anti-tipping devices to prevent tipping. This is crucial for safety, especially in households with children or pets.
- Be cautious of pinch points during assembly, particularly when handling doors and drawers.
- Ensure all screws and fasteners are tightened securely before using the cabinet. Periodically check and re-tighten as needed.
- Do not overload shelves or drawers. Distribute weight evenly to maintain stability.
- Keep small parts and packaging materials away from children during assembly.

# Anti-Tipping Design For Safe Use





Image: Anti-Tipping Design for Safe Use. This diagram illustrates the importance of securing the cabinet to the wall to prevent accidental tipping, especially with children present.

## 2. PRODUCT OVERVIEW

The TOKSOM 71-inch Kitchen Pantry Storage Cabinet is a freestanding unit designed to enhance kitchen organization with a blend of modern farmhouse aesthetics and practical functionality. It features a black finish, clean lines, and gold metal handles, offering versatile storage solutions for various household items.



Image: Front view of the TOKSOM 71-inch Kitchen Pantry Storage Cabinet, demonstrating its capacity and design in a kitchen setting.

## Key Features:

- **Modern Farmhouse Design:** Simple black finish with clean lines and stylish gold metal handles.
- **Large Storage Capacity:** Includes a deep, easy-glide drawer, multiple open compartments, a dedicated microwave shelf, four large cabinets, and spacious countertops.
- **Adjustable Shelves:** Offers flexible storage solutions for various item sizes.
- **Multi-purpose Functionality:** Suitable for use as a kitchen hutch, buffet sideboard, coffee bar, wine rack, or general storage/display cabinet in dining rooms, living rooms, or condos.
- **Durable Construction:** Made from CARB P2-compliant MDF with a reinforced and heightened base for moisture prevention and enhanced stability.
- **Waterproof Surface:** Easy to clean and maintain.



**Durable Wooden Countertop**



**Exquisite Golden Handles**



**Fluted Panel Design**



**Sturdy Metal Hinges**

Image: Detailed views highlighting the quality components of the cabinet, including the golden handles, fluted panel texture, and metal hinges.

### 3. SPECIFICATIONS

---

Detailed dimensions and material specifications for the TOKSOM Kitchen Pantry Storage Cabinet.



Image: Dimensional diagram of the cabinet, providing precise measurements for planning placement.

Attribute	Value
Brand	TOKSOM
Color	Black B
Product Dimensions	15.15"D x 41.33"W x 70.86"H
Special Feature	Heavy Duty
Mounting Type	Floor Mount
Room Type	Dining Room, Living Room
Door Style	Slab
Included Components	Kitchen Pantry Storage Cabinet
Finish Type	High Gloss
Size	71" H

Number of Shelves	3
Item Weight	110 Pounds
Base Type	Straight base
Installation Type	Freestanding
Top Material Type	Engineered Wood
Assembly Required	Yes
Frame Material	Engineered Wood
Is Customizable	No
Number of Levels	5
Model Name	Kitchen Pantry Storage Cabinet
Manufacturer	TOKSOM
Item model number	6687
Date First Available	January 4, 2025

## 4. SETUP AND ASSEMBLY INSTRUCTIONS

---

This cabinet requires assembly. It is recommended that two people assemble the unit to ensure ease and safety. All necessary hardware and detailed instructions are included in the packaging.

### Before You Begin:

- Unpack all components and verify against the parts list provided in your package. Each accessory is thoughtfully labeled.
- Clear a spacious, clean, and level area for assembly.
- Gather necessary tools (e.g., screwdriver, hammer if required).
- Review the step-by-step assembly instructions and numbered accessories provided in your package.

### Assembly Steps (General Guidance):

1. Assemble the main frame of the cabinet according to the numbered diagrams.
2. Attach the back panels, ensuring they are properly aligned and secured.
3. Install the drawer slides and assemble the drawer unit.
4. Mount the doors using the provided hinges, ensuring they open and close smoothly. Adjust hinges if necessary for proper alignment.
5. Insert the adjustable shelves into the desired positions. The shelves can be moved to accommodate items of varying heights.
6. Attach the golden metal handles to the doors and drawer.
7. **Crucial Step:** Install the anti-tipping devices to secure the cabinet to a wall. This prevents accidental tipping and ensures stability.



Image: Adjustable shelves feature, allowing customization of storage space during assembly and use.

## 5. OPERATING INSTRUCTIONS

---

The TOKSOM Kitchen Pantry Storage Cabinet is designed for versatile use in various rooms. Here's how to maximize its functionality:

### Storage Utilization:

- **Microwave Shelf:** The central open compartment is specifically designed to accommodate a microwave or other small kitchen appliances. Ensure adequate ventilation around appliances.
- **Adjustable Shelves:** Utilize the adjustable shelves within the cabinets to store items of different heights, such as tall bottles, cereal boxes, or stacks of plates. Simply remove and re-insert the shelf pins to change shelf height.
- **Deep Drawer:** The easy-glide drawer is ideal for organizing smaller kitchen essentials like utensils, wraps, or pantry staples.
- **Lower Cabinets:** Use the spacious lower cabinets for larger items, cookware, or bulkier pantry supplies.
- **Open Compartments:** The smaller open sections can be used for decorative items, frequently accessed spices, or coffee mugs.



Image: The deep drawer in use, demonstrating its capacity for organizing kitchen items.

## Multi-purpose Use:

Beyond the kitchen, this cabinet can serve various roles:

- **Dining Room:** Function as a buffet sideboard for serving dishes, storing tableware, or as a coffee bar.
- **Living Room:** Use as a display cabinet for books, decorative items, or media storage.
- **Bathroom:** Can be adapted for linen storage or organizing toiletries.



Image: Visual representation of the cabinet's multifunctional and ample storage space for various items.

## 6. MAINTENANCE AND CARE

---

Proper care will ensure the longevity and appearance of your TOKSOM Kitchen Pantry Storage Cabinet.

- **Cleaning:** The black wood-look surface is waterproof and easy to wipe clean. Use a soft, damp cloth with mild soap if necessary. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Spills:** Wipe up spills immediately to prevent moisture damage, especially on the countertop and interior surfaces.
- **Dusting:** Regularly dust the cabinet with a soft, dry cloth to prevent buildup.
- **Hardware:** Periodically check all screws, hinges, and drawer slides to ensure they are tight and functioning correctly. Re-tighten as needed.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.



Image: Detail of the cabinet's countertop, emphasizing its durable and easy-to-clean surface.

## 7. TROUBLESHOOTING

---

If you encounter any issues during assembly or use, refer to the following common solutions:

### Common Issues and Solutions:

- **Parts Missing or Damaged:** If you find any damaged or missing parts upon unboxing, do not proceed with assembly. Contact TOKSOM customer service immediately for replacement parts.
- **Difficulty with Assembly:** Ensure you are following the step-by-step instructions precisely. Verify that all parts are oriented correctly. Sometimes, a board might be installed backward, requiring re-assembly of that section.
- **Doors Not Aligning Properly:** Check that the hinges are installed correctly and tightened. Most hinges allow for minor adjustments (up/down, left/right, in/out) using a screwdriver to achieve perfect alignment.
- **Drawer Not Sliding Smoothly:** Ensure the drawer slides are installed correctly and are free of obstructions. Apply a small amount of silicone lubricant if needed.
- **Stripped Screws/Handles:** If a screw hole becomes stripped, try using a slightly larger screw or wood glue with a toothpick to fill the hole before re-inserting the original screw. For stripped handles, contact customer service for replacements.
- **Cabinet Wobbles:** Ensure the cabinet is on a level surface. Adjust any leveling feet if present. Re-check all fasteners for tightness. Confirm the anti-tipping device is securely installed to the wall.

## 8. WARRANTY AND SUPPORT

---

For any questions, concerns, or assistance with your TOKSOM Kitchen Pantry Storage Cabinet, please contact TOKSOM

customer service. Refer to your purchase documentation for specific warranty details and contact information. We are committed to providing support for our products.

Please have your model number (6687) and purchase date available when contacting support to expedite assistance.