

Gvirtue P3700

Gvirtue P3700 Universal Remote Control for NVIDIA Shield TV

Instruction Manual

1. PRODUCT OVERVIEW

The Gvirtue P3700 Universal Remote Control is designed as a replacement for NVIDIA Shield TV remotes, offering enhanced features and broad compatibility. This remote is compatible with NVIDIA SHIELD TV models from 2015, 2017, and 2019, including the SHIELD TV Cube and SHIELD TV Pro. For 2015 and 2017 models, an upgrade to the latest SHIELD experience is required for full functionality.

Key features include a backlit function for visibility in low-light conditions and integrated voice search capabilities.



Image: The Gvirtue P3700 remote shown alongside various NVIDIA Shield TV models (2015, 2017, 2019 Cube, 2019 Pro), illustrating its broad compatibility.



Image: The remote displaying its backlit buttons, providing comfortable lighting for use day and night.

2. SETUP INSTRUCTIONS

2.1. Battery Installation

The remote requires two AAA batteries (not included). To install:

1. Remove the battery cover from the back of the remote.
2. Insert two AAA batteries, ensuring correct polarity (+/-).
3. Replace the battery cover.



Image: A hand inserting two AAA batteries into the remote control's battery compartment.

2.2. Pairing with NVIDIA Shield TV

Follow these steps to pair your new Gvirtue P3700 remote with your NVIDIA Shield TV:

1. Ensure your NVIDIA Shield TV is powered on and within 2 feet of the new remote.
2. Press and hold the "Select" button on the remote until the remote's light flashes.
3. If your remote was previously paired with another Shield device, press and hold the "Home" and "Back" buttons simultaneously until the light flashes.
4. The remote should connect automatically after a few moments. A confirmation message may appear on your TV screen.

HOW TO PAIR THE NEW REMOTE WITH YOUR SHIELD TV ?



1 / Insert 2 PCS AAA batteries (batteries not included) **2** / Hold the new remote within 1 foot of your SHIELD TV.





3 / Press and hold the  +  (Or Select button) on your remote, until the remote light flashes. **4** / The remote should connect after a few moments.

Image: Visual instructions demonstrating the pairing process, including battery insertion and button presses.

2.3. USB Dongle Connection (if applicable)

The remote operates via a USB dongle. Insert the provided USB dongle into an available USB port on your NVIDIA Shield TV. The remote will communicate wirelessly with the dongle.

Your browser does not support the video tag.

Video: An unboxing and setup demonstration of the remote control, including battery installation and USB dongle connection to an NVIDIA Shield TV.

3. OPERATING INSTRUCTIONS

3.1. Button Functions



Image: A detailed diagram labeling each button on the Gvirtue P3700 remote control and its corresponding function.

- **Power Button:** Puts your NVIDIA Shield TV into standby mode.
- **Navigation Ring (Up, Down, Right, Left) & OK Button:** Used for menu navigation and selection.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Returns to the main home screen of your NVIDIA Shield TV.
- **Volume Up/Down:** Adjusts the audio volume.

- **Mute Button:** Mutes or unmutes the audio.
- **Play/Pause, Fast-Forward, Rewind:** Media playback controls.
- **Netflix Button:** Direct access to the Netflix application.
- **Backspace Button:** Deletes characters during text input.
- **Mouse Toggle:** Activates/deactivates the air mouse function.
- **Menu Button:** Accesses additional menu options.

3.2. Voice Search Function

The remote features a dedicated microphone button for voice commands:

1. Long press the microphone button on the remote.
2. Speak your command clearly into the remote to access Google Assistant on Android TV.
3. You can search for TV shows, movies, weather conditions, and more.

Get to know your VIZIO Voice Remote.



Push-to-talk voice button.

Quickly search for content in SmartCast, launch apps, and more



Luminous function

The remote control is as accessible at night as it is during the day



Fewer buttons, more control.

Enjoy a simplified design enabling quicker access to TV controls.



Image: A user demonstrating the voice search feature by speaking into the remote control.

4. TROUBLESHOOTING

If you encounter issues with your Gvirtue P3700 remote, consider the following troubleshooting steps:

- **Remote Not Responding:**
 - Check if the batteries are correctly installed and have sufficient charge. Replace them if necessary.
 - Ensure the USB dongle is securely plugged into your NVIDIA Shield TV.
 - Attempt to re-pair the remote by following the pairing instructions in Section 2.2.
- **Intermittent Connectivity:**
 - Ensure there are no obstructions between the remote and the NVIDIA Shield TV.
 - Minimize interference from other wireless devices.
 - If issues persist, try plugging the USB dongle into a different USB port on your NVIDIA Shield

TV.

- **Voice Search Not Working:**

- Ensure the remote is properly paired.
- Speak clearly and directly into the microphone.
- Verify that Google Assistant is enabled and configured correctly on your NVIDIA Shield TV.

5. SPECIFICATIONS

Brand	Gvirtue
Model Name	P3700
Item Model Number	NVIDIA Remote
Compatible Devices	NVIDIA SHIELD TV (2015/2017/2019 models)
Connectivity Technology	Infrared
Special Feature	Voice Search, Backlit
Colour	Black
Battery Type	AAA (2 required)
Button Quantity	25
Parcel Dimensions	14.5 x 4.2 x 2.2 cm; 50 g
Country of Origin	China

6. WARRANTY AND SUPPORT

Gvirtue provides a 90-day warranty return service for this replacement remote control. If you have any questions or concerns regarding your order or the product, please contact Gvirtue directly. Customer support aims to respond within 24 hours during working days.

For further assistance, refer to the contact information provided with your purchase or visit the Gvirtue store on Amazon.