ACCOHOHO LM080

ACCOHOHO Farmhouse Fireplace TV Stand with Electric Fireplace

Model: **LM080** | Brand: **ACCOHOHO**

1. Introduction

Thank you for choosing the ACCOHOHO Farmhouse Fireplace TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before beginning assembly or use.

Important Safety Information

- Always follow assembly instructions precisely to ensure structural integrity.
- Do not overload the TV stand or shelves. The tabletop supports up to 150 lbs.
- Ensure the electric fireplace is connected to a grounded outlet.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the fireplace.
- Do not block the air vents of the electric fireplace.
- Unplug the fireplace before cleaning or maintenance.
- This product ships in two separate packages. These packages may arrive on different days. Please ensure you have received all packages before starting assembly.

2. Product Overview

The ACCOHOHO Farmhouse Fireplace TV Stand is designed to accommodate TVs up to 80 inches, offering both aesthetic appeal and practical storage solutions. It features a 36-inch electric fireplace with adjustable heat and flame settings.

Key Features:

- **Dimensions:** 68.5"W x 15.5"D x 35.7"H
- **TV Compatibility:** Fits TVs up to 80 inches.

- **Electric Fireplace:** 36-inch unit with 5000 BTUs, heating up to 400 sq. ft.
- **Storage:** Open soundbar shelf, three spacious drawers, and two large adjustable-shelf cabinets.
- **Material:** Constructed from high-quality MDF and reinforced particleboard for durability.
- **Style:** Farmhouse design with an antique white finish.

Product Dimensions and Components



Figure 2.1: Overall product dimensions and individual drawer dimensions. Note that the product is delivered in two packages.



Semi-open Top Shelf

Great space for place your sound bar

Ample Storage Cabinet

Perfect for organizing all your essentials





Adjustable Shelf

Adjustable shelf for flexiable and cunstomizable storage

Figure 2.2: TV size compatibility, showing the stand can accommodate televisions up to 80 inches.

3. Setup & Assembly

Assembly of the ACCOHOHO Farmhouse Fireplace TV Stand requires careful attention to detail. The package includes clear, easy-to-follow instructions and labeled parts for quick identification. It is recommended to have at least two people for assembly.

Before You Begin:

- **Unpack Carefully:** Lay out all parts and hardware on a clean, soft surface to prevent scratches. Verify all components are present against the parts list in your included manual.
- **Tools Required:** A screwdriver (manual or electric drill on low torque setting), and possibly wood glue for added stability (optional, not included).
- **Patience is Key:** Assembly can take several hours. Take your time and follow each step sequentially. Avoid overtightening screws, especially near panel edges, to prevent damage.

Assembly Steps:

1. Begin by assembling the main frame of the TV stand according to the provided diagrams.
2. Attach the side cabinets and central support structures.
3. Install the drawer slides and assemble the three drawers.
4. Carefully place the top panel onto the assembled frame.
5. Insert the electric fireplace unit into its designated opening.
6. Attach the cabinet doors and adjust hinges for proper alignment.
7. Install all handles and knobs.

Storage Features



Figure 3.1: The spacious 70-inch wide tabletop with a weathered texture finish.



Figure 3.2: Three large storage drawers for organizing small items.



Figure 3.3: Details of the semi-open top shelf, ample storage cabinets, and adjustable shelves.

Product Overview Video

Your browser does not support the video tag.

Video 3.1: A detailed overview of the Farmhouse Fireplace TV Stand, showcasing its features, electric heater, remote control, and storage options. This video is provided by a seller.

4. Operating Instructions (Electric Fireplace)

The integrated 36-inch electric fireplace provides warmth and ambiance with easy-to-use controls.

Fireplace Features:

- **Heating Power:** 5000 BTUs, capable of warming up to 400 sq. ft. in approximately 3 seconds.
- **Temperature Control:** Adjustable from 64°F to 82°F.

- **Flame Effect:** Realistic 3D flames with 4 brightness levels, operable with or without heat.
- **Timer:** Programmable timer from 1 to 8 hours.
- **Safety:** Equipped with overheat protection and UL certification.

Controls:

The fireplace can be controlled using either the included remote control or the mechanical button panel located on the unit.



Figure 4.1: Electric fireplace controls and features.



Figure 4.2: Realistic flame visual effect and brightness levels of the electric fireplace.

Using the Remote Control:

- **Power Button:** Turns the fireplace ON/OFF.
- **Heat Button:** Activates or deactivates the heating function.
- **Temperature Up/Down:** Adjusts the desired room temperature.
- **Flame Brightness:** Cycles through 4 levels of flame brightness.
- **Timer Button:** Sets the automatic shut-off timer (1-8 hours).

5. Maintenance

Proper care and maintenance will extend the life and appearance of your ACCOHOHO Fireplace TV Stand.

Cleaning the TV Stand:

- Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as they can damage the finish.
- For stubborn marks, use a mild soap solution and immediately dry with a clean cloth.
- Protect the surface from scratches by using coasters under drinks and felt pads under decorative items.

Electric Fireplace Maintenance:

- Ensure the fireplace is unplugged and cool before cleaning.
- Clean the glass front with a soft, damp cloth. Do not use abrasive cleaners.
- Periodically check the air intake and exhaust vents for dust or obstructions and clean as necessary with a soft brush or vacuum cleaner.
- Replace remote control batteries as needed.

6. Troubleshooting

If you encounter any issues with your ACCOHOHO Fireplace TV Stand, refer to the following common problems and solutions.

Common Issues:

- **Fireplace Not Turning On:**
  - Check if the power cord is securely plugged into a grounded electrical outlet.
  - Ensure the wall switch (if applicable) is ON.
  - Verify the remote control batteries are functional and correctly inserted.
  - Check the circuit breaker for your home.
- **No Heat Output:**
  - Confirm the heat function is activated via the remote or control panel.
  - Ensure the desired temperature setting is higher than the current room temperature.
  - Check for any obstructions in the heater's air vents.
- **Flames Not Visible:**
  - Adjust the flame brightness setting using the remote or control panel.
- **Remote Control Not Working:**
  - Replace the batteries.
  - Ensure there are no obstructions between the remote and the fireplace sensor.
- **Missing or Damaged Parts During Assembly:**
  - Refer to the parts list in your assembly manual.
  - Contact customer support immediately with details of the missing or damaged components.

If these steps do not resolve the issue, please contact ACCOHOHO customer support for further assistance.

7. Specifications

Feature	Specification
Brand	ACCOHOHO
Model Name	Fireplace TV Stand
Model Number	LM080
Material	Engineered Wood
Style	Farmhouse
Color	Antique White
Overall Dimensions (W x D x H)	68.5" x 15.5" x 35.7"
Item Weight	147 pounds
Tabletop Weight Capacity	Up to 150 lbs
TV Size Compatibility	Up to 80 inches
Electric Fireplace Size	36 inches
Heating Power	5000 BTUs
Heating Area	Up to 400 sq. ft.

Temperature Range	64°F to 82°F
Timer Settings	1-8 hours
Safety Features	Overheat Protection, UL Listed
Included Components	Electric Fireplace, TV Stand

8. Warranty Information

ACCOHOHO products are manufactured to high-quality standards. While specific warranty details are not provided in this manual, please retain your proof of purchase. For information regarding warranty coverage and claims, please contact ACCOHOHO customer support directly. Warranty terms typically cover manufacturing defects under normal use.

9. Customer Support

For any questions, assistance with assembly, missing parts, or troubleshooting not covered in this manual, please contact ACCOHOHO customer support. Have your model number (LM080) and purchase information ready when you call or email.

Contact Information: Please refer to the contact details provided with your purchase or visit the official ACCOHOHO website for the most current support information.

© 2026 ACCOHOHO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question