Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Flrrtenv F-ZJSC-VT-CA

Flrrtenv L-Shaped Desk with LED Lights and Power Outlets

Model: F-ZJSC-VT-CA

1. Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Always ensure the desk is properly assembled and anchored to the wall or floor to prevent tipping.
- Do not place heavy objects on the desk that exceed its weight capacity of 26.2 kg (57.67 lbs).
- Exercise caution when using power outlets and USB ports to avoid electrical hazards.
- Keep the desk and its components away from heat sources and liquids.
- Ensure all electrical connections are secure and comply with local electrical codes.

2. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Desktop Panels (L-shaped sections)
- Steel Frame Components
- Monitor Stand Riser
- 4 Fabric Drawers
- Power Outlet Unit (2 AC, 1 USB, 1 Type-C)
- LED Light Strip and Remote Control
- Storage Bag
- Assembly Hardware (screws, bolts, Allen wrench)
- Instruction Manual

3. Assembly Instructions

Assembly typically requires two people. Follow the numbered steps provided in the included assembly guide. Ensure all screws are tightened securely but do not overtighten.

3.1 Desk Configuration

This L-shaped desk is reversible, allowing you to configure the longer section to either the left or right side to suit your space. Plan your desired orientation before starting assembly.




Figure 3.1: Multiple installation modes for the reversible L-shaped desk.

3.2 General Assembly Steps

1. Unpack all components and verify against the package contents list.
2. Assemble the main steel frame sections according to the diagrams.
3. Attach the desktop panels to the assembled frame, ensuring correct orientation for your chosen L-shape.
4. Install the monitor stand riser onto the desktop.
5. Insert the fabric drawers into their designated compartments.
6. Mount the power outlet unit into the pre-drilled slot on the desktop.
7. Attach the LED light strip to the underside of the monitor stand or desktop as desired.
8. Secure the storage bag to the side of the desk frame.
9. Ensure all connections are tight and the desk is stable.

3.3 Product Dimensions



Figure 3.2: Overall product dimensions for planning your space.

4. Operating Instructions

4.1 LED Lighting System

The desk features an integrated LED lighting system with a remote control for customization.




Figure 4.1: LED lighting features and remote control.

- **Power On/Off:** Use the power button on the remote control.
- **Color Selection:** Choose from 30 static colors using the color palette buttons.
- **Dynamic Modes:** Select from 22 dynamic lighting modes (e.g., fade, jump, strobe).
- **Flicker Frequency:** Adjust the speed of dynamic modes with 10 frequency levels.
- **Brightness Adjustment:** Modify the light intensity with 5 brightness levels.

4.2 Integrated Power Outlets

The desk includes a built-in power strip for convenient charging and power access.



Figure 4.2: Integrated power outlets for charging devices.

- **AC Outlets:** Two (2) 230V/13A AC outlets for powering standard electronics.
- **USB-A Port:** One (1) 5V/3A USB-A port for charging compatible devices.
- **Type-C Port:** One (1) 5V/3A Type-C port for charging compatible devices.
- Connect the desk's main power cord to a wall outlet to activate the integrated power unit.

5. Maintenance

Regular maintenance helps prolong the life and appearance of your desk.

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Clean up spills immediately to prevent damage to the desktop surface.
- **Drawers:** The fabric drawers can be removed for cleaning. Spot clean with a mild detergent if necessary.
- **Connections:** Periodically check all screws and bolts to ensure they remain tight.

6. Troubleshooting

If you encounter issues, refer to the following common problems and solutions.

- **Desk is wobbly:**
  a. Ensure all assembly screws are securely tightened.
  b. Check that the desk is on a level surface. Adjust feet if applicable.
- **LED lights not working:**
  a. Check if the LED strip is properly connected to its power source.
  b. Ensure the remote control has working batteries.
  c. Point the remote directly at the LED receiver.
- **Power outlets not functioning:**
  a. Verify that the desk's main power cord is securely plugged into a functional wall outlet.
  b. Check if the wall outlet itself is working (test with another device).
  c. Ensure the power unit is correctly installed in the desktop.
- **Drawers do not slide smoothly:**
  a. Ensure the fabric drawers are correctly inserted and not overloaded.

7. Specifications

Feature	Detail
Brand	Flrrtenv
Model Number	F-ZJSC-VT-CA
Desk Design	L-Shaped Computer Desk (Reversible)
Overall Dimensions (L x W x H)	Approx. 128 cm x 120 cm x 94 cm (50.4 in x 47.2 in x 37 in)
Desktop Material	Scratch-resistant surface (Rustic Brown finish)
Base Material	Alloy Steel
Number of Drawers	4 (Fabric)
Weight Capacity	26.2 kg (57.67 lbs)
LED Lighting	30 Colors, 22 Dynamic Modes, 10 Flicker Frequencies, 5 Brightness Levels (Remote Controlled)
Power Outlets	2 x AC (230V/13A), 1 x USB-A (5V/3A), 1 x Type-C (5V/3A)
Special Features	Integrated Monitor Stand, RGB Lighting, Ample Storage, Power & Charging Ports
Recommended Use	Gaming, Home Office, Workstation

8. Warranty and Support

This product comes with a limited warranty. For specific warranty details, please refer to the warranty card included in your package or contact Flrrtenv customer support.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact our customer support team through the retailer's platform or the contact information provided with your purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSB8BQYL

More documents and user manuals: **https://manuals.plus/**