



Manuals.plus /

› **Chrangmay** /

› Chrangmay 47.24" Modern Vanity Desk with Mirror and Lights, Model 524 - Instruction Manual

## Chrangmay 524

# Chrangmay 47.24" Modern Vanity Desk with Mirror and Lights - Model 524

Instruction Manual

## INTRODUCTION

---

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Chrangmay 47.24" Modern Vanity Desk with Mirror and Lights, Model 524. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.



Image: The Chrangmay 47.24" Modern Vanity Desk, showcasing its illuminated mirror, multiple drawers, and integrated storage shelves.

## PRODUCT SPECIFICATIONS

---



---

The Chrangmay Vanity Desk requires self-assembly. It is recommended to have two people for certain steps to ensure stability and ease of construction. Please ensure all components are present before beginning assembly.

### **Before You Begin:**

- Unpack all components and verify against the parts list provided in your package.
- Clear a spacious area for assembly.
- Gather necessary tools (e.g., screwdriver, hammer - typically included or standard household tools).
- Review the assembly instructions included in your product packaging thoroughly.

### **General Assembly Steps (Refer to your specific manual for detailed diagrams):**

1. Assemble the main desk frame and leg supports.
2. Install the drawer slides and assemble the drawers.
3. Attach the storage cabinet and shelves to the main desk structure.
4. Carefully place the tempered glass tabletop onto the desk.
5. Mount the mirror unit, ensuring all electrical connections for the lights are secure.
6. Connect the power outlet unit and ensure it is properly secured.

**Important Note:** Some users have found it easier to place the glass top before attaching the mirror piece. Always handle the tempered glass with care to prevent damage.




Image: Overhead view of the vanity desk with drawers and storage compartments open, illustrating the ample storage capacity.

## OPERATING INSTRUCTIONS

### LED Mirror Lights:


- **Power On/Off:** Lightly touch the power button icon on the mirror to turn the lights on or off.
- **Change Light Color:** With the lights on, lightly touch the power button again to cycle through the three available light colors: Cool Light, Warm Light, and Warm Yellow Light.
- **Adjust Brightness:** To adjust the brightness, press and hold the power button. The brightness will cycle from 10% to 100%. Release the button when the desired brightness is reached.
- **Turn off Power Indicator Light:** In the off mode, long press the switch button to turn off the power indicator light.

**Warm yellow light** Short press "☺" to adjust the light color




Cool Light Mode

**Warm light** Short press "☺" to adjust the light color



Warm Light Mode

**Cool light** Short press "☺" to adjust the light color



Warm Yellow Light Mode

Images: The vanity mirror displaying its three distinct lighting modes: Cool Light, Warm Light, and Warm Yellow Light.

### **Integrated Charging Station:**

The vanity desk includes a built-in charging station for convenience. This station features:

- 2 Standard AC Outlets (125V/12A)

- 1 USB Port (5V/2A)
- 1 Type-C Port (5V/20W)

Plug the vanity desk's main power cord (6.56 feet) into a wall outlet. You can then use the integrated outlets and USB ports to power or charge your hair dryer, curling iron, phone, tablet, or other compatible electronic devices.



## Embedded fast charging station

Safe, convenient, fast. 4-in-1 design, the perfect charging solution



5V/2A

1 USB output



5V/20W

1 Type-c output



125V/12A

2 AC outlets



6.56 feet

Power Cord

Image: A close-up view of the embedded fast charging station, showing the AC outlets, USB, and Type-C ports in use.

## MAINTENANCE AND CARE

Proper care will help maintain the appearance and extend the lifespan of your Chrangmay Vanity Desk.

- **Cleaning Surfaces:** Use a soft, damp cloth to wipe down all surfaces. Avoid harsh chemicals or abrasive cleaners, which can damage the engineered wood finish.
- **Tempered Glass Top:** The 4mm tempered glass tabletop is designed for durability and scratch resistance. Clean with a glass cleaner and a lint-free cloth to avoid streaks. Avoid placing extremely hot items directly on the glass.

- **Drawers and Shelves:** Periodically empty and wipe down drawers and shelves to prevent dust and debris buildup. Ensure smooth sliding rails remain free of obstructions.
- **Electrical Components:** Ensure the charging station and mirror lights are unplugged before cleaning. Do not spray liquids directly onto electrical components.
- **General Care:** Avoid exposing the desk to direct sunlight or extreme temperature changes, which can affect the wood finish.



## 4mm tempered glass tabletop

The entire tabletop is fitted with tempered glass, effectively protecting the surface from scratches, making it easy to clean, and enhancing durability.

Image: A close-up view highlighting the 4mm tempered glass tabletop, designed for protection and easy cleaning.

## TROUBLESHOOTING

This section addresses common issues you might encounter with your vanity desk.

- **Mirror Lights Not Working:**
  - Ensure the vanity desk's main power cord is securely plugged into a functional wall outlet.
  - Check if the power button on the mirror is being pressed correctly (light touch for on/off, long press for

brightness).

- Verify that the power indicator light is on. If not, try long-pressing the switch button in off mode to activate it.

- **Charging Station Not Functioning:**

- Confirm the vanity desk is plugged into a live power source.
- Test the outlets/ports with a different device to rule out device-specific issues.
- Ensure cables are fully inserted into the ports.

- **Drawers Sticking or Not Sliding Smoothly:**

- Check for any obstructions in the drawer slides.
- Ensure the drawer slides are properly aligned and secured. Refer to assembly instructions if necessary.
- Verify that the drawers are not overloaded.

- **Glass Top Appears Damaged:**

- While tempered glass is durable, extreme impact or thermal shock can cause damage. If the glass is cracked or shattered, discontinue use immediately and contact customer support for replacement options.

- **Assembly Difficulties:**

- Double-check all steps against the provided assembly manual.
- Ensure all parts are correctly oriented.
- If a step is particularly challenging, consider seeking assistance from another person.

## WARRANTY AND SUPPORT

---

Chrangmay is committed to providing high-quality products and excellent customer service. Your vanity desk comes with a standard manufacturer's warranty covering defects in materials and workmanship.

- For specific warranty details, please refer to the documentation included with your purchase.
- If you encounter any product problems, require replacement parts, or have questions regarding assembly or operation, please do not hesitate to contact Chrangmay customer support.
- Contact information can typically be found on the product packaging or on the official Chrangmay website.

We are dedicated to ensuring your satisfaction with your Chrangmay Vanity Desk.

