

Xiangtat SF24 16#

Xiangtat 1/18 Ferrari SF24 F1 2024 Season Charles Leclerc Die-Cast Model Car Instruction Manual

1. INTRODUCTION

Thank you for choosing the Xiangtat 1/18 Ferrari SF24 F1 2024 Season Charles Leclerc Die-Cast Model Car. This model is a meticulously crafted replica, designed for collectors aged 15 years and older. It is not intended as a toy. This manual provides essential information for the proper handling, display, and care of your die-cast model.

Key Features:

- 1/18 Scale Die-Cast Model Car
- Officially licensed Ferrari product
- Die-cast metal body with plastic components
- Steerable wheels and rubber tires
- Four-wheel free rotation

2. SETUP AND DISPLAY

Your die-cast model is designed for display. Follow these steps to unbox and prepare your model for presentation.

2.1 Unboxing the Model

Carefully remove the model from its packaging. The model is secured within a clear acrylic display case, which is then housed in a protective sleeve. Gently slide the inner case out of the sleeve. The model is typically secured to a base with screws to prevent movement during transit. Use a small screwdriver (not included) to carefully loosen these screws from the underside of the base if you wish to remove the model.



Figure 1: Front view of the Ferrari SF24 F1 die-cast model, showcasing its detailed design.



Figure 2: Side profile of the Ferrari SF24 F1 die-cast model, highlighting its aerodynamic shape and sponsor decals.

2.2 Displaying the Model

Place the model on a stable, flat surface away from direct sunlight, extreme temperatures, and high humidity. The included acrylic case provides protection from dust and accidental damage. Ensure the display area is free from vibrations that could cause the model to fall.

Video 1: This video demonstrates the unboxing and initial presentation of the 1/18 Ferrari SF24 F1 2024 Season 16# Car Model, showing how it is secured in its display case.

3. HANDLING AND OPERATING

While designed for durability, proper handling is crucial to maintain the model's condition.

3.1 General Handling

- Always handle the model by its main body, avoiding delicate parts like the wings, mirrors, or antenna.
- Avoid dropping or subjecting the model to impacts, as this can cause damage to the paintwork or structural components.
- Do not force movable parts beyond their intended range of motion.

3.2 Functionality

The model features steerable wheels and four-wheel free rotation, allowing for minor adjustments in display pose. These

functions are for static display purposes only and are not designed for active play or high-speed movement.



Figure 3: Top-down view of the Ferrari SF24 F1 model, showing the intricate cockpit and overall chassis design.

4. MAINTENANCE

Regular maintenance will help preserve the appearance and longevity of your die-cast model.

4.1 Cleaning

- Use a soft, dry microfiber cloth to gently wipe away dust from the model and its display case.
- For stubborn smudges on the acrylic case, a slightly damp cloth with mild soap and water can be used, followed by a dry wipe. Avoid abrasive cleaners.
- Do not use harsh chemicals, solvents, or alcohol-based cleaners on the model itself, as these can damage the paint or plastic components.

4.2 Storage

When not on display, store the model in its original packaging or a similar protective container to prevent dust accumulation and damage. Keep it in a cool, dry place.

5. TROUBLESHOOTING

While die-cast models are generally robust, minor issues can occur. Here are some common concerns and solutions:

5.1 Loose Parts

If a small part becomes loose, carefully reattach it using a small amount of model-safe adhesive if necessary. Ensure the adhesive is suitable for both metal and plastic components and apply sparingly.

5.2 Dust Accumulation

If dust accumulates in hard-to-reach areas, use a soft brush (like a clean, soft paintbrush) or compressed air (held at a safe distance) to dislodge it.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	2.52 x 2.76 x 5.47 inches
Item Weight	1.6 ounces
Scale	1:18
Material	Die-cast metal body with plastic parts
Manufacturer Recommended Age	15 years and up
Model Number	SF24 16#

7. SAFETY INFORMATION

This die-cast model is a collectible item and not a toy. It contains small parts that could pose a choking hazard to young children. Keep out of reach of children under 15 years of age. Handle with care to avoid sharp edges or breakage.

8. WARRANTY AND SUPPORT

For any questions regarding your Xiangtat die-cast model, please refer to the seller's return policy or contact customer support through the platform of purchase. While specific warranty details are not provided, general product support can often be found via the manufacturer or retailer.

Visit the [Xiangtat Store](#) for more products and information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question