

[Manuals.plus](#) /

› [LIGE](#) /

› LIGE DM4 GPS Smartwatch User Manual

LIGE DM4

LIGE DM4 GPS Smartwatch User Manual

Model: DM4

1. INTRODUCTION

Thank you for choosing the LIGE DM4 GPS Smartwatch. This manual provides detailed instructions on how to set up, operate, and maintain your device to ensure optimal performance and longevity. Please read this manual thoroughly before using the smartwatch.



The LIGE DM4 GPS Smartwatch, featuring a 1.43-inch AMOLED display, GPS, Bluetooth calling, and a powerful LED flashlight.

2. PACKAGE CONTENTS

Upon opening your LIGE DM4 Smartwatch package, please verify that all the following items are included:

- LIGE DM4 Smartwatch x1
- Watch Straps x2 (Leather and Silicone)
- Charging Cable x1
- Product Manual x1
- Strap Adjustment Tool x1

3. SETUP GUIDE

3.1 Charging the Smartwatch

Before first use, fully charge your LIGE DM4 smartwatch. Connect the magnetic charging cable to the charging contacts on the back of the watch and plug the USB end into a standard USB power adapter (not included). A full charge typically takes approximately 2 hours.



The LIGE DM4 features a 530mAh battery, offering 7-10 days of typical use and up to 30 days in standby mode.

3.2 App Installation and Pairing

To unlock the full potential of your LIGE DM4 smartwatch, you need to install the companion app on your smartphone. The smartwatch is compatible with Android 5.0+ and iOS 11.0+.

- 1. Activate Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
- 2. Download the App:** Scan the QR code provided in the watch's interface or search for "GloryFit Pro" in your smartphone's app store (App Store for iOS, Google Play Store for Android). You can also download it from <https://app.uteasy.com/app-download/GloryFitPro/download/index.html>.
- 3. Open the App:** Launch the "GloryFit Pro" app and follow the on-screen instructions to create an account or log in.
- 4. Add Device:** In the app, navigate to the device section and select "Add Device" or "Bind Device". The app will search for nearby smartwatches.
- 5. Select Your Watch:** Choose "DM4" from the list of found devices. Confirm the pairing request on both your phone and the smartwatch.
- 6. Enable Call Audio:** After successful connection, you may need to activate the call audio function within the app or your phone's Bluetooth settings to enable Bluetooth calls directly from the watch.



Connection method for the LIGE DM4 smartwatch, illustrating Bluetooth pairing and app setup.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

The LIGE DM4 features a 1.43-inch AMOLED HD touchscreen (466*466 resolution) for intuitive control. Swipe left/right, up/down to navigate through menus and functions. The watch also has physical buttons for quick access to certain features.

Te maintient parfaitement sur la bonne voie

Voyagez librement avec DM4 qui utilise non seulement 6 systèmes de positionnement par satellite pour une couverture fiable, mais capte également les signaux satellites L11 et L5, afin de maintenir la force et la cohérence du signal pour un suivi GPS précis, sans être affecté par les interférences environnementales ou le caisson monobloc en acier inoxydable robuste du montre connecté, même dans les zones urbaines denses.



The six satellite positioning systems supported include GPS, Galileo, GLONASS, BeiDou, QZSS, and NAVIC (IRNSS).



The 1.43-inch AMOLED HD screen provides ultra-high clarity and vibrant colors.

4.2 Bluetooth Calls and Smart Notifications

Once connected via Bluetooth, you can make and receive calls directly from your smartwatch. Enable permissions for the watch and your phone to receive app notifications, text messages, and other alerts.



Receive call and message notifications directly on your wrist.

4.3 GPS and Multi-system Positioning

The DM4 supports single-frequency L1 and six satellite systems (GPS, GLONASS, BeiDou, Galileo, NAVIC, QZSS) for fast and precise location tracking. It also includes a compass, altimeter, and barometer for real-time data on altitude, barometric pressure, and location.

Gardez votre esprit concentré sur le jeu.

Le DM4 contient des capteurs de boussole et d'altimètre barométrique internes qui affichent votre direction actuelle, votre altitude et la pression atmosphérique, de sorte que vous puissiez vous orienter dans la nature à votre guise.



Boussole

Trouvez votre orientation grâce à des mesures précises, où que vous vous aventuriez.



Altitude

Suivez votre altitude actuelle et tracez les tendances de l'altitude.



Pression atmosphérique

Mesurez votre pression atmosphérique actuelle et consultez un graphique des variations.

The smartwatch utilizes six main satellite positioning systems for accurate tracking.

Surveillance du sommeil sur 24 heures

Suivi des é tages de sommeil
Suivi des naps diurnes
Analyse approfondie du sommeil



Surveillance des stades de sommeil



Suivi des siestes diurnes



Analyse approfondie du sommeil



Integrated compass, altimeter, and barometric pressure sensors provide essential outdoor data.

4.4 Integrated LED Flashlight

The smartwatch is equipped with a powerful LED flashlight, providing 6-8 meters of illumination. This feature is suitable for camping, hiking, night adventures, power outages, or finding objects in the dark.



The powerful LED flashlight offers instant illumination for various situations. **Note: Do not direct the light towards eyes.**

4.5 Sports Tracking

The DM4 supports over 120 sports modes, including running, cycling, walking, hiking, and football. It effectively monitors your exercise time, steps, calories burned, and records all-day activities for detailed insights into your fitness.

Batterie 530 mAh, longue durée

La lampe de poche LED, avec un éclairage de haute luminosité, est indispensable pour les situations d'urgence, les signaux de détresse, etc. lors des activités de plein air.



Lampe de poche LED

530 mAh



Temps d'attente
45 Jours

Temps de charge
2.5 Heures

Jours de travail
5-7 Jours

Track your exercises and health with over 170 sports modes.

4.6 24/7 Health Monitoring

Equipped with advanced sensors, the smartwatch provides 24/7 real-time heart rate monitoring and other health tracking functions. It also automatically monitors your sleep status and provides a comprehensive sleep quality analysis to help you adjust your lifestyle. *(Note: Data is for reference only and not intended for medical use.)*



24-hour sleep monitoring provides detailed insights into your sleep quality.

4.7 Other Functions

The LIGE DM4 smartwatch offers a variety of additional features for convenience and utility:

- **Voice Assistant:** Interact with your watch using voice commands.
- **Calculators:** Perform basic calculations directly on your wrist.
- **World Clock:** Keep track of time in different time zones.
- **Find My Phone:** Locate your misplaced smartphone.
- **Music Control:** Control music playback on your connected phone.

- **Camera Control:** Use your watch as a remote shutter for your phone's camera.
- **Weather Forecast:** Get real-time weather updates.
- **Alarm Clock:** Set alarms for reminders.
- **Timer & Stopwatch:** Utilize built-in timing functions.
- **DIY Watch Faces:** Customize your watch face with over 200 options available in the app.
- **Sedentary Reminder:** Get alerts to move after periods of inactivity.
- **Water Consumption Reminder:** Stay hydrated with timely reminders.
- **Do Not Disturb Mode:** Silence notifications when needed.



A wide array of functions are available on the LIGE DM4 smartwatch.



Choose from over 200 watch faces or create your own DIY designs.

5. MAINTENANCE

5.1 Cleaning and Care

To maintain the appearance and functionality of your smartwatch, regularly clean the screen and straps with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

5.2 Water Resistance

The LIGE DM4 smartwatch is IP68 rated, offering protection against dust and immersion in water up to 1.5 meters for 30 minutes. It also boasts 5ATM and IP69K ratings, indicating resistance to high-pressure water jets and prolonged immersion. It is designed to withstand various environmental conditions, including shock, extreme temperatures (-40°C to 70°C), and corrosion.



Qualité U.S. MIL-STD-810H



5ATM & IP69K



Antichoc



Anti-liquide
-40°C à 70°C



Résistant à
la poussière



à la
corrosion



The smartwatch is built to U.S. MIL-STD-810H military-grade standards for durability, including 5ATM & IP69K water resistance, anti-shock, anti-liquid, and corrosion resistance.

5.3 Battery Tips

To maximize battery life, avoid extreme temperatures, use the provided charging cable, and fully charge the device before long periods of inactivity. The 530mAh battery provides 7-10 days of typical use and up to 30 days of standby time.

6. TROUBLESHOOTING

6.1 Common Issues and Solutions

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the charger for at least 10 minutes before attempting to power it on.
- **Unable to pair with phone:**
 - Ensure Bluetooth is enabled on your phone and the watch.
 - Make sure the watch is within the Bluetooth range of your phone.
 - Restart both your phone and the smartwatch.
 - Clear the Bluetooth cache on your phone (if applicable).
 - Try unpairing and re-pairing the device through the app.
- **Notifications not received:**
 - Check app permissions on your phone to ensure notifications are allowed for the GloryFit Pro app.
 - Ensure the GloryFit Pro app is running in the background.
 - Verify that 'Do Not Disturb' mode is not active on either the watch or your phone.
- **Inaccurate health data:** Ensure the watch is worn snugly on your wrist, about one finger's width from your wrist bone. Clean the sensors regularly.
- **Short battery life:**
 - Reduce screen brightness.
 - Disable continuous heart rate monitoring if not needed.
 - Limit the number of apps sending notifications to the watch.
 - Ensure GPS is not constantly active when not in use.

If you encounter persistent issues, please refer to the Warranty & Support section for contact information.

7. SPECIFICATIONS

Feature	Specification
Model Number	DM4
Brand	LIGE
Display	1.43-inch AMOLED HD Touchscreen (466*466 pixels)
Battery Capacity	530 mAh Lithium-Polymer
Battery Life	7-10 days (typical use), up to 30 days (standby)
Charging Time	Approx. 2 hours
Connectivity	Bluetooth
GPS	Multi-system positioning (GPS, GLONASS, BeiDou, Galileo, NAVIC, QZSS)
Water Resistance	IP68, 5ATM, IP69K
Compatible Devices	Android 5.0+ / iOS 11.0+ Smartphones

Feature	Specification
Internal Storage	256 MB
Dimensions (Watch Face)	46mm (diameter) x 12mm (thickness)
Strap Length	150mm (Min) - 260mm (Max)

Lampe de poche LED puissante

*Remarque : Ne dirigez pas la lumière vers les yeux.



Activités nocturnes en plein air

Panne de courant

Trouver des choses

Mode haute luminosité

Mode flash

Mode SOS

Detailed dimensions of the LIGE DM4 smartwatch.

8. WARRANTY AND SUPPORT

LIGE offers a 2-year product care warranty for the DM4 smartwatch. Your comfort and satisfaction are our top priority. If you have any questions, concerns, or require technical assistance, please do not hesitate to contact us. We are committed to responding within 24 hours and providing a satisfactory solution.

For support, please refer to the contact information provided with your purchase or visit the official LIGE brand store on Amazon: [LIGE Brand Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DSC2FDXK>

More documents and user manuals: <https://manuals.plus/>