

[Manuals.plus](#) /

› [EasySMX](#) /

› EasySMX M15 BT Mobile Gaming Controller User Manual


EasySMX ESM-M15

EasySMX M15 BT Mobile Gaming Controller User Manual

Model: ESM-M15 | Brand: EasySMX

PRODUCT OVERVIEW

The EasySMX M15 BT Mobile Gaming Controller is designed for an enhanced gaming experience on mobile devices, compatible with mainstream Android devices and the iPhone 15 series. It features advanced mechanical buttons, Hall-effect joysticks and triggers for precision, and a comfortable telescopic design.



The EasySMX M15 controller in black, holding a smartphone horizontally, showcasing its design as a mobile gaming console.

Key Features

- **Bluetooth Controller for iPhone/Android:** Compatible with a variety of mobile phone models, supporting mainstream Android devices and the iPhone 15 series (excluding Type-C models). *Note: Avoid thick cases over 1mm.*
- **Enhanced Mechanical Buttons:** Equipped with micro-switch buttons with a lifespan of up to 5 million clicks, offering fast response, clear tactile feedback, and high durability.
- **Game Compatibility:** Plays nicely with Xbox, PlayStation, PC games, and streaming services like Steam Link, NVIDIA GeForce Now, and Amazon Luna. Good for titles such as Asphalt 9, Diablo Immortal, Fortnite, and more. *Note: Switch your Android phone to Bluetooth for Call of Duty.*
- **Hall-Effect Joystick & Trigger:** Features Hall-effect technology for precision, no drift, and no dead zones. Uses magnets to detect movement, preventing wear and tear for accurate 360° in-game control.
- **Non-Slip Grip & Telescopic Design:** Suitable for various phones, with a non-slip grip for a stable hold. The telescopic range extends up to 176mm, effectively avoiding the camera.

WHAT'S INCLUDED

The EasySMX M15 package typically includes the following items:



The package includes the EasySMX M15 Mobile Gaming Controller, a user manual, and a USB-C charging cable.

SETUP & PAIRING

Initial Power On & Pairing

To power on the controller and initiate pairing, press and hold the Home button (located on the left side of the controller) until the indicator light starts flashing rapidly.

The controller supports multiple pairing modes:

- **Xbox Mode (Xinput):** Hold the Home button + X button simultaneously for 2 seconds. The indicator light will flash rapidly.
- **PlayStation Mode (Wireless Controller):** Hold the Home button + B button simultaneously for 2 seconds. The indicator light will flash rapidly.
- **HID Mode (Android):** Hold the Home button + A button simultaneously for 2 seconds. The indicator light will flash rapidly.
- **Apple Mode:** Hold the Home button + Y button simultaneously for 2 seconds. The indicator light will flash rapidly.

Once the indicator light is flashing rapidly, navigate to your device's Bluetooth settings and scan for available devices. Select "Xbox Wireless Controller" (for Xbox mode) or "Wireless Controller" (for PlayStation mode) or "EasySMX-M15-Setbb" (for HID/Apple modes) to complete the pairing process.

An official video demonstrating the features and connectivity of the M15 Bluetooth Mobile Gaming Controller.

Reconnecting

After initial pairing, the controller will attempt to automatically reconnect to the last paired device when powered on. If it doesn't connect immediately, the light will slowly blink, indicating it's in auto-reconnect mode. You may need to manually select it from your device's Bluetooth list if automatic reconnection fails.

OPERATING MODES

The EasySMX M15 offers versatile connectivity to suit various gaming platforms.

- **HID Mode (Fn+A):** Standard Android mode, compatible with most native Android games.
- **Xbox Mode (Fn+X):** For Xbox Game Pass, Xbox Remote Play, and games that support Xbox controllers.
- **Apple Mode (Fn+B):** For iPhone 15 series and iOS games that support controllers.
- **Bluetooth Xbox Mode (Fn+Turbo):** An alternative Xbox mode for specific compatibility needs.



A visual guide showing the indicator light colors and button combinations for switching between HID, Xbox, Apple, and Bluetooth Xbox modes.

FEATURES DEEP DIVE

Hall-Effect Joysticks and Triggers

Experience precise and drift-free control with Hall-effect technology. This magnetic sensing system ensures long-lasting accuracy and responsiveness for 360-degree in-game movement.



More Than A Trigger

Hall Effect Sensor



Longer Durability & Faster Actuation

Extra Rapid Trigger Applicable



Toggle Quick Trigger: FN + Left/Right Trigger

An illustration detailing the Hall-Effect sensor in the triggers and joysticks, emphasizing no drift and faster actuation.

Advanced Mechanical Buttons

The controller features micro-switch buttons designed for tactile feedback and rapid response, enhancing your gaming immersion with a satisfying "click" sound.




A cutaway view of the controller's buttons, revealing the micro-switch mechanism for enhanced tactile feedback and durability.

Mappable Back Buttons

Customize your gameplay with two mappable back buttons (M1 and M2) for quick access to complex commands or frequently used actions.



2 Mappable Back Buttons



Combo ▶

M1=A+B+LT

Turbo ▶

M1=A+X+LT

Remap ▶

M1=A M2=B

Programmable buttons in M1/M2 are: A/B/X/Y/LB/RB/LT/RT/L3/R3/D-pad

The back of the controller highlighting the M1 and M2 programmable buttons, which can be configured for combos, turbo functions, or remapping.

Adjustable Vibration

The M15 offers 6-level adjustable vibration feedback, powered by an upgraded micro motor, to provide a more immersive gaming experience. (Note: Vibrations may only be felt in streaming games).



6-level Adjustable Vibration

Upgraded Micro Motor for Next-level Vibration



(*Vibrations can only be felt in streaming games)

An image illustrating the 6-level adjustable vibration feature, indicating an upgraded micro motor for enhanced immersion.

COMPATIBILITY

The EasySMX M15 is broadly compatible with various gaming platforms and services, transforming your mobile device into a portable console.

- **Platforms:** Android, iPhone 15 Series (Bluetooth connection), Xbox Remote Play, PS Remote Play, Steam Link, NVIDIA GeForce Now, Amazon Luna.

- **Games:** Supports popular titles like Asphalt 9, Diablo Immortal, Fortnite, Minecraft, Call of Duty Mobile (requires Bluetooth mode on Android).



A graphic showcasing the controller's compatibility with various gaming platforms and popular mobile games on both iOS and Android.

SPECIFICATIONS

Attribute	Value
-----------	-------

Attribute	Value
Item Model Number	ESM-M15
Product Dimensions	9 x 5 x 2 inches
Item Weight	11.3 ounces
Manufacturer	EasySMX
Country of Origin	China
Batteries	1 9V batteries required. (included)
First Available Date	January 22, 2025

TROUBLESHOOTING

Pairing Issues

If the controller does not pair or connect correctly:

- Ensure the controller is in the correct pairing mode (Xbox, PS, HID, Apple) by holding the Home button and the corresponding mode button (X, B, A, Y) for 2 seconds until the light flashes rapidly.
- Check your device's Bluetooth settings to ensure Bluetooth is enabled and the controller is visible.
- If the controller's light is slowly blinking, it's in auto-reconnect mode. If it doesn't connect automatically, manually select it from your device's Bluetooth list.
- Try unpairing the controller from your device's Bluetooth settings and then re-pairing it.
- Ensure your phone case is not thicker than 1mm, as this can interfere with the telescopic design and connection.

Game Compatibility

Some games may require specific controller modes or settings. For Call of Duty Mobile on Android, ensure your phone is connected via Bluetooth mode. Refer to individual game settings for controller support.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the controller. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** If not using the controller for an extended period, ensure it is fully charged before storage to prolong battery life.

WARRANTY AND SUPPORT

For warranty information, technical support, or further assistance, please visit the official EasySMX website or contact their customer service.

Official EasySMX Store: [EasySMX Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question