

SPYPOINT FORCE-24

SPYPOINT FORCE-24 Non-Cellular Trail Camera User Manual

Brand: SPYPOINT | Model: FORCE-24

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your SPYPOINT FORCE-24 Non-Cellular Trail Camera. Please read this manual thoroughly before using your camera to ensure optimal performance and longevity. The FORCE-24 is designed for wildlife monitoring and scouting, capturing high-quality photos and videos without the need for cellular data plans.

2. PRODUCT OVERVIEW

The SPYPOINT FORCE-24 is a robust non-cellular trail camera engineered to capture clear 2K videos with sound and 24-megapixel photos. It features low-glow LEDs for discreet night vision, a 0.5-second trigger speed, and a 70-foot motion detection range. This camera operates without cellular connectivity, storing all captured media directly onto an SD card (not included).



Image 1: The SPYPOINT FORCE-24 trail camera twin pack, including two cameras, mounting straps, and product packaging. This image illustrates the complete product contents.

FORCE-24



Image 2: A front view of the SPYPOINT FORCE-24 trail camera, highlighting its key specifications: 24MP photo resolution, 2K video resolution, 0.5-second trigger speed, and 70-foot detection range.

3. SETUP

3.1 Battery Installation

1. Open the camera's housing latch.
2. Locate the battery compartment.
3. Insert the required batteries (not included), ensuring correct polarity (+/-).
4. Close the battery compartment securely.

3.2 SD Card Installation

1. With the camera housing open, locate the SD card slot.
2. Insert a compatible SD card (not included) into the slot until it clicks into place. Ensure the card is inserted in the correct orientation.
3. It is recommended to format the SD card using the camera's menu before first use.

3.3 Mounting the Camera

1. Select a suitable location for your camera, such as a tree or post, ensuring a clear view of the desired monitoring area.
2. Use the provided mounting strap to secure the camera firmly. Thread the strap through the designated slots on the camera's back.
3. Adjust the camera's angle to cover the target area effectively.

3.4 Initial Configuration

1. Power on the camera using the ON/OFF switch.
2. Navigate the intuitive setup screen using the camera's control buttons.
3. Set the date, time, and desired operating mode (Photo, Video, Time-Lapse).
4. Adjust settings such as photo resolution, video resolution, trigger delay, and motion sensor sensitivity according to your preferences.

4. OPERATING INSTRUCTIONS

4.1 Powering On/Off

- To power on, slide the ON/OFF switch to the 'ON' position. The camera will enter setup mode.
- To power off, slide the ON/OFF switch to the 'OFF' position.

4.2 Menu Navigation

- Use the navigation buttons (up, down, left, right) to move through menu options.
- Press the 'OK' or 'Enter' button to select an option or confirm a setting.
- Press the 'Menu' or 'Back' button to return to the previous screen or exit the menu.

4.3 Setting Operating Modes

The FORCE-24 offers several operating modes:

- **Photo Mode:** Captures still images when motion is detected. You can set burst mode for multiple photos per trigger.
- **Video Mode:** Records video clips with sound when motion is detected.
- **Time-Lapse Mode:** Captures photos at set intervals regardless of motion.
- **Time-Lapse+ Mode:** Combines time-lapse photography with motion-activated captures.

4.4 Adjusting Settings

Access the camera's settings menu to customize:

- **Resolution:** Choose between 24MP for photos and 2K for videos.
- **Trigger Delay:** Set the delay between consecutive captures.
- **Sensitivity:** Adjust the motion sensor's sensitivity to prevent false triggers or missed events.
- **Burst Mode:** Configure the number of photos taken per trigger in Photo Mode (up to 5 photos).

4.5 Retrieving Photos and Videos

To access your captured media:

1. Power off the camera.
2. Remove the SD card from its slot.
3. Insert the SD card into a computer's card reader or a compatible device.
4. Browse the files on the SD card to view your photos and videos.



Image 3: A laptop screen showing a 2K video clip captured by the SPYPOINT FORCE-24 camera, featuring a deer in a snowy environment. This demonstrates the camera's video quality with sound.



Image 4: A laptop screen displaying 24-megapixel night vision photos captured by the SPYPOINT FORCE-24 camera, showing moose in a dark setting. This illustrates the camera's night vision photo capabilities.

5. MAINTENANCE

5.1 Cleaning

- Regularly clean the camera lens and motion sensor window with a soft, lint-free cloth to ensure clear images and proper detection.
- Wipe the camera's exterior with a damp cloth to remove dirt and debris. Avoid using harsh chemicals.

5.2 Battery Replacement

Replace batteries when the low battery indicator appears on the camera's screen or when performance degrades. Always replace all batteries at once with new ones of the same type.

5.3 SD Card Management

To maintain optimal performance and prevent data corruption, it is recommended to:

- Format the SD card periodically using the camera's menu.

- Use high-quality SD cards (Class 10 or higher) with sufficient storage capacity.

6. TROUBLESHOOTING

If you encounter issues with your SPYPOINT FORCE-24 camera, refer to the following common troubleshooting steps:

- **Camera Not Powering On:** Check battery installation and ensure batteries are fresh. Verify the ON/OFF switch is in the 'ON' position.
- **No Photos/Videos Captured:** Ensure the SD card is properly inserted and formatted. Check the camera's operating mode and settings (e.g., trigger delay, sensitivity). Verify motion detection range and clear any obstructions.
- **Poor Image/Video Quality:** Clean the camera lens. Ensure the camera is securely mounted to prevent movement. Check lighting conditions and adjust camera placement if necessary.
- **Short Battery Life:** Ensure you are using high-quality batteries. Extreme temperatures can affect battery performance. Reduce the frequency of captures or video length if possible.

For further assistance, please contact SPYPOINT customer support.

7. SPECIFICATIONS

Feature	Specification
Brand	SPYPOINT
Model Name	FORCE-24
Photo Resolution	24 Megapixels
Video Capture Resolution	2K (with Audio)
Photo Sensor Technology	CMOS
Flash Memory Type	SD Card (not included)
Video Capture Format	MPEG-4
Supported Audio Format	AAC
Connectivity Technology	USB




Feature	Specification
Trigger Speed	0.5 seconds
Motion Detection Range	70 feet
Special Features	5-Photo Burst Mode, Time-Lapse & Time-Lapse+ Modes, Extended Battery Life, Low Maintenance Setup, Non-Cellular operation (No SIM or Wi-Fi Required)
Lens Type	Wide Angle




8. WARRANTY AND SUPPORT

The SPYPOINT FORCE-24 trail camera typically comes with a manufacturer's warranty. Please refer to the product packaging or the official SPYPOINT website for specific warranty terms and conditions, including duration and coverage details. Keep your proof of purchase for warranty claims.

For technical support, product inquiries, or warranty service, please visit the official SPYPOINT website or contact their customer service department. You can also find more information and support resources on the [SPYPOINT Store on Amazon](#).

Related Documents - FORCE-24

	<p>SPYPOINT FORCE-48 User Manual: Setup, Features, and Troubleshooting</p> <p>Comprehensive user manual for the SPYPOINT FORCE-48 trail camera, covering setup, features, power, memory, installation, file transfer, troubleshooting, warranty, and regulations. Learn how to maximize your game scouting and wildlife tracking experience.</p>
	<p>SPYPOINT SOLAR-DARK Quick Start Guide</p> <p>A quick start guide for the SPYPOINT SOLAR-DARK trail camera, covering setup, power sources, SD card installation, configuration, operating modes, mounting instructions, and disposal. Includes detailed descriptions of components and features.</p>
	<p>SPYPOINT LINK-MICRO-S-LTE Quick Start Guide</p> <p>A comprehensive quick start guide for the SPYPOINT LINK-MICRO-S-LTE trail camera, covering setup, activation, power management, configuration, and disposal.</p>

	<p>SPYPOINT FORCE-24 User Manual</p> <p>Comprehensive user manual for the SPYPOINT FORCE-24 trail camera, covering setup, features, operation, troubleshooting, and warranty information.</p>
	<p>SPYPOINT FORCE-PRO S Quick Start Guide: Setup, Operation, and Installation</p> <p>Comprehensive quick start guide for the SPYPOINT FORCE-PRO S trail camera. Learn how to set up, install, and operate your camera for optimal performance, including power sources, SD card usage, and mode settings.</p>
	<p>Spypoint FORCE-20 Trail Camera Quick Start Guide Setup & Features</p> <p>Get started quickly with the Spypoint FORCE-20 trail camera. This guide covers setup, configuration, modes, and installation for optimal performance. Learn about battery, SD card, and more.</p>

Documents - SPYPOINT – FORCE-24



[SPYPOINT FORCE-24 User Manual](#)

Comprehensive user manual for the SPYPOINT FORCE-24 trail camera, covering setup, features, power options, memory card usage, troubleshooting, and regulatory compliance.

lang:en score:35 filesize: 4.84 M page_count: 26 document date: 2025-06-30



[SPYPOINT FORCE-24 User Manual](#)

Comprehensive user manual for the SPYPOINT FORCE-24 trail camera, covering setup, features, operation, troubleshooting, and warranty information.


lang:en score:33 filesize: 4.84 M page_count: 26 document date: 2025-06-30

[\[pdf\]](#) Instructions Frequently Asked Questions Guide

FORCE 24Jul 9 2025 — Utilisez les boutons △▽◀▶ pour naviguer sur l'écran LCD et changer d'option le bouton OK sélectionner Plusieurs68308bfbe15c4spypoint on demandware static Library Sites spypointSharedLibrary en US v1752128648176 upload manuals 68308bfbe15c4 \$staticlink\$ 24FORCE 1 PlusieursJul Plusieursspypoint v1756473812195 \$staticlink\$spypoint ||| ||| FORCE-24 Guide de dmarrage rapide DANS LA BOTE FORCE-24 COURROIE D INSTALLATION NOTE Les piles sont vendues sparment. Le manuel de l'utilisateur, les mises jour du logiciel et les FAQ sont disponibles l'adresse suivante: www.spypoint.com/su


FORCE-24 Guide de dmarrage rapide DANS LA BOTE **FORCE-24** COURROIE D INSTALLATION NOTE Les piles sont vendues sparment. Le manuel de l'utilisateur, les mises jour du logiciel et les FAQ sont disponibles l'adresse suivante: www.spypoint.com/support. NOS COMPOSANTES q Lentille photo i Prise 12 V...

lang:fr score:27 filesize: 963.17 K page_count: 2 document date: 2025-02-17




[\[pdf\]](#) Instructions Frequently Asked Questions Guide

FORCE 24 6 days ago — Utilisez les boutons △▽◀▶ pour naviguer sur l'écran LCD et changer d'option le bouton OK sélectionner Plusieurs 68308bfb15c4 \$staticlink\$ spypoint on demandware static Library Sites spypointSharedLibrary en US v1751567732944 upload manuals |||



FORCE-24 Guide de démarrage rapide DANS LA BOTE **FORCE-24** COURROIE D'INSTALLATION NOTE Les piles sont vendues séparément. Le manuel de l'utilisateur, les mises à jour du logiciel et les FAQ sont disponibles à l'adresse suivante: www.spypoint.com/support. NOS COMPOSANTES q Lentille photo i Prise 12 V... lang:fr **score:25** filesize: 963.17 K page_count: 2 document date: 2025-02-17


[SPYPOINT FORCE-24 Quick Start Guide](#)



A quick start guide for the SPYPOINT FORCE-24 trail camera, covering installation, setup, and operation modes. lang:en **score:25** filesize: 964.15 K page_count: 2 document date: 2025-02-17

[\[pdf\]](#) User Manual Quick Start Guide Instructions Frequently Asked Questions Guide Diagram

FORCE 248 days ago — User Manual software updates FAQs available at spypoint support The camera will take both a photo and video each detection OTHER68308bdf4a603spypoint on demandware static Library Sites spypointSharedLibrary en US v1755681372354 upload manuals 68308bdf4a603 \$staticlink\$ 24 SpypointJust contact us! 1 888 779 7646 More information in the certifications security guide8 OTHERspypoint \$staticlink\$spypoint OTHERJul 5 2025 Make sure is turned OFF Locate SD card slot It bottom right corner of see diagrams spypoint v1756473812195 ||| ||| FORCE-24 Quick Start Guide IN THE BOX FORCE-24 INSTALLATION STRAP NOTE Batteries sold separately. User Manual, software updates FAQs available at: www.spypoint.com/support. COMPONENTS q Photo lens w Red LED indicator e Low glow flash r Dete



FORCE-24 Quick Start Guide IN THE BOX **FORCE-24** INSTALLATION STRAP NOTE Batteries sold separately. User Manual, software updates FAQs available at: www.spypoint.com/support. COMPONENTS q Photo lens w Red LED indicator e Low glow flash r Detection lens t Cable lock hole y Slot for installation ... lang:en **score:24** filesize: 964.15 K page_count: 2 document date: 2025-02-17