

[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE LED Dresser and TV Stand User Manual

WLIVE ASNG108HH

WLIVE LED Dresser and TV Stand User Manual

Model: ASNG108HH

Brand: WLIVE

INTRODUCTION

Thank you for choosing the WLIVE LED Dresser and TV Stand. This versatile furniture piece combines ample storage with modern features, including customizable LED lighting and integrated power outlets. Designed for bedrooms, living rooms, or entryways, it provides a stable surface for your television and convenient storage for various items. This manual provides essential information for the safe assembly, operation, and maintenance of your new dresser.



Image: The WLIVE LED Dresser and TV Stand, showcasing its design with a television placed on top and the integrated power outlet visible.

Safety Instructions

Please read all safety instructions carefully before assembly and use to prevent injury or damage.

- **Anti-Tipping Kit:** Always install the included anti-tipping kit to secure the dresser to the wall. This is crucial to prevent accidental tipping, especially in households with children or pets.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 25 kg (55 lbs) for the top panel. This stand is suitable for TVs up to 45 inches. Distribute weight evenly across the drawers and top surface.
- **Electrical Safety:**

- Ensure the power cord is not pinched or damaged during assembly or use.
- Only use the integrated power outlets and USB ports for devices within their specified voltage and current limits (AC: 125V/12A, USB: 5V/2.1A).
- Do not overload the outlets.
- Keep liquids away from electrical components.
- **Assembly:** Follow all assembly instructions precisely. Ensure all screws and fasteners are tightened securely before use. Do not overtighten.
- **Placement:** Place the dresser on a flat, level surface. Use the adjustable feet to ensure stability and protect your floor from scratches.
- **Children and Pets:** Keep small parts and packaging materials away from children. Do not allow children to climb on or play with the dresser.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components
- Wooden Top Panel
- Fabric Drawers (8 total)
- LED Light Strip with Controller
- Integrated Power Outlet Unit (2 AC, 2 USB ports)
- Assembly Hardware (screws, bolts, Allen wrench)
- Anti-Tipping Kit
- Instruction Manual

8 LARGE DRAWERS



120-135



120-150



90-100



80-90



40-50



45-60

Image: An illustration of the dresser with its eight fabric drawers, demonstrating their spacious capacity for various items like clothes, diapers, and books.

SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the step-by-step instructions provided in the included assembly guide. It is recommended to assemble the dresser on a soft, clean surface to prevent scratches.

1. Unpack all components and verify against the package contents list.
2. Assemble the metal frame according to the diagrams in the assembly guide, ensuring all connections are secure.
3. Attach the wooden top panel to the assembled frame.
4. Install the integrated power outlet unit into its designated slot on the top panel.
5. Insert the fabric drawers into their respective compartments.
6. Affix the LED light strip to the underside of the top panel or as indicated in the assembly guide.
7. Secure the dresser to the wall using the provided anti-tipping kit. This step is critical for safety.

8. Adjust the leveling feet at the bottom of the dresser to ensure it stands stable and level on your floor.

For visual assistance, refer to the detailed diagrams in the assembly manual. If you encounter any difficulties, please contact customer support.

OPERATING INSTRUCTIONS

LED Light Strip Operation

The integrated LED light strip offers a wide range of customization options to enhance your room's ambiance.

- **Power On/Off:** Use the power button on the remote control or the mobile application to turn the lights on or off.
- **Color Selection:** Choose from over 6000 colors using the color wheel on the remote or app.
- **Brightness Adjustment:** Adjust the brightness level to your preference.
- **Lighting Modes:** Explore various pre-set lighting modes, including static colors, dynamic transitions, and rhythm-based modes that react to music or sound (microphone rhythm).
- **Timer Function:** Set a timer for the lights to automatically turn off.



Image: A visual representation of the RGB LED light strip's features, including color options, microphone rhythm, music rhythm, and timer function, along with its remote control and mobile app interface.

Power Outlet and USB Charging Ports

The dresser is equipped with a convenient power station to charge your devices.

- **AC Outlets (x2):** Plug in your electronic devices requiring standard AC power (125V/12A).
- **USB Ports (x2):** Connect your USB-powered devices for charging (5V/2.1A).
- Ensure devices are compatible with the specified voltage and current.

TELEVISION STANDS WITH POWER OUTLET



Image: A close-up view of the integrated power outlet unit, highlighting the two AC outlets and two USB charging ports, with devices connected for charging.

MAINTENANCE

Regular maintenance will help prolong the life and appearance of your dresser.

- **Cleaning:**
 - For the wooden top panel and metal frame, wipe with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
 - For fabric drawers, spot clean with a mild detergent and water. Allow to air dry completely. Do not machine wash.
- **Stability Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Leveling Feet:** Ensure the adjustable feet are properly set to keep the dresser level and stable.
- **Electrical Components:** Keep the power outlets and USB ports free from dust and debris. Do not attempt to

repair electrical components yourself.

TROUBLESHOOTING

If you encounter any issues with your WLIVE LED Dresser and TV Stand, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Dresser is wobbly/unstable.	Uneven floor; loose fasteners.	Adjust the leveling feet at the bottom. Check and tighten all assembly screws. Ensure anti-tipping kit is installed correctly.
LED lights are not working.	Power not connected; remote battery dead; controller issue.	Ensure the power plug for the LED strip is securely connected to a working outlet. Check remote control battery. If issues persist, contact support.
Power outlets/USB ports not working.	Power cord not plugged in; overloaded circuit.	Verify the main power cord for the outlet unit is fully plugged into a functional wall outlet. Ensure you are not exceeding the maximum current capacity. Try a different device.
Drawers do not slide smoothly.	Overloaded drawer; fabric misaligned.	Reduce the weight in the drawer. Ensure the fabric drawer is properly seated within its compartment and not catching on the frame.

If the problem persists after attempting these solutions, please contact WLIVE customer support for further assistance.

SPECIFICATIONS

- **Model Number:** ASNG108HH
- **Dimensions (L x W x H):** 33.81 cm x 99.9 cm x 79.81 cm (13.31 in x 39.33 in x 31.42 in)
- **Weight:** 13.38 kg (29.5 lbs)
- **Material:** Metal frame, Wood panel, Fabric drawers
- **Color:** Dark Gray
- **TV Stand Capacity:** Up to 25 kg (55 lbs), suitable for TVs up to 45 inches
- **AC Outlets:** 2 (125V/12A)
- **USB Ports:** 2 (5V/2.1A)
- **Special Features:** RGB LED Light Strip (6000+ colors, multiple modes, timer), Anti-tipping kit, Adjustable feet, Scratch-resistant



Image: A detailed diagram illustrating the product dimensions, including height, width, and depth, along with drawer sizes and weight capacities.

WARRANTY AND SUPPORT

WLIVE is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, please retain your proof of purchase.

If you have any questions, concerns, or require assistance with assembly, operation, or troubleshooting, please do not hesitate to contact WLIVE customer support. Our team is ready to help you.

For the most up-to-date contact information, please visit the official WLIVE website or refer to the contact details provided with your purchase.