

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Dakota](#) /
- › [Dakota Digital Clip Watch Model 38249-parent Instruction Manual](#)

Dakota 38249-parent

Dakota Digital Clip Watch Instruction Manual

Model: 38249-parent

[Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. Product Overview

The Dakota Digital Clip Watch is a versatile timekeeping device designed for durability and convenience. It features both analog and digital displays, along with multiple functions including an alarm, stopwatch, timer, calendar, 12/24 hour time mode, and dual time. Its robust construction and integrated carabiner clip allow for easy attachment to various items, making it suitable for outdoor activities and daily use.



Figure 1: Key features of the Dakota Digital Clip Watch.




Figure 2: Dakota Digital Clip Watch (Black).

2. Initial Setup

2.1 Attaching the Watch

The integrated carabiner clip allows for secure attachment to belt loops, backpack straps, golf bags, or other suitable loops. Ensure the clip is fully closed after attachment to prevent accidental detachment.



Figure 3: Watch clipped to a backpack strap.

2.2 Setting Time and Date

Refer to the specific button labels (MODE, LIGHT, SET, STSP) on your watch. Typically, the 'MODE' button cycles through functions, 'SET' is used to adjust values, and 'LIGHT' activates the backlight. The analog hands are usually set by pulling out the crown and rotating it, then pushing it back in. The digital time and date are set using the 'MODE' and 'SET' buttons. Consult the detailed instructions provided with your watch for precise steps.



Figure 4: Dakota Digital Clip Watch on a wooden surface.

3. Operating Instructions

3.1 Timekeeping Functions

- **Analog Display:** Provides traditional hour, minute, and second hands.
- **Digital Display:** Shows time, date, and other functions. Can be set to 12-hour or 24-hour format.
- **Dual Time:** Allows setting and viewing of a second time zone.

3.2 Special Features

- **Alarm:** Set an audible alarm for daily reminders.
- **Stopwatch:** Measure elapsed time with precision.
- **Timer:** Countdown from a preset time.
- **Calendar:** Displays the current date.
- **Light:** Press the 'LIGHT' button to illuminate the digital display for visibility in low-light conditions.
- **Compass:** The integrated compass provides basic directional reference. For precise navigation, a dedicated compass is recommended.



Figure 5: Labeled functions of the watch.

3.3 Multi-Tool Functions

Some models of the Dakota Clip Watch may include additional tools such as a small knife, bottle opener, or flathead screwdriver. These tools are designed for light-duty tasks. Exercise caution when using any sharp or pointed tools.

Video 1: Demonstration of the Dakota Multi-Tool Clip Watch features, including the knife, bottle opener, and flathead screwdriver.

Video 2: Illustrates how the Dakota Watch can be clipped to various items for convenience.

Video 3: Shows the analog and digital displays of the Dakota Clip Watch.

4. Care and Maintenance

4.1 Water Resistance

The watch is 100 feet water resistant. This means it is suitable for splashes, rain, and brief immersion in water. It is not recommended for swimming, diving, or prolonged water exposure. Ensure the crown is pushed in completely to maintain water resistance.



Figure 6: Watch undergoing a water resistance test.

4.2 Cleaning

Clean the watch with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the finish or crystal.

4.3 Battery Replacement

If the watch stops functioning or the display dims, the battery may need replacement. It is recommended to have

the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

5. Troubleshooting

- **Analog and Digital Time Discrepancy:** If the analog and digital times do not match, reset both displays independently. Ensure the analog crown is fully pushed in after setting.
- **Inaccurate Compass:** The integrated compass is designed for basic directional guidance. Environmental factors and magnetic interference can affect its accuracy. For critical navigation, use a professional-grade compass.
- **Digital Display Not Working:** Check if the battery needs replacement. If the issue persists after battery replacement, contact customer support.
- **Watch Not Keeping Time:** This could indicate a low battery or a mechanical issue. Replace the battery first. If the problem continues, seek professional service.

6. Product Specifications

Product Dimensions	3.25 x 1.5 x 0.5 inches
Item Weight	4 ounces
Model Number	38249-parent
Water Resistance	100 feet
Movement	Digital and Analog Quartz
Clasp Type	Tang Buckle (for strap, if applicable)



Figure 7: Product dimensions.

7. Warranty and Support

Dakota products are manufactured with quality components. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Dakota Watch Company website. Keep your proof of purchase for any warranty claims.

Manufacturer: Dakota Watch Company