

Oster OBLD100

Oster Blender Ultra Power 1000 Instruction Manual

Model: OBLD100

1. INTRODUCTION

Thank you for choosing the Oster Blender Ultra Power 1000. This appliance is designed for efficient blending, grinding, and nutrient extraction, offering convenience for various culinary tasks. It features a powerful 1000W motor, six stainless steel blades, and two portable cups (800ml and 600ml) with a travel lid. The blender includes three pre-programmed settings and a stable suction cup base for secure operation.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before use.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Keep hands and utensils out of container while blending to prevent the possibility of severe injury to persons or damage to the blender. A scraper may be used but only when the blender is not running.
- Blades are sharp. Handle with care.
- Always operate blender with lid in place.
- Do not blend hot liquids.
- Ensure the appliance is unplugged before assembling or disassembling parts.

3. PRODUCT COMPONENTS

The Oster Blender Ultra Power 1000 includes the following components:

- Motor Base with control panel
- Blade Assembly with 6 stainless steel blades
- 800ml Portable Blending Cup
- 600ml Portable Blending Cup
- Travel Lid for portable cups



Image: All components of the Oster Blender Ultra Power 1000, including the motor base, blade assembly, 800ml cup, 600ml cup, and travel lid, displayed separately.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean:** Before first use, wash the blending cups, blade assembly, and travel lid in warm, soapy water. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.
3. **Position:** Place the motor base on a clean, dry, and stable surface. The suction cup base will help

secure it.

4. **Assemble Blade:** Place the blade assembly onto the open end of the blending cup. Twist clockwise until securely tightened.

5. OPERATING INSTRUCTIONS

This blender features a simple control panel with three buttons: **TURBO**, **AUTO/PULSAR**, and **MOER**.

1. **Prepare Ingredients:** Add your desired ingredients to either the 800ml or 600ml blending cup. Do not exceed the MAX fill line indicated on the cup.
2. **Attach Cup to Base:** Invert the cup with the blade assembly attached and place it onto the motor base. Twist clockwise to lock it into position. Ensure it is securely seated before operating.
3. **Select Function:**
 - **TURBO:** Provides continuous high-speed blending for smooth results. Press and hold for continuous operation.
 - **AUTO/PULSAR:** Offers a pulse function for controlled blending or can be used for pre-programmed cycles. Press briefly for pulse, or press and release for an automatic cycle.
 - **MOER (Grind):** Specifically designed for grinding harder ingredients. Press and release for an automatic grinding cycle.
4. **Blend:** Press the desired button to start blending. Monitor the consistency of your ingredients.
5. **Finish:** Once blending is complete, release the button (if using TURBO or PULSAR manually) or wait for the automatic cycle to finish. Twist the cup counter-clockwise to unlock and remove it from the motor base.
6. **Serve:** Remove the blade assembly by twisting counter-clockwise. If using the portable cups, attach the travel lid for on-the-go consumption.



Image: The Oster Blender Ultra Power 1000 in operation, blending ingredients to create a smooth dip, demonstrating its use in food preparation.

6. CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your blender.

1. **Unplug:** Always unplug the blender from the power outlet before cleaning.
2. **Disassemble:** Remove the blending cup from the motor base and detach the blade assembly from the cup.
3. **Wash Components:** Wash the blending cups, blade assembly, and travel lid immediately after use. These parts are generally dishwasher-safe (top rack only) or can be hand-washed with warm, soapy water. Exercise extreme caution when handling the sharp blades.
4. **Clean Motor Base:** Wipe the motor base with a damp cloth. Do not immerse the motor base in water or any other liquid.
5. **Dry and Store:** Ensure all parts are completely dry before reassembling or storing. Store the blender in a dry place.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; cup not properly seated; power outage.	Ensure plug is firmly in outlet; twist cup clockwise until securely locked; check household circuit breaker.
Motor stops during operation.	Overheating due to prolonged use or too much load.	Unplug and let cool for 15-20 minutes. Reduce ingredient quantity for next use.
Ingredients are not blending smoothly.	Too little liquid; ingredients too large; air pocket around blades.	Add more liquid; cut ingredients into smaller pieces; use pulse function or shake cup gently.
Leakage from cup.	Blade assembly not tightened; seal ring missing or damaged.	Ensure blade assembly is tightly screwed onto the cup; check if the seal ring is properly in place and undamaged.







8. SPECIFICATIONS

- **Model:** OBLD100
- **Brand:** Oster
- **Power:** 1000 Watts
- **Voltage:** 220 Volts
- **Capacity:** 800 ml and 600 ml portable cups
- **Material:** Plastic (cups), Stainless Steel (blades)
- **Special Features:** Compact design, Intelligent control, Two portable cups with lid, Ultra-powerful motor, Suction cup base.
- **Product Dimensions:** Approximately 14D x 14W x 37H centimeters
- **Package Dimensions:** Approximately 38.5 x 26 x 18 cm; 3 kilograms

9. WARRANTY AND SUPPORT

This Oster Blender Ultra Power 1000 comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

For warranty claims, technical support, or service inquiries, please refer to the contact information provided with your purchase documentation or visit the official Oster website for your region. Please have your model number (OBLD100) and proof of purchase available when contacting support.

	<p>Oster BLSTDG Series Blender User Manual and Recipes</p> <p>Comprehensive user manual for the Oster BLSTDG Series Blender, covering important safeguards, features, operating instructions, cleaning, storage, recipes, and warranty information.</p>
	<p>Oster BL660 Owner's Guide: Refurbished Product Information and Support</p> <p>Comprehensive owner's guide for the Oster BL660 blender, detailing accessory variations, important notes on refurbished units, and product support contact information.</p>
	<p>Oster Easy-To-Use Blender with 5 Speeds User Manual</p> <p>User manual for the Oster Easy-To-Use Blender with 5 Speeds, providing safety instructions, operating guides, cleaning tips, recipes, and warranty information.</p>
	<p>Oster Pro Series Blender with High Performance Motor User Manual</p> <p>User manual for the Oster Pro Series Blender with High Performance Motor (Model BLSTEPG-STO), detailing safety precautions, product features, operation instructions, care and maintenance, and warranty information.</p>
	<p>Oster Easy-to-Clean Blender with Dishwasher-Safe Glass Jar User Manual</p> <p>User manual for the Oster Easy-to-Clean Blender with Dishwasher-Safe Glass Jar (BLSTBCG Series), covering safety, operation, cleaning, and recipes. Visit www.oster.com for more information.</p>
	<p>Oster Pro Series Blender with High Performance Motor User Manual</p> <p>User manual for the Oster Pro Series Blender with High Performance Motor (Model BLSTEPH), providing detailed instructions on safety, operation, assembly, cleaning, maintenance, and warranty information.</p>

