

[Manuals.plus](#) /

› [Spin Master](#) /

› Spin Master DC Comics, Batman Stealth Remote Control Batcycle with 12" Batman Action Figure, Super Hero Kids Toys for Boys and Girls Ages 4 & Up

Spin Master 6074720

Instruction Manual

SPIN MASTER DC COMICS, BATMAN STEALTH REMOTE CONTROL BATCYCLE

Model: 6074720 | Brand: Spin Master

1. INTRODUCTION

The Spin Master DC Comics Batman Stealth Remote Control Batcycle is a full-function remote control vehicle designed for interactive play. This set includes a 12-inch Batman action figure with 11 points of articulation, allowing for dynamic posing and integration with the Batcycle. The Batcycle is approximately 10 inches long and 4 inches wide, suitable for use with other 12-inch action figures.

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Batcycle to ensure a safe and enjoyable experience.



BATMAN and all related characters and elements © & ™ DC.
BATMAN et tous les personnages et éléments connexes © et ™ DC.
WB SHIELD: © & ™ WBEI. (s25)

EXCLUSIVE 12" BATMAN FIGURE

Image: The 12-inch Batman action figure positioned on the Stealth Remote Control Batcycle, highlighting the detailed design and how the figure interacts with the vehicle.

2. WHAT'S INCLUDED

Your Spin Master DC Comics Batman Stealth Remote Control Batcycle package contains the following items:

- 1 x Batcycle
- 1 x Remote Control
- 1 x 12-inch Batman Action Figure



Image: All components of the Batman Stealth Remote Control Batcycle set, including the Batcycle, the 12-inch Batman action figure, the remote control, and the product packaging.

3. SETUP

3.1 Battery Installation

The Batcycle requires 6 AA batteries for operation. The remote control also requires batteries (typically AAA, not specified in product data, but common for RC controllers). Ensure batteries are inserted with correct polarity (+/-).

1. Locate the battery compartment on the underside of the Batcycle.
2. Open the battery compartment cover using a small screwdriver (not included).
3. Insert 6 AA batteries, observing the correct polarity.
4. Replace the battery compartment cover and secure it with the screw.
5. Repeat steps 1-4 for the remote control, inserting the required batteries.

3.2 Figure Placement

Place the 12-inch Batman action figure onto the Batcycle. The figure is designed to sit securely and its arms can be positioned to hold the handlebars, enhancing the realistic play experience.



BATMAN and all related characters and elements © & ™ DC.
BATMAN et tous les personnages et éléments connexes © et ™ DC.
WB SHIELD: © & ™ WBEL. (s25)

HANDS MOVE WITH THE STEERING WHEEL

Image: A child demonstrating how to place the Batman figure onto the Batcycle, illustrating the figure's articulated arms that can be positioned to interact with the steering.

4. OPERATING INSTRUCTIONS

The Batman Stealth Remote Control Batcycle offers full-function remote control, allowing for forward, backward, left, and right movement. The Batman figure's arms turn as you steer the bike, adding to the dynamic play.

4.1 Remote Control Functions

- **Forward/Backward:** Use the left joystick/button to move the Batcycle forward or backward.
- **Left/Right Steering:** Use the right joystick/button to steer the Batcycle left or right.

The controls are designed to be intuitive for users aged 4 and up, providing responsive steering and movement.



BATMAN and all related characters and elements © & ™ DC.
BATMAN et tous les personnages et éléments connexes © et ™ DC.
WB SHIELD: © & ™ WBEL. (s25)

RECREATE EPIC BATTLES & SCENES

Image: A child operating the Batman Stealth Remote Control Batcycle indoors, demonstrating the product in action during play.

4.2 Play Environment

The Batcycle is suitable for both indoor and outdoor play. For optimal performance, use on flat, clear surfaces. Avoid operating in wet conditions or on rough terrain that could damage the vehicle.



BATMAN and all related characters and elements © & ™ DC.
BATMAN et tous les personnages et éléments connexes © et ™ DC.
WB SHIELD: © & ™ WBEL. (s25)

PLAY INDOORS OR OUTSIDE

Image: A child operating the Batman Stealth Remote Control Batcycle outdoors on a paved surface, illustrating its suitability for various play environments.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Batman Stealth Remote Control Batcycle, follow these maintenance guidelines:

- **Cleaning:** Wipe the Batcycle and Batman figure with a clean, damp cloth. Do not immerse in water. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the Batcycle and remote control in a cool, dry place, away from direct sunlight and extreme temperatures. Remove batteries if the product will not be used for an extended period to prevent leakage.
- **Battery Care:** Always use fresh batteries of the recommended type. Do not mix old and new batteries, or different types of batteries. Dispose of used batteries responsibly.

6. TROUBLESHOOTING

If you encounter issues with your Batman Stealth Remote Control Batcycle, please refer to the following common solutions:

- **Vehicle not responding:**

- Ensure both the Batcycle and remote control have fresh batteries installed correctly.
- Check that the power switches on both the Batcycle and remote control are in the "ON" position.
- Verify that the remote control and Batcycle are within operating range of each other.

- **Poor performance or slow movement:**

- Replace old batteries with new ones.
- Ensure the play surface is smooth and clear of obstacles.

- **Interference:**

- Move away from other electronic devices that may cause signal interference.
- Avoid operating multiple RC vehicles on the same frequency simultaneously.

7. SPECIFICATIONS

Feature	Detail
Product Dimensions	15 x 5 x 9 inches
Item Weight	2.5 pounds
Model Number	6074720
Recommended Age	4 years and up
Batteries Required	6 AA batteries (for Batcycle)
Manufacturer	Spin Master
Release Date	July 1, 2025



BATMAN and all related characters and elements © & ™ DC.
BATMAN et tous les personnages et éléments connexes © et ™ DC.
WB SHIELD: © & ™ WBEL. (s25)

Image: The 12-inch Batman action figure standing next to the 10-inch Batcycle, visually representing their approximate sizes.

8. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

This product is recommended for ages 4 years and up. Adult supervision is recommended during play.

- Do not operate the vehicle near people, pets, or fragile objects.
- Keep fingers, hair, and loose clothing away from moving wheels.
- Do not pick up the vehicle while it is in motion.
- Ensure all battery compartments are securely closed before play.

9. WARRANTY AND SUPPORT

This product is covered by the Spin Master Care Commitment. For full details regarding warranty coverage and customer support, please refer to the official Spin Master website or contact their customer service directly.

Manufacturer: Spin Master

For further assistance, please visit www.spinmaster.com or contact their customer support.

