Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bell+Howell 50127

Bell+Howell Ultrasonic Pest Repeller User Manual

Model: 50127

Introduction

The Bell+Howell Ultrasonic Pest Repeller is designed to help control various pests in your home using advanced ultrasonic technology. This device emits high-frequency sound waves that are irritating to pests but generally undetectable by humans and most household pets. It offers a chemical-free and odor-free solution for pest management.

Product Features

- **Safe for Pets and Kids:** Operates without harmful chemicals or odors, making it safe for use around children and pets.
- **Easy to Use:** Simply plug into a standard electrical outlet.
- **Effective on Most Rodents and Insects:** Designed to repel mice, rats, spiders, ants, roaches, and other common household pests.
- **Ultrasonic and Variable Technology:** Emits constantly changing wavelengths to prevent pests from adapting to the sound.
- **Silent and Odorless Operation:** Provides pest control without noise or chemical smells.
- **Room Coverage:** Each unit is effective for a single room, as ultrasonic waves do not travel through walls. For optimal performance, use one repeller per room.
- **LED Indicator:** A built-in LED light indicates that the unit is powered on and operating.
- **Multiple Sizes:** Available in Classic, Micro, and Extra Outlet designs to suit various placement needs.

Setup and Installation

1. **Unpack:** Carefully remove the pest repeller units from their packaging.
2. **Placement:**
    - Identify areas with pest activity or potential entry points.
    - Place one unit per room for maximum effectiveness, as ultrasonic waves do not penetrate walls or solid objects.
    - Ensure the unit is not obstructed by furniture, curtains, or other large items that could block the ultrasonic

waves.

- For best results, plug the unit into a lower outlet, close to the floor, as most pests travel along the floor.

3. **Power On:** Plug the unit directly into a standard 120V AC electrical outlet. The LED indicator light on the front of the unit will illuminate, confirming it is powered on and emitting ultrasonic waves.
4. **Initial Period:** Allow 2-4 weeks for the device to achieve full effectiveness. Pest activity may initially increase as pests are driven out of their hiding places.



Image: The Bell+Howell Ultrasonic Pest Repeller 6-pack, showing the various unit designs and packaging.



Image: A floor plan illustrating optimal placement of multiple pest repeller units for complete room coverage within a home.




Image: A visual comparison of the Classic, Micro, and Extra Outlet designs of the Bell+Howell pest repellers, including their approximate dimensions and suggested uses.

Operating Instructions

Once plugged in, the Bell+Howell Ultrasonic Pest Repeller operates continuously. The unit emits ultrasonic waves that create an uncomfortable environment for pests, encouraging them to leave the protected area. The variable technology ensures that pests do not become accustomed to the sound frequencies.

- The LED indicator light will remain lit as long as the unit is receiving power and functioning.
- No adjustments or settings are required after initial plug-in.
- For continuous protection, keep the units plugged in at all times.




Image: An illustration demonstrating the pest repeller emitting sound waves and highlighting the types of pests it is designed to repel, including ants, geckos, spiders, bed bugs, mosquitoes, cockroaches, and mice.



Image: A scene depicting a child and a cat sleeping peacefully in a room with a pest repeller, emphasizing the product's safety for families and pets.



Image: A collage showing the pest repeller unit placed in different indoor settings such as a bedroom, living room, bathroom, and kitchen, illustrating its versatility for use anywhere in the home.

[redacted]

Video: An official product video from Bell+Howell demonstrating the features and benefits of the pest repeller, including its effectiveness on various pests, whole-home coverage, and safety for kids and pets.

Maintenance

The Bell+Howell Ultrasonic Pest Repeller requires minimal maintenance.

- **Cleaning:** Wipe the exterior of the unit with a soft, dry cloth as needed. Do not use liquid cleaners or immerse the unit in water.
- **Obstruction Check:** Periodically ensure that the front of the unit, where the speaker grille is located, is not blocked by furniture, curtains, or other objects. Obstructions can reduce the effectiveness of the ultrasonic waves.
- **Continuous Operation:** For best results, keep the unit plugged in and operating continuously.

Troubleshooting

Problem	Possible Cause	Solution
LED indicator light is off.	Unit is not receiving power.	Check if the outlet is functioning by plugging in another device. Ensure the unit is fully plugged into the outlet. Check your home's circuit breaker.
Pest activity has not decreased or has increased.	Insufficient time for effectiveness. Obstruction of ultrasonic waves. Unit placement is not optimal. Pests are adapting (less likely due to variable tech).	Allow 2-4 weeks for full results. Initial increase in activity is normal. Ensure the unit is not blocked by furniture, curtains, or other objects. Relocate the unit to an unobstructed area, preferably near the floor. Consider adding more units for larger or multi-room coverage.
Unit is making an audible noise.	Rare occurrence, possibly due to a defect or specific environmental factors.	Unplug and re-plug the unit. If the noise persists, contact customer support.

Specifications

- **Brand:** Bell+Howell
- **Model Number:** 50127
- **Product Dimensions:** Approximately 4"L x 4"W x 4"H (varies slightly by design type)
- **Item Weight:** Approximately 0.55 Pounds (8.8 ounces)
- **Material:** Plastic
- **Color:** White
- **Power Source:** Plug-in Electric (120V AC)
- **Technology:** Ultrasonic, Variable Frequency
- **Target Species:** Mice, Rats, Spiders, Ants, Roaches, and other common insects.
- **Coverage:** One unit per room recommended.

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Bell+Howell website. Keep your purchase receipt for warranty claims.
Manufacturer: Emson
Brand Store: Bell+Howell Store on Amazon

© 2025 Bell+Howell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSCMPVBJ

More documents and user manuals: **https://manuals.plus/**