

[Manuals.plus](#) /

› [Surebonder](#) /

› Surebonder Motorized Mini Glue Gun User Manual

Surebonder B0DSCNHVML

Surebonder Motorized Mini Glue Gun User Manual

Model: B0DSCNHVML

PRODUCT OVERVIEW

The Surebonder Motorized Mini Glue Gun is designed for efficient and precise adhesive application in various crafting and DIY projects. This bundle includes the motorized glue gun and 20, 10-inch all-purpose mini glue sticks, providing a continuous and smooth glue flow without manual pumping.



Image: The Surebonder Motorized Mini Glue Gun, black and lime green, shown alongside a clear plastic bag containing 20 long, clear glue sticks.

Key Features

- **Motorized Mechanism:** Provides a smooth, continuous flow of glue with a simple trigger press.
- **Compact & Ergonomic Design:** Lightweight and easy to handle for intricate tasks and extended use.
- **Easy on the Hands:** Automatic function reduces strain, eliminating the need for continuous trigger pumping.
- **Extra Long Glue Sticks:** 10-inch length minimizes the frequency of refills.
- **Versatile Adhesion:** Bonds to wood, metal, fabric, plastic, ceramics, glass, and more.

FEATURES



Image: A detailed diagram of the glue gun highlighting its components: Detail Tip, Insulated Nozzle Cover, Motorized Trigger, ON/OFF Button, Power Indicator Light and Ready Light, Wide Base, Cord Protector, Ergonomic Rubber Grippled Handle, Feeder Tube, Inlet Tube, and 35-Watts of Heating Power.

SETUP

1. **Unpack:** Carefully remove the glue gun and glue sticks from the packaging.
2. **Inspect:** Check the glue gun and power cord for any visible damage. Do not use if damaged.
3. **Insert Glue Stick:** Insert a 10-inch mini glue stick into the inlet tube at the rear of the glue gun. Push it gently until it stops.
4. **Connect Power:** Plug the power cord into a standard electrical outlet (120V AC).

OPERATING INSTRUCTIONS

Follow these steps for safe and effective operation of your Surebonder Motorized Mini Glue Gun:

1. **Power On:** Press the red ON/OFF button located on the base of the glue gun.
2. **Warm-up:** The power indicator lights will flash, indicating the glue gun is warming up. Allow approximately 3-5 minutes for the glue gun to reach optimal temperature.
3. **Ready for Use:** The lights will turn solid when the glue gun is ready to dispense glue.
4. **Apply Glue:** Hold the glue gun firmly and press the motorized trigger to dispense glue. The motorized mechanism will feed the glue stick automatically. Release the trigger to stop the flow.
5. **Refill:** When the glue stick is nearly depleted, insert a new glue stick into the inlet tube. The new stick will push the remaining portion of the old stick through.

HOW TO USE



1. Push Red ON/OFF Button



2. Lights will flash this indicates glue gun is warming up.



3. Lights turn solid this means the glue gun is ready to use.



4. Add Glue and hold the trigger down until glue comes out.

Image: A four-panel diagram illustrating the usage steps: 1. Push Red ON/OFF Button. 2. Lights will flash, indicating warming up. 3. Lights turn solid, indicating ready to use. 4. Add Glue and hold the trigger down until glue comes out.



Image: A hand holding the Surebonder Motorized Mini Glue Gun, applying a line of hot glue onto a piece of braided ribbon, with additional glue sticks visible in the background.

MAINTENANCE

- **Cleaning:** Always unplug the glue gun and allow it to cool completely before cleaning. Use a dry cloth to wipe down the exterior. Do not use abrasive cleaners or immerse the gun in water.
- **Nozzle Care:** Do not attempt to clean the nozzle while the gun is hot. Never pull out a partially used glue stick from the back of the gun, as this can damage the feeding mechanism.
- **Storage:** Store the glue gun in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the gun is unplugged and fully cooled before storing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Glue gun not heating up.	Not plugged in; power switch off; faulty outlet.	Ensure plug is fully inserted; press ON/OFF button; try a different outlet.
Glue not dispensing.	Not fully heated; no glue stick inserted; glue stick jammed.	Wait for lights to turn solid; insert a new glue stick; ensure glue stick is properly aligned. Do not force.
Glue flow is inconsistent.	Insufficient heating; partially used glue stick.	Allow more time to heat; ensure a full glue stick is inserted to push through any remnants.

SPECIFICATIONS

- **Model:** B0DSCNHVML
- **Brand:** Surebonder
- **Power:** 35 Watts of Heating Power
- **Glue Stick Size:** Mini Size (compatible with 0.28 inch / 7mm diameter glue sticks)
- **Glue Stick Length:** 10 inches (included)
- **Adhesive Type:** All-purpose, high and low temperature compatible.
- **First Available:** January 6, 2025



Image: The front of the Surebonder Clear Stik glue stick packaging, indicating "MINI SIZE", "ALL TEMP", "QUALITY BOND", "MADE IN U.S.A.", and "20 GLUE STICKS".



SUREBONDER
BETTER BONDING™ SINCE 1968

Our clear all purpose adhesive works in both high temp and low temp glue guns making it perfect for all your projects.

Notre colle transparente tout usage fonctionne avec les pistolets à colle à haute et basse température, la rendant idéale pour tous vos projets.

Nuestro adhesivo transparente multiuso funciona en pistolas encoladoras de alta y baja temperatura lo que lo hace ideal para todo sus proyectos.

HIGH TEMP

Bonds to: wood, plastic, metal, ceramic, leather

HAUTE TEMP

Colle à: bois, plastique, métal, céramique, cuir

ALTA TEMP

Uniones: madera, plástico, metal, cerámica, cuero

LOW TEMP

Bonds to: lace, ribbon, floral, fabric, foam

BASSE TEMP

Colle à: dentelle, ruban, bouquet, tissu, mousse

BAJA TEMP

Uniones: encaje, cinta, diseños florales, tela, espuma

KEEP AWAY FROM CHILDREN.

GARDEZ HORS DE LA PORTEE DES ENFANTS.

MANTENGA FUERA DEL ALCANCE DE LOS NIÑOS.

CAUTION: DO NOT touch heated nozzle or melted glue; temperatures can reach 400°F. If hot glue contact occurs, do not remove glue, plunge into cold water. Customer is responsible for testing this product for intended use. Manufacture assumes no responsibility for consequential or indirect damages from the use of this product. **CONFORMS TO ASTM D-4236. - MISE EN GARDE:** Ne pas toucher la buse chaude ou la colle fondue; la température peut atteindre 205°C. S'il y a contact avec la colle chaude, ne pas retirer la colle, mettre sous l'eau froide. Le client est responsable de tester ce produit pour son usage prévu. Le fabricant n'assume aucune responsabilité pour les dommages indirects subis par ce produit. **CONFORME À LA NORME ASTM D-4236. - PRECAUCIÓN:** No toque la boquilla caliente ni el adhesivo fundido; la temperatura puede alcanzar los 205°C. Si se produce contacto con el pegamento caliente, no lo retire y ponga el área afectado bajo un chorro de agua fría. El cliente tiene la responsabilidad de probar este producto para el uso previsto. El fabricante no asume ninguna responsabilidad por daños consecuentes o indirectos debido al uso de este producto. **CUMPLE LA NORMA ASTM D-4236.**

#DT-20M10



0 18239 13825 2

surebonder.com
© 2019 FPC Corporation
Wauconda, IL 60084

MADE IN THE USA
(*with global materials)

FABRIQUE AUX E.-U.
(*avec des matériaux internationaux)

FABRICADO EN EE. UU.
(*con materiales importados)

Image: The back of the Surebonder Clear Stik glue stick packaging, displaying usage notes for high and low temperature applications, caution statements, and manufacturer information.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Surebonder directly. Refer to the product packaging or the official Surebonder website for the most current contact details.

Surebonder Adhesives

Website: www.surebonder.com

Note: This product is from a small business brand. Support small businesses.