

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CalExotics](#) /

› [CalExotics First Time Rotating Venus Butterfly Stimulator User Manual](#)

CalExotics SE-0003-17-3

CalExotics First Time Rotating Venus Butterfly Stimulator User Manual

Model: SE-0003-17-3

INTRODUCTION

The CalExotics First Time Rotating Venus Butterfly is an entry-friendly pleasure device designed for personal exploration. It features a soft, ergonomic shape and rotating stimulation action, offering varied motion to enhance your experience. This manual provides essential information for the safe and effective use, maintenance, and care of your device.

PRODUCT FEATURES

- Full-Contact Design:** Powerful butterfly stimulator with a rotating pleasure tip.
- Multiple Functions:** Offers 10 functions of vibration, pulsation, and escalation.
- Body-Safe Material:** Made from 100% body-safe silicone.
- Waterproof:** Fully waterproof for versatile use and easy cleaning.
- Memory Chip:** State-of-the-art memory chip resumes on the last function used.
- Security Travel Lock:** Hold the power button for 3 seconds to turn on or off the travel lock feature.
- USB Rechargeable:** Includes a USB charging cord. Complete charge in 1 hour. Runs for 30 minutes on high speed and 35 minutes on low speed.

PRODUCT SPECIFICATIONS

Model Number	SE-0003-17-3
Dimensions	4.25 x 3 x 3 inches
Weight	5.6 ounces
Material	Silicone

Color	Purple
Power Source	USB Rechargeable
Manufacturer	California Exotic Novelties

SAFETY INFORMATION

- This product is intended for adult use as a non-medical pleasure device only.
- Not for medical use. Discontinue use in the event of any medical condition or pain.
- Consult a healthcare professional if you have any concerns.
- Keep out of reach of children.
- Do not use if the product appears damaged or defective.

SETUP AND CHARGING

Initial Charge

Before first use, fully charge your device. A complete charge takes approximately 1 hour.

1. Locate the charging port on the device.
2. Connect the provided USB charging cord to the device and to a USB power source (e.g., computer, USB wall adapter).
3. The LED light on the device will flash while charging and glow solid when fully charged.



Image: The CalExotics First Time Rotating Venus Butterfly connected via its USB charging cable to a laptop, illustrating the charging process. The device is purple and butterfly-shaped.

Note: The device runs for approximately 30 minutes on high speed and 35 minutes on low speed on a full charge.

OPERATION

Power On/Off and Travel Lock

- To turn the device ON or OFF, press and hold the power button for 3 seconds.
- This action also functions as a security travel lock, preventing accidental activation.

Cycling Through Functions

- Once powered on, press the power button repeatedly to cycle through the 10 functions of vibration, pulsation, and escalation.
- The device's memory chip will remember the last function used when turned off and resume it upon next activation.



Image: The CalExotics First Time Rotating Venus Butterfly, highlighting its ergonomic design and the rotating pleasure tip.

CLEANING AND MAINTENANCE

- Always clean your device thoroughly before and after each use.
- Wash with warm water and a toy cleaner or mild soap.
- Rinse thoroughly and pat dry with a lint-free cloth.
- Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.
- The device is waterproof, allowing for easy cleaning under running water.



Image: The CalExotics First Time Rotating Venus Butterfly being splashed with water, illustrating its waterproof capabilities for easy cleaning.

STORAGE

- Store your device in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep it separate from other toys made of different materials to prevent damage or reactions.
- Ensure the device is fully charged before storing for extended periods to maintain battery health.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or travel lock is active.	Charge the device for 1 hour. Press and hold the power button for 3 seconds to deactivate the travel lock.
Vibrations are weak.	Low battery.	Recharge the device.
Device does not respond to button presses.	Travel lock is active.	Press and hold the power button for 3 seconds to deactivate the travel lock.

WARRANTY AND SUPPORT

Your CalExotics First Time Rotating Venus Butterfly Stimulator comes with a **1-year limited manufacturer warranty**.

For warranty claims, technical support, or any questions regarding your product, please contact CalExotics customer service. Refer to the product packaging or the official CalExotics website for contact details.

Please retain your proof of purchase for warranty purposes.