Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CalExotics SE-0619-58-3

CalExotics Love Bunny Rockin' G Bunny Vibrator User Manual

Model: SE-0619-58-3
Brand: CalExotics

Introduction **Setup** **Operation** **Maintenance** **Troubleshooting** **Specifications** **Warranty & Support**

1. Introduction

Thank you for choosing the CalExotics Love Bunny Rockin' G Bunny Vibrator, Model SE-0619-58-3. This device is designed to provide a unique experience with its weighted design, triple motors, and body-safe silicone construction. It offers over 100 combinations of rocking and flickering pleasure, along with 12 functions for both the shaft and the stimulator. This manual provides essential information for the safe and effective use of your product.




Image: Front view of the CalExotics Love Bunny Rockin' G Bunny Vibrator.

2. Setup

2.1 Charging

Before first use, fully charge your Love Bunny Rockin' G Bunny Vibrator. The device is USB rechargeable and includes a charging cord. The LED light will flash while charging and glow solid when fully charged.

- Connect the charging cord to the charging port on the device.
- Plug the USB end into a compatible USB power source (e.g., computer, USB wall adapter).

- A complete charge takes approximately 2 hours.
- Once fully charged, the device runs for 45 minutes on high speed and 60 minutes on low speed.



Image: The vibrator connected to its USB charging cable.

2.2 Security Travel Lock

The device features a security travel lock to prevent accidental activation. To unlock or lock the device, press and hold the top button for 3 seconds.

3. Operation

The Love Bunny Rockin' G Bunny Vibrator features triple motors, allowing for independent operation of the shaft and stimulator. It also has a memory chip that resumes on the last function used.

3.1 Activating the Stimulator (Bunny Ears)

- Ensure the device is unlocked (refer to Section 2.2).
- Press the **bottom button** to turn ON the stimulator's vibration.
- Continue to press the **bottom button** to cycle through 12 intense functions of vibration, pulsation, and escalation.
- To turn OFF the stimulator, press and hold the **bottom button** for 3 seconds.

3.2 Activating the Shaft

- Ensure the device is unlocked (refer to Section 2.2).
- Press the **top button** to turn ON the shaft's rocking motion and vibration.
- Continue to press the **top button** to cycle through 12 functions of rocking 'G' stimulation and vibration.
- To turn OFF the shaft, press and hold the **top button** for 3 seconds.

The device offers over 100 combinations when both the stimulator and shaft are active, allowing you to customize your experience.



Image: Rear view of the vibrator highlighting the control buttons.

3.3 Instructional Video

Your browser does not support the video tag.

Video: Official CalExotics video demonstrating the features and operation of the Love Bunny Rockin' G Bunny Vibrator.

4. Maintenance

4.1 Cleaning

The Love Bunny Rockin' G Bunny Vibrator is 100% waterproof (IPX7 submersible), making it easy to clean.

- Clean the device thoroughly before and after each use.
- Wash with warm water and a mild soap or a specialized toy cleaner.
- Rinse thoroughly and pat dry with a lint-free cloth.
- Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.






Image: The vibrator submerged in water, illustrating its waterproof design.

4.2 Storage

Store the device in a clean, dry, and cool place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent potential damage or reactions.

5. Troubleshooting

If you encounter any issues with your Love Bunny Rockin' G Bunny Vibrator, please refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Check if the security travel lock is activated (press and hold the top button for 3 seconds to unlock).
- **Device not charging:** Verify that the charging cable is securely connected to both the device and the USB power source. Try a different USB port or power adapter.
- **Weak vibration:** The battery may be low. Recharge the device.

If the problem persists after attempting these steps, please contact CalExotics customer support for further assistance.

6. Specifications

Feature	Detail
Model Number	SE-0619-58-3
Material	Body-safe Silicone, Acrylonitrile Butadiene Styrene (ABS)
Dimensions	7.25 x 2.5 x 1.25 inches

Weight	12.49 ounces
Power Source	USB Rechargeable
Charge Time	2 hours
Run Time (High Speed)	45 minutes
Run Time (Low Speed)	60 minutes
Waterproof Rating	IPX7 Submersible
Motors	Triple motors, independently operated

7. Warranty & Support

7.1 Warranty Information

The CalExotics Love Bunny Rockin' G Bunny Vibrator comes with a**1-year limited manufacturer warranty**. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use.

7.2 Customer Support

For any questions, concerns, or warranty inquiries, please visit the official CalExotics website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.

Legal Disclaimer: Statements regarding this product have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. For adult use as a non-medical pleasure device only. Not for medical use. Discontinue use in the event of any medical condition or pain.

© 2024 CalExotics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSCRZK63

More documents and user manuals: **https://manuals.plus/**