

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Biolomix](#) /

› [BioloMix BMF101 Electric 4-in-1 Milk Frother User Manual](#)

## Biolomix BMF101

# BioloMix BMF101 Electric 4-in-1 Milk Frother User Manual

Model: BMF101 | Brand: Biolomix

## INTRODUCTION

Thank you for choosing the BioloMix BMF101 Electric 4-in-1 Milk Frother. This appliance is designed to enhance your beverage experience by creating various milk preparations, including hot dense foam, warm airy foam, cold milk foam, and heated milk for hot chocolates. Please read this manual thoroughly before use to ensure safe and optimal operation.



*Image: The BioloMix BMF101 Electric Milk Frother in black, accompanied by a cup of frothed coffee and scattered coffee beans.*

## IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using the appliance.
- Do not immerse the frother base or power cord in water or other liquids.
- Ensure the power supply voltage matches the rating label on the appliance.
- Always unplug the frother from the power outlet when not in use and before cleaning.
- Keep the appliance out of reach of children.
- Do not operate the appliance if the cord or plug is damaged.
- Use the frother only for its intended purpose.
- Avoid contact with moving parts.
- Do not use the frother on an uneven surface or near heat sources.

## PRODUCT OVERVIEW

The BioloMix BMF101 features a sleek design with intuitive controls and a durable stainless steel interior. It comes with a single whisk designed for all functions.

# Enjoy Your Tasty Coffee At Home



Image: The BioloMix BMF101 Electric Milk Frother showing its dimensions (100mm/3.9in width, 220mm/8.66in height, 120mm/4.72in base width).

## Components:

- **Frother Jug:** Stainless steel with non-stick coating.
- **Power Base:** Connects to the power outlet and supplies power to the jug.
- **All-in-One Whisk:** Used for all frothing and heating functions.
- **Lid:** Transparent lid to cover the jug during operation.

# All in One Whisk:

One whisk is suitable for all functions. There is no need to worry about using the wrong whisk to cause milk froth failure.




**Ours**

**One** whisks for **four** functions



**Others**



**Have to  
change to  
different  
whisks**

*Image: A comparison highlighting the BioloMix's single all-in-one whisk for four functions versus other frothers that require changing different whisks for various preparations.*

## SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, clean the frother jug interior and whisk with a damp cloth. Do not immerse the jug exterior or power base in water.
3. **Place Whisk:** Ensure the all-in-one whisk is securely placed on the spindle at the bottom of the frother jug.
4. **Position:** Place the frother jug onto the power base.
5. **Connect Power:** Plug the power base into a suitable electrical outlet.

## OPERATING INSTRUCTIONS

The BioloMix BMF101 offers four distinct functions, easily selected via the touch control panel. Always ensure milk

is added between the MIN and MAX fill lines indicated inside the jug.



*Image: The interior of the frother jug displaying the minimum liquid level (2.7oz/80ml), maximum level for frothing (5.1oz/150ml), and maximum level for heating (10.2oz/300ml).*

### Function Selection:

The control panel features icons for each function. Lightly tap the buttons to cycle through options and start the process.





## 4 Functions

Select your desired function, meeting a variety of needs




**Warm Thick Foam 140°F**




**Warm Thin Foam 140°F**




**Heat Milk 140°F**




**Cold Milk Foam**

*Image: The control panel of the frother illustrating the four functions: Warm Thick Foam (140°F), Warm Thin Foam (140°F), Heat Milk (140°F), and Cold Milk Foam.*

### Function Guide

Function	Icon	Light Color	Time (approx.)	Min Capacity	Max Capacity
Frothing Cold Milk	❄️	Blue	2 min.	100ml	150ml
Frothing Airy Foam & Heating	☕ (thin foam)	Red	1.45 min.	100ml	150ml
Frothing Dense Foam & Heating	☕ (thick foam)	Red	1.45 min.	100ml	150ml
Heating (a small amount of froth)	☕	Red	1.45 min.	100ml	300ml

The frother is equipped with temperature control and an automatic shut-off feature, ensuring milk foam is ready at the optimal temperature without burning.



Image: Graphic illustrating the temperature controller feature of the BioloMix BMF101, which automatically stops heating once the ideal temperature (65°C +/- 5°C or 140-158°F) is reached.

## Video Demonstration:

Your browser does not support the video tag.

Video: Official BioloMix demonstration of the Electric Milk Frother's 4-in-1 automatic hot and cold functions.

## MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and hygiene of your BioloMix milk frother. Always clean the frother before each use.

1. **Disconnect:** Unplug the power base from the electrical outlet.
2. **Remove Whisk:** Carefully remove the whisk from the bottom of the jug.
3. **Clean Interior:** Rinse the interior of the frother jug with water. Use a soft, damp cloth or sponge to wipe away any milk residue.
4. **Clean Whisk:** Wash the whisk under running water.
5. **Dry:** Thoroughly dry all parts before reassembling or storing.
6. **Exterior:** Wipe the exterior of the frother jug and power base with a damp cloth. Do not rinse the exterior or immerse the base in water.



Image: Visual guide for cleaning the frother, emphasizing not to rinse the exterior or bottom, but to wipe the exterior with a wet towel and rinse the interior carefully to prevent overflowing.

## TROUBLESHOOTING

### Common Issues and Solutions

Problem	Possible Cause	Solution
Frother does not start.	Not properly plugged in; jug not correctly placed on base.	Ensure power cord is securely plugged in. Re-position the jug firmly on the power base.

Problem	Possible Cause	Solution
Milk not frothing or heating properly.	Incorrect milk level; whisk not installed; milk type unsuitable.	Check milk levels are between MIN and MAX lines. Ensure whisk is correctly attached. Use whole milk (fat content > 3%) for best frothing results.
Milk burns or sticks to the bottom.	Frother not cleaned properly; excessive milk.	Clean the frother thoroughly after each use. Do not exceed the MAX fill line for heating.

## SPECIFICATIONS

- **Brand:** Biolomix
- **Model Name:** BMF101
- **Special Feature:** 4 in 1 Automatic Hot and Cold Milk Frother
- **Color:** Black
- **Material:** Metal (Stainless Steel interior with non-stick coating)
- **Product Dimensions:** 5.5"W x 8.26"H
- **Capacity:** 150 Milliliters (frothing), 300 Milliliters (heating)
- **Power Source:** Corded Electric
- **Wattage:** 500 watts
- **Item Weight:** 2.23 Pounds
- **Product Care Instructions:** Hand Wash Only (interior)

## WARRANTY AND SUPPORT

For warranty information or product support, please refer to the warranty card included with your purchase or visit the official Biolomix website. Keep your proof of purchase for any warranty claims.

**Manufacturer:** Biolomix

**Contact:** Please refer to the contact details provided in your product packaging or on the official Biolomix website for assistance.