

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [PYY](#) /

> [PYY Countertop Electric Pizza Oven Instruction Manual \(Model: countertop pizza oven\)](#)

PYY countertop pizza oven

PYY Countertop Electric Pizza Oven Instruction Manual

Model: countertop pizza oven

1. IMPORTANT SAFETY INSTRUCTIONS

Read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the voltage rating of the oven matches your power supply. Do not operate with a damaged cord or plug.
- **Heat Hazard:** The oven surfaces become extremely hot during operation. Use oven mitts or gloves when handling hot parts or food. Do not touch hot surfaces directly.
- **Placement:** Place the oven on a stable, heat-resistant surface, away from walls and flammable materials. Ensure adequate ventilation around the appliance.
- **Supervision:** Close supervision is necessary when any appliance is used by or near children.
- **Cleaning:** Always unplug the oven and allow it to cool completely before cleaning. Do not immerse the appliance in water or any other liquid.
- **Intended Use:** This appliance is designed for baking food items such as pizza, pretzels, egg tarts, bread, cakes, pies, pastries, and chicken wings. Do not use for purposes other than its intended use.
- **Damaged Components:** If the baking stone is broken upon arrival, contact customer support for a replacement.

2. PRODUCT OVERVIEW

The PYY Countertop Electric Pizza Oven is designed for efficient baking with precise temperature control and a durable construction.

Key Features:

- **Uniform Heating:** Equipped with upper and lower heating tubes for 360° even heat distribution.
- **Separate Temperature Controls:** Independent controls for upper and lower heating elements allow for flexible baking.
- **Temperature Range:** Adjustable from 122°F (50°C) to 662°F (350°C).

- **Integrated Timer:** A timer function allows setting bake times up to 120 minutes.
- **Easy Monitoring:** Features a built-in light and an explosion-proof, heat-resistant tempered glass window to observe cooking progress without opening the door.
- **Durable Design:** Wrinkle black paint finish is abrasion-proof and fingerprint resistant.
- **Capacity:** Accommodates pizzas up to 14 inches.

Included Components:

- PYY Countertop Electric Pizza Oven
- Pizza Stone



Image 2.1: Front view of the PYY Countertop Electric Pizza Oven, showing the control knobs and viewing window.

3. SETUP

1. **Unpacking:** Carefully remove the oven and all accessories from the packaging. Remove any protective films or

packaging materials from the appliance.

2. **Placement:** Position the oven on a flat, stable, and heat-resistant countertop. Ensure there is at least 6 inches (15 cm) of clear space on all sides of the oven for proper ventilation. Do not place the oven near water or heat sources.
3. **Initial Cleaning:** Before first use, wipe the interior and exterior surfaces with a damp cloth. Wash the pizza stone with warm water and allow it to dry completely.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

4. OPERATING INSTRUCTIONS

4.1 Controls Overview

ENHANCE FLAVOR JOURNEY

Baking Expert, Making Moments Bright



Image 4.1: Close-up of the control panel, illustrating the upper temperature, lower temperature, and baking timer knobs, along with the power switch and oven light switch.

- **Upper Temperature Knob:** Adjusts the temperature of the upper heating elements (122°F - 662°F / 50°C - 350°C).
- **Lower Temperature Knob:** Adjusts the temperature of the lower heating elements (122°F - 662°F / 50°C - 350°C).
- **Baking Timer Knob:** Sets the cooking duration (0 - 120 minutes). The oven will automatically turn off when the timer expires.
- **Power Switch:** Turns the oven on or off.

- **Pizza Oven Light Switch:** Controls the interior oven light for monitoring.

4.2 Preheating the Oven

1. Place the pizza stone inside the oven on the rack.
2. Close the oven door.
3. Turn on the Power Switch.
4. Set both the Upper and Lower Temperature Knobs to your desired baking temperature (e.g., 450°F for pizza).
5. Allow the oven to preheat for 15-20 minutes, or until the desired temperature is reached. Preheating the pizza stone is crucial for a crispy crust.

4.3 Baking Pizza

1. Preheat the oven as described in Section 4.2.
2. Carefully slide the pizza onto the preheated pizza stone using a pizza peel.
3. Close the oven door.
4. Set the Baking Timer to the recommended cooking time for your pizza (typically 8-15 minutes, depending on thickness and toppings).
5. Monitor the pizza through the tempered glass window. Use the oven light if needed.
6. Once baked to your preference, carefully remove the pizza using a pizza peel.
7. Turn off the Power Switch and allow the oven to cool.

Your browser does not support the video tag.

Video 4.2: Demonstration of preparing and baking a pizza in the PYY Countertop Electric Pizza Oven, including ingredient preparation, oven loading, and removal of the finished pizza.

4.4 Baking Other Foods

The oven's adjustable temperature and timer make it suitable for various baked goods. Adjust temperature and time according to the specific food item and desired results.

- **Egg Tarts:** Place tarts on a baking sheet or directly on the pizza stone. Adjust temperature and time as needed.
- **Chicken Wings:** Place wings on a baking sheet lined with foil. Use the separate temperature controls to achieve desired crispiness.
- **Pretzels, Bread, Cakes, Pies, Pastries:** Follow recipe instructions for temperature and baking time.

TIME & ENERGY SAVER

Explore the Multi Cooking Potential



Image 4.3: The PYY pizza oven shown with various food items it can bake, including pizza, egg tarts, grilled sausages, baked vegetables, and chicken wings.

5. MAINTENANCE

5.1 Cleaning

1. **Cool Down:** Always ensure the oven is unplugged and completely cool before cleaning.

2. **Exterior:** Wipe the exterior with a damp cloth. The wrinkle black paint is designed to be abrasion-proof and fingerprint resistant, making cleaning easier. Avoid abrasive cleaners.
3. **Interior:** For the interior, wipe with a damp cloth. For stubborn food residue, a mild detergent can be used, but ensure all soap residue is wiped away.
4. **Pizza Stone:** Scrape off any excess food with a spatula. For baked-on residue, allow the stone to cool, then gently scrub with a stiff brush and warm water. Do not use soap on the pizza stone as it can be absorbed and affect food taste. Ensure the stone is completely dry before next use.
5. **Glass Window:** Clean with a soft cloth and glass cleaner if necessary.

5.2 Storage

Store the oven in a dry, cool place when not in use. Ensure it is clean and completely dry before storage.

6. TROUBLESHOOTING

If you encounter issues with your PYY Countertop Electric Pizza Oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not turn on.	Not plugged in; Power switch off; Circuit breaker tripped.	Ensure power cord is securely plugged in. Turn on the power switch. Check your household circuit breaker.
Oven does not heat up.	Temperature knobs not set; Timer not set; Heating elements malfunction.	Ensure both upper and lower temperature knobs are set to a desired temperature. Set the timer. If the issue persists, contact customer support.
Food is not cooking evenly.	Incorrect temperature settings; Oven not preheated sufficiently; Uneven food placement.	Ensure both upper and lower temperature knobs are set appropriately. Allow sufficient preheating time (15-20 minutes). Distribute food evenly on the baking surface.
Oven door does not close completely.	Obstruction in the door hinge or seal; Misalignment.	Check for any food debris or foreign objects obstructing the door. Gently adjust the door if possible. If the door is damaged or severely misaligned, contact customer support.

If the problem persists after attempting these solutions, please contact PYY customer support for assistance.

7. SPECIFICATIONS

Feature	Detail
Brand	PYY
Model Name	countertop pizza oven
Color	Black
Product Dimensions (D x W x H)	20.8" x 22.4" x 10.8"
Material	Stainless Steel

Feature	Detail
Power Source	Electric
Wattage	1800W
Temperature Range	122°F - 662°F (50°C - 350°C)
Timer	Up to 120 minutes
Control Type	Button Control (Knobs)
Door Style	Dropdown Door
Max Pizza Size	14 inches
Item Weight	48.5 pounds
UPC	797387370795
ASIN	B0DSDFPSTX

IDEAL DIMENSION

20.8"D x 22.4"W x 10.8"H



Image 7.1: Dimensional overview of the PYY Countertop Electric Pizza Oven, indicating its depth, width, and height, alongside a 14-inch pizza for size reference.

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact PYY customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

