Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY FRL09

ALLIMITY FRL09 A/C Replacement Remote Control User Manual

Model: FRL09

1. Overview

This manual provides instructions for the ALLIMITY FRL09 A/C Replacement Remote Control, designed to operate specific Carrier Air Conditioner models. This remote is an infrared (IR) replacement and does not require any programming or pairing. Simply insert batteries, and it is ready for use.



Figure 1: Angled view of the FRL09 Replacement Remote Control.

2. Product Contents

The package for your ALLIMITY FRL09 A/C Replacement Remote Control includes:

- 1 x FRL09 A/C Replacement Remote Control

Note: 2 AAA batteries are required for operation and are not included in the package.

3. Setup

3.1 Battery Installation

To power your remote control, follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch (if present) and lift to open.




Figure 2: Battery compartment open.

3. Insert two (2) new AAA alkaline batteries into the compartment, ensuring the positive (+) and negative (-) ends align correctly with the polarity indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Figure 3: Battery compartment closed.

Your remote control is now ready for use. No programming or pairing is required.

4. Operating Instructions

4.1 Basic Operation

Point the remote control directly at the infrared receiver on your Carrier Air Conditioner unit. Ensure there are no obstructions between the remote and the air conditioner. Press the desired function button to control your unit.





Figure 4: Front view of the FRL09 Remote Control with button layout.

4.2 Button Functions

While specific button functions may vary slightly based on your air conditioner model, common buttons typically include:

- **Power Button:** Turns the air conditioner ON or OFF.
- **Mode Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temperature Up/Down Buttons:** Adjusts the desired temperature setting.
- **Fan Speed Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Swing Button:** Controls the louver swing function.
- **Timer Button:** Sets the timer for automatic ON/OFF.

5. Compatible Air Conditioner Models

This ALLIMITY FRL09 A/C Replacement Remote Control is compatible with the following Carrier Air Conditioner models:

- 42PQV
- 42PHQ007P
- 42PHQ009P
- 42PHQ012P
- 42PHQ014P
- 42PHQ018P
- 42PHQ024P
- 42PHQ009A
- 42PHQ012A

6. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and corrosion. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control or expose it to extreme temperatures, humidity, or direct sunlight.

7. Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

- **Remote Control Not Responding:**
  - Ensure new AAA batteries are correctly installed with proper polarity.
  - Check if there is a clear line of sight between the remote control and the air conditioner's receiver. Remove any obstructions.
  - Verify that the air conditioner unit is powered on and functioning correctly.
- **Intermittent Operation:**
  - Batteries may be low. Replace them with new ones.
  - Ensure you are within the effective operating range of the air conditioner's IR receiver.

If the problem persists after trying these steps, contact customer support for further assistance.

8. Specifications

Key specifications for the ALLIMITY FRL09 A/C Replacement Remote Control:



Figure 5: FRL09 Remote Control with dimensions.

Feature	Detail
Model Number	FRL09
Brand	ALLIMITY
Product Dimensions	5 x 1 x 0.5 inches (approx. 12.7 x 2.54 x 1.27 cm)
Item Weight	2.93 ounces (approx. 83 grams)
Color	White
Special Feature	Ergonomic design
Compatible Devices	Carrier Air Conditioners (specific models listed in Section 5)
Power Source	2 x AAA Batteries (not included)

© 2025 ALLIMITY. All rights reserved.
For support, please refer to your product's purchase platform or contact the seller directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSDSW8QQ

More documents and user manuals: **https://manuals.plus/**