



[Manuals.plus](#) /

› [VASAGLE](#) /

› VASAGLE ULTV540W01 58" Fireplace TV Stand Instruction Manual

VASAGLE ULTV540W01

VASAGLE ULTV540W01 58" Fireplace TV Stand Instruction Manual

Model: ULTV540W01 | Brand: VASAGLE

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your VASAGLE ULTV540W01 58" Fireplace TV Stand. Please read all instructions carefully before assembly and use to ensure safe and proper functionality.



Image: The VASAGLE ULTV540W01 Fireplace TV Stand, featuring a rustic white base with barn doors, a honey brown top, and an illuminated electric fireplace insert. A television is placed on top, surrounded by festive decorations.

IMPORTANT SAFETY INFORMATION

- Do not cover the ventilation openings.
- Leave a gap of at least 0.8" from the wall for ventilation.
- Do not overload the tabletop or shelves. The top of this entertainment center can hold up to 170 lb (77.5 kg).
- Be cautious of sharp edges and small parts during assembly.
- Plug the fireplace TV stand directly into a wall outlet. Do not use a power strip or share the outlet with other devices.
- Ensure all connections are secure before use.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 1 x Fireplace TV Stand (disassembled components)

- 1 x Accessory Kit (includes all necessary hardware and tools)
- 1 x Instructions Manual
- 1 x 18-inch Electric Fireplace Insert with Remote

SETUP AND ASSEMBLY

The VASAGLE Fireplace TV Stand is designed for easy assembly. Follow the detailed instructions provided in the included manual. All necessary tools are supplied.

1. Unpack all components and verify against the parts list.
2. Assemble the main frame of the TV stand according to the step-by-step diagrams.
3. Install the sliding barn doors. These doors can be used to hide or display items in the compartments.
4. Insert the adjustable shelves into the desired height options within the compartments. Each side compartment has 2 adjustable shelves with 3 height options.
5. Carefully place the 18-inch electric fireplace insert into the central opening.
6. Utilize the cable management cutouts at the back of the unit to organize wires and cables for your media devices.

Customized Storage

hello

love is patient, love is friend



2 Adjustable Shelves

Each has 3 height options




Image: Illustration of the TV stand's storage features, highlighting the sliding barn doors and the two adjustable shelves within each side compartment, offering three height options.




Image: Detail showing the circular cutouts at the back of the TV stand, designed for convenient cable management to keep wires tidy.

OPERATING INSTRUCTIONS: ELECTRIC FIREPLACE

The integrated 18-inch electric fireplace offers both aesthetic flame effects and functional heating. It can be controlled via the touch panel on the unit or the included remote control.

Features:

- **10 Temperature Settings:** Adjust the heat output to your comfort level.
- **4 Flame Brightness Levels:** Customize the visual ambiance from dim to bright.
- **1-8 Hour Timer:** Set the fireplace to automatically turn off after a specified duration.
- **Overheat Protection:** For safety, the unit will automatically shut off if it overheats.

Usage:

1. Ensure the fireplace is properly installed and plugged directly into a wall outlet.
2. Use the power button on the unit or remote to turn the fireplace on/off.
3. Press the flame button to cycle through the 4 brightness levels.
4. Press the heat button to activate the heating function and adjust through the 10 temperature settings.
5. Use the timer button to set the desired auto-off duration.
6. **Important:** Do not use the fireplace when the sliding doors are covering it.

10 Temperature Settings



82°F	Orange square	27°C
80°F	Orange square	26°C
78°F	Orange square	25°C
76°F	Orange square	24°C
74°F	Orange square	23°C
72°F	Orange square	22°C
70°F	Yellow square	21°C
68°F	Yellow square	20°C
66°F	Yellow square	19°C
64°F	Yellow square	18°C
°F	Yellow circle	°C



Overheat
Protection

Dual Unit Display



Timer

1-8 Hours

Image: Visual representation of the electric fireplace's 10 temperature settings (64°F to 82°F), along with icons for overheat protection and a 1-8 hour timer function.

4 Brightness Levels



Image: Illustration demonstrating the four adjustable flame brightness levels (L1 to L4) of the electric fireplace, controlled by the included remote control.



Image: A lifestyle shot illustrating the electric fireplace's heating capability, suggesting it can warm an area of approximately 300 square feet, with temperature settings, brightness levels, and a timer.

Your browser does not support the video tag.

Video: An official product video showcasing the VASAGLE Fireplace TV Stand, demonstrating the electric fireplace's flame effects and heating capabilities, along with the overall design and functionality of the unit.

MAINTENANCE

- **Cleaning:** Wipe the surfaces of the TV stand with a damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Fireplace:** Ensure the fireplace is unplugged before cleaning. Gently wipe the glass and exterior with a soft, damp cloth. Do not spray water directly onto the unit.
- **General Care:** Regularly check all screws and connections to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

- **Fireplace not turning on:**
 - Check if the power cord is securely plugged into a wall outlet.
 - Ensure the main power switch on the fireplace unit is in the "ON" position.
 - Verify that the remote control batteries are not depleted.
- **No heat output:**
 - Confirm the heating function is activated via the heat button on the unit or remote.
 - Check for any obstructions around the air vents.
 - The overheat protection may have activated; unplug the unit, wait 15 minutes, and plug it back in.
- **Unstable stand:**
 - Ensure all assembly screws are fully tightened.
 - Place the stand on a flat, level surface.

SPECIFICATIONS

Brand	VASAGLE
Model Number	ULTV540W01
Color	Rustic White + Honey Brown
Material	MDF (Medium Density Fiberboard), Particleboard, Steel
Product Dimensions (L x W x H)	58 x 16 x 24 inches (147 x 40.5 x 60.5 cm)
Item Weight	81 pounds (36.7 kg)
Max. Static Load Capacity of Tabletop	170 lb (77.5 kg)
Fireplace Size	18 inches
TV Size Compatibility	Up to 65 inches (ideal for 40", 43", 50", 55", 60", 65" TVs)
Special Features	10 Temperature Settings, 4 Flame Brightness Levels, 1-8 Hour Timer, Overheat Protection, Sliding Barn Doors, Adjustable Shelves, Cable Management
Batteries Required (for remote)	Yes




Image: A detailed diagram outlining the dimensions of the TV stand (58"L x 16"W x 24"H) and its maximum static load capacity of 170 lbs, along with visual references for compatible TV sizes up to 65 inches.

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or customer support, please refer to your purchase documentation or contact the retailer directly. VASAGLE is committed to providing quality products and assistance.

- **Returns:** This product is returnable until January 31, 2026 (based on provided data). Please check your specific purchase details for the exact return window.

- **Customer Support:** For any questions or issues, please reach out to the customer support provided by your retailer or the manufacturer.