

## Coleshome ZJZ-SB8C

# Coleshome Desk with 8 Fabric Drawers

Model: ZJZ-SB8C | Brand: Coleshome

## 1. INTRODUCTION

Thank you for choosing the Coleshome Desk with 8 Fabric Drawers. This manual provides essential information for the assembly, operation, and maintenance of your new desk. Please read it carefully before use and retain it for future reference.

### Key Features:

- **Ample Storage:** Features 8 easy-to-assemble fabric drawers, ideal for organizing documents, office supplies, cosmetics, and skincare products, keeping your workspace tidy.
- **Stable and Versatile Design:** Equipped with adjustable legs to ensure stability on various surfaces. Functions as a professional desk, vanity table, craft table, or workbench.
- **Robust Construction:** Built with a high-quality metal frame for a stable base. Durable fabric drawers complement the sturdy structure, combining strength and style.
- **Easy Assembly:** Comes with detailed instructions and clearly labeled parts for straightforward setup.

## 2. SAFETY INFORMATION

Please observe the following safety precautions to ensure safe use and prevent damage to the product or injury to yourself.

- **Anchoring:** Ensure the desk is securely anchored to the floor or wall to prevent tipping, especially if heavy items are placed on top or in drawers.
- **Weight Capacity:** Do not exceed the recommended weight capacity for the desktop and drawers. Overloading can compromise stability and cause damage.
- **Placement:** Place the desk on a flat, stable surface. Avoid placing it in areas with high humidity or direct

sunlight, which can affect material integrity.

- **Children:** Keep small children away from the desk during assembly and ensure all small parts are out of reach to prevent choking hazards.
- **Sharp Edges:** Handle components carefully during assembly to avoid cuts from sharp edges.

### 3. SETUP AND ASSEMBLY


---

The Coleshome Desk is designed for simple assembly. Follow these steps carefully. All necessary parts are clearly labeled, and detailed instructions are included in the packaging.

#### Assembly Steps:

1. **Step 1: Assemble the Metal Frame.** Connect the metal frame components as shown in the diagram. Ensure all connections are secure.
2. **Step 2: Attach the Desktop.** Carefully place the desktop onto the assembled metal frame. Align the pre-drilled holes and secure with the provided screws.
3. **Step 3: Install Drawer Supports.** Attach the drawer support rails to the metal frame on both sides of the desk.
4. **Step 4: Insert Fabric Drawers.** Unfold the fabric drawers and insert the bottom panels. Slide the assembled drawers into the designated slots on the support rails.

# Montaggio facile



Passo 1



Passo 2



Passo 3



Passo 4

Assembly diagram illustrating the four steps: 1. Frame assembly, 2. Desktop placement, 3. Drawer frame attachment, 4. Drawer insertion.

For detailed visual guidance, refer to the included instruction manual with diagrams.

## 4. OPERATION AND USAGE

Your Coleshome Desk is designed for functional and organized use. Here are guidelines for optimal operation.

### Using the Fabric Drawers:

- **Drawer Assembly:** Before first use, ensure each fabric drawer is fully unfolded and the rigid bottom panel is inserted to provide stability.
- **Storage:** Utilize the 8 fabric drawers for organized storage of office supplies, documents, personal items, or craft materials. Distribute weight evenly within the drawers.
- **Smooth Operation:** The drawers are designed to slide smoothly. Avoid forcing them if they encounter resistance. Check for obstructions if movement is not fluid.

# 8 pratici scomparti in tessuto

ogni cosa trova il suo posto



Stoffschublade entfalten



Pappe unten anlegen



Fertig



Illustration of the 8 practical fabric compartments, demonstrating their use for organizing various items. The inset shows the simple steps to prepare a fabric drawer for use.

## Adjustable Feet:

- The desk features adjustable feet at the base of its metal legs. These can be rotated to compensate for uneven floor surfaces, ensuring the desk remains stable and level.
- Adjust the feet by turning them clockwise or counter-clockwise until the desk is stable and does not wobble.



## Piano di alta qualità

resistente all'acqua

anti-graffio

facile da pulire



## Gambe in metallo robusto



## Piedini regolabili

proteggono il pavimento

anti-barcollamento

Image highlighting the high-quality desktop surface, robust metal legs, and adjustable feet for stability and floor protection.

## 5. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Coleshome Desk.

### Desktop Care:

- **Cleaning:** Wipe the desktop surface with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Dry immediately with a clean cloth.
- **Spills:** Promptly clean up any spills to prevent staining or damage to the surface.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters for drinks to prevent water rings.
- **Scratches:** While the surface is anti-scratch, avoid dragging sharp or heavy objects across it to prevent damage.

### Fabric Drawer Care:

- **Cleaning:** For light dirt, use a lint roller or a soft brush. For stains, spot clean with a mild fabric cleaner

and a damp cloth. Allow to air dry completely. Do not machine wash.

- **Dusting:** Regularly dust the fabric drawers to maintain their appearance.

### Metal Frame Care:

- **Cleaning:** Wipe the metal frame with a soft, dry cloth to remove dust. For smudges, use a slightly damp cloth and dry thoroughly.
- **Rust Prevention:** Avoid prolonged exposure to moisture to prevent rust.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your Coleshome Desk, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Desk wobbles or is unstable.	Uneven floor surface; loose connections.	Adjust the leveling feet at the bottom of the desk legs. Ensure all screws and bolts are tightened.
Drawers do not slide smoothly.	Drawer not fully assembled; obstruction in the drawer slot; drawer overloaded.	Ensure the bottom panel is correctly inserted into the fabric drawer. Check for any items blocking the drawer's path. Reduce the weight in the drawer.
Missing parts during assembly.	Packaging error.	Carefully check all packaging materials. If parts are still missing, contact Coleshome customer service immediately.
Damage upon arrival.	Shipping damage.	Contact Coleshome customer service within the specified return period with details and photos of the damage.

If the problem persists after attempting these solutions, please contact Coleshome customer support for further assistance.

## 7. SPECIFICATIONS

---

Detailed technical specifications for the Coleshome Desk with 8 Fabric Drawers.

# Spazio ampio per le gambe



Desk dimensions and drawer capacity overview.

Feature	Detail
Brand	Coleshome
Model Number	ZJZ-SB8C
Desk Design	Writing Desk
Product Dimensions (D x W x H)	48P x 120l x 74.2H cm (120 x 48 x 74.2 cm)
Color	Black
Style	Modern Rustic
Base Material	Metal
Top Material Type	Metal

Feature	Detail
Special Feature	Desk with Drawers
Number of Drawers	8 (Fabric Drawers)
Item Weight	14.8 Kilograms
Tabletop Thickness	2 Centimeters
Storage Volume	80 Liters
Recommended Uses	Work, Makeup, Crafts, Gaming
Assembly Required	Yes
Assembly Tools Included	No
Country of Origin	China

## 8. WARRANTY AND SUPPORT

---

### Warranty Information:

This Coleshome Desk comes with a **Limited Warranty**. Please refer to the warranty card included in your product packaging for specific terms and conditions, including coverage duration and what is covered.

### Customer Support:

If your Coleshome Desk arrives damaged, incomplete, or scratched, or if you have any questions regarding assembly, operation, or maintenance, please do not hesitate to contact our customer service team. Our professional support team is committed to resolving your issues within 24 hours.

For assistance, please visit the Coleshome store on Amazon or use the contact information provided in your product packaging.