

[Manuals.plus](#) /

› [sonecesiya](#) /

› sonecesiya Accessories Kit Instruction Manual for Dreame W10 / W10 Pro Robot Vacuum Cleaner

sonecesiya YES0237M

sonecesiya Accessories Kit Instruction Manual for Dreame W10 / W10 Pro Robot Vacuum Cleaner

Model: YES0237M

INTRODUCTION

This instruction manual provides detailed guidance for the installation, maintenance, and replacement of components within the sonecesiya Accessories Kit for Dreame W10 and W10 Pro Robot Vacuum Cleaners. Proper use and maintenance of these replacement parts will help ensure your robot vacuum operates efficiently and maintains optimal cleaning performance.

PRODUCT OVERVIEW

The sonecesiya Accessories Kit (Model YES0237M) is designed to provide essential replacement parts for your Dreame W10 or W10 Pro robot vacuum cleaner. The kit includes:

- 1 Main Brush
- 2 Side Brushes
- 2 Filters
- 2 Mop Pads
- 1 Cleaning Tool




Image: All components included in the sonecesiya Accessories Kit, featuring one main brush, two side brushes, two filters, two mop pads, and a cleaning tool.

COMPATIBILITY

This accessory kit is specifically compatible with the following robot vacuum cleaner models:

- Dreame W10 Robot Vacuum Cleaner
- Dreame W10 Pro Robot Vacuum Cleaner

Ensure your robot vacuum model matches one of the listed models for proper fit and function.

INSTALLATION INSTRUCTIONS

1. Main Brush Installation

1. Turn off the robot vacuum cleaner and place it upside down on a flat surface.
2. Locate the main brush cover, usually secured by latches or screws. Open or remove the cover.
3. Remove the old main brush.
4. Insert the new main brush into its designated slot, ensuring the ends align with the brush bearings.

5. Close the main brush cover securely.

Anti-tangle Main Brush

- ✓ easy to install and disassemble
- ✓ easy to remove hair without tangling
- ✓ made of rubber and nylon, with low noise



Image: The main brush, highlighting its anti-tangle design and ease of installation and disassembly. It is constructed from rubber and nylon for reduced noise.



Image: A detailed view of the main brush, showing its bristles and orange core, ready for installation.

2. Side Brush Installation

1. Turn off the robot vacuum cleaner and place it upside down.
2. Locate the side brushes. They are typically held in place by a screw.
3. Unscrew and remove the old side brush.
4. Align the new side brush with the post and secure it with the screw.

3. Filter Installation

1. Open the dustbin compartment of your robot vacuum.
2. Remove the dustbin.
3. Locate the filter within the dustbin. Remove the old filter.
4. Insert the new filter into the dustbin, ensuring it is seated correctly.
5. Close the dustbin and reinsert it into the vacuum cleaner.

High-Efficiency Particulate Arrestance Filter

Capture 99.97% of particles as small as 0.3 microns,
intercept dust, and do not release it back into the air




Image: A high-efficiency particulate arrestance filter, designed to capture 99.97% of particles as small as 0.3 microns, preventing them from re-entering the air.



Image: A close-up view of the filter, showing its pleated design for maximum surface area and filtration efficiency.

4. Mop Pad Installation

1. Locate the mop pad attachment area on the underside of the robot vacuum.
2. Remove the used mop pads.
3. Attach the new mop pads, ensuring they are securely fastened, typically via Velcro or a clip mechanism.



Image: Two mop pads attached to the underside of a robot vacuum, illustrating their placement for effective floor cleaning.

MAINTENANCE

Regular maintenance of your robot vacuum's accessories is crucial for optimal performance and longevity. Always turn off and unplug the robot vacuum before performing any maintenance.

1. Cleaning the Main Brush

- Remove the main brush as described in the installation section.
- Use the provided cleaning tool to remove hair, debris, and tangled threads from the brush bristles.
- If necessary, rinse the brush under running water. Ensure it is completely dry before reinstallation.
- Inspect the brush for wear and tear. Replace if bristles are significantly damaged or worn.



Image: A close-up of the main brush, showing how hair and debris can accumulate and be removed, emphasizing the importance of regular cleaning.

2. Cleaning the Side Brushes

- Remove the side brushes.
- Remove any hair or debris tangled around the bristles or the brush base.
- If bristles are bent, you can soak them in warm water for a few minutes to help them regain their shape.
- Replace side brushes if bristles are excessively worn or damaged.

3. Cleaning and Replacing Filters

- Remove the filter from the dustbin.
- Tap the filter gently over a trash can to remove loose dust and debris.
- The filters in this kit are washable. Rinse the filter under cool, running water until the water runs clear. Do not use detergent.
- Allow the filter to air dry completely for at least 24 hours before reinstallation. Do not expose to direct sunlight or heat.
- Replace filters every 2-3 months, or more frequently depending on usage and environment, to maintain optimal filtration performance.

WASHABLE & REUSABLE

HEPA material filter can intercept dust and prevent secondary pollution



Image: Two filters being rinsed under water, demonstrating their washable and reusable nature. This helps prevent secondary pollution.

4. Cleaning Mop Pads

- Remove the mop pads from the robot vacuum.
- Wash the mop pads by hand or machine wash with similar colors. Do not use bleach.
- Air dry completely before reattaching to the vacuum.
- Replace mop pads when they show signs of significant wear, reduced absorbency, or damage.

SPECIFICATIONS

Material	Acrylonitrile Butadiene Styrene (ABS), Non-woven Fabric, Nylon, Microfiber
Main Brush Size	11 cm (length)

Filter Size	14 x 4.9 x 1.2 cm
Side Brush Length	4 + 8.5 cm (total length of arms)
Model Number	YES0237M
Included Components	1 Main Brush, 2 Side Brushes, 2 Filters, 2 Mop Pads, 1 Cleaning Brush

TROUBLESHOOTING

If you encounter issues after replacing parts, consider the following:

- **Reduced Cleaning Performance:** Ensure all brushes are free of tangles and debris. Check that filters are clean and properly seated.
- **Unusual Noises:** Verify that the main brush and side brushes are correctly installed and not obstructed.
- **Parts Not Fitting:** Double-check that the kit is compatible with your specific Dreame W10 or W10 Pro model. Refer to the "Compatibility" section.
- **Vacuum Error Messages:** Consult your Dreame W10/W10 Pro robot vacuum's original user manual for specific error code interpretations.

WARRANTY AND SUPPORT

For any questions regarding the sonecesiya Accessories Kit, or if you experience issues not covered in this manual, please contact sonecesiya customer support. Refer to your purchase documentation for specific warranty details and contact information.

You can often find support information on the brand's official website or through the retailer where the product was purchased.

