Oosofi Manchester

Oosofi Manchester 20" Wide Wall Cabinet User Manual

Model: Manchester

1. Product Overview

The Oosofi Manchester Wall Cabinet is a compact and versatile storage solution designed to maximize space in various rooms. It features a single door and two internal shelves, providing organized storage for your essentials.




Image 1.1: Front view of the Oosofi Manchester Wall Cabinet.

2. Safety Information

Please read all instructions carefully before assembly and installation. Failure to follow these instructions may result in injury or damage to the product.

- **Wall Mounting:** This cabinet is designed for wall mounting. Ensure the wall structure is suitable to support the cabinet's weight and its contents. Use appropriate hardware for your wall type (e.g., drywall anchors, stud screws).
- **Weight Capacity:** Do not exceed the maximum weight limits for the shelves and top surface. Refer to the specifications section for details. Overloading can cause the cabinet to detach from the wall or collapse.
- **Assembly:** Assemble the cabinet on a soft, clean surface to prevent scratches. Keep small parts away from children during assembly.
- **Stability:** After installation, ensure the cabinet is securely fastened and stable. Periodically check all connections for

tightness.




Image 2.1: Weight distribution and capacity for the Oosofi Manchester Wall Cabinet. Top surface: 10 kg (22 lb). Each internal shelf: 15 kg (33 lb).

3. Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

- Top Panel
- Bottom Panel
- Side Panels (x2)
- Back Panel
- Door Panel
- Adjustable Shelves (x2)
- Hardware Pack (screws, dowels, hinges, handle, wall mounting brackets)

4. Tools Required

The following tools are recommended for assembly and installation:

- Phillips Head Screwdriver
- Drill (for wall mounting)
- Drill Bits (appropriate for wall anchors)
- Level
- Measuring Tape
- Pencil
- Hammer (optional, for dowels)

5. Assembly Instructions

1. **Prepare Panels:** Lay out all panels on a clean, soft surface. Identify each panel according to the included diagram (if applicable).
2. **Assemble Frame:** Attach the side panels to the top and bottom panels using the provided screws and dowels. Ensure all connections are tight.
3. **Install Back Panel:** Slide or fasten the back panel into the grooves or onto the back of the assembled frame. Secure with small nails or screws as provided.
4. **Attach Hinges to Door:** Secure the hinges to the door panel using the designated screws.
5. **Attach Door to Cabinet:** Mount the door to the cabinet frame by attaching the hinges to the pre-drilled holes on one of the side panels. Adjust hinges for proper door alignment.
6. **Install Handle:** Attach the handle to the door using the provided screws.
7. **Insert Shelves:** Place the shelf pins into the desired holes on the side panels. Rest the adjustable shelves on these pins.

6. Installation Instructions (Wall Mounting)

Proper wall mounting is critical for safety and stability. If you are unsure, consult a professional.

1. **Choose Location:** Select a suitable wall location, ensuring no hidden electrical wires or plumbing.
2. **Mark Mounting Points:** Hold the cabinet against the wall at the desired height. Use a level to ensure it is straight. Mark the positions for the wall mounting brackets or screws.
3. **Drill Pilot Holes:** Drill pilot holes at the marked locations. Use a drill bit appropriate for your wall type and the

provided wall anchors.

4. **Insert Wall Anchors:** Insert wall anchors into the pilot holes if required for your wall type (e.g., drywall).
5. **Attach Mounting Hardware:** Secure the wall mounting brackets or screws into the wall. Ensure they are firmly attached.
6. **Mount Cabinet:** Carefully lift the cabinet and align its mounting points with the hardware on the wall. Secure the cabinet to the wall. Double-check that it is level and stable.

7. Operating Instructions

The Oosofi Manchester Wall Cabinet is designed for straightforward use.

- **Opening/Closing the Door:** Use the handle to gently open and close the cabinet door. Avoid forcing the door.
- **Adjusting Shelves:** The internal shelves are adjustable. To change shelf height, remove items from the shelf, lift the shelf, remove the shelf pins, reposition the pins to desired holes, and then place the shelf back on the pins.
- **Storage:** Distribute weight evenly on the shelves and do not exceed the maximum weight capacity per shelf or for the entire cabinet.




Image 7.1: The Oosofi Manchester Wall Cabinet with its door open, demonstrating internal storage capacity.

8. Maintenance and Care

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.
- **Avoid Excessive Moisture:** Do not expose the cabinet to excessive moisture or humidity, as this can cause warping or damage.

9. Troubleshooting

- **Door Not Closing Properly:** Check hinge alignment. Adjust hinges as needed using a screwdriver. Ensure no items inside are obstructing the door.
- **Cabinet Feels Unstable:** Verify that the wall mounting hardware is securely fastened to the wall and the cabinet. Ensure all internal assembly screws are tight.
- **Scratches on Surface:** Minor scratches can sometimes be touched up with a furniture repair pen matching the cabinet's finish.

10. Specifications

Feature	Detail
Brand	Oosofi
Model	Manchester
Color	White
Material	Engineered Wood
Product Dimensions (D x W x H)	13.1" x 19.7" x 23.6" (33.5 cm x 50.0 cm x 60.0 cm)
Item Weight	31.8 pounds
Top Surface Weight Capacity	10 kg (22 lb)
Internal Shelf Weight Capacity (each)	15 kg (33 lb)
Special Feature	Easy to Install
Mounting Type	Wall Mount



Image 10.1: Dimensional overview of the Oosofi Manchester Wall Cabinet.

11. Warranty and Support

Oosofi products are manufactured with quality and care. For specific warranty information, please refer to the documentation included with your purchase or contact Oosofi customer support.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Oosofi customer support through the retailer where the product was purchased or visit the official Oosofi website.

Oosofi Customer Support: Please refer to your purchase receipt or the Oosofi brand store for contact details.

© 2026 Oosofi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question