

Coleshome B01SY141901001UK

Coleshome Desk with 8 Drawers (120 x 48 cm) - Instruction Manual

Model: B01SY141901001UK

- Contents
- Assembly
- Introduction
- Safety Information
- Package
- Usage
- Maintenance
- Troubleshooting
- Specifications
- Support

1. INTRODUCTION

Thank you for purchasing the Coleshome Desk with 8 Drawers. This manual provides detailed instructions for assembly, usage, maintenance, and troubleshooting to ensure you get the most out of your new desk. Please read this manual carefully before beginning assembly and retain it for future reference.

2. SAFETY INFORMATION

- Keep all packaging materials, especially plastic bags, away from children and pets to prevent suffocation.
- Assemble the desk on a clean, soft surface (e.g., carpet) to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not overload the desk or drawers. Refer to the specifications for weight limits.
- Avoid standing or sitting on the desk.
- Use only the provided parts and hardware. Do not substitute with other components.
- If any parts are missing or damaged, do not proceed with assembly. Contact customer support immediately.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present. Tools for assembly are not included.

- Desk Top Panels (x3)
- Metal Frame Components (various bars and legs)
- Fabric Drawers (x8)
- Drawer Handles (x8)

- Adjustable Foot Pads (x4)
- Assembly Hardware (screws, bolts, Allen wrench - if included, otherwise user must provide)



Figure 1: Overview of the Coleshome Desk with key dimensions: 120cm length, 48cm width, and 74.2cm height. A single drawer is shown with internal dimensions and a 5kg weight capacity.

4. ASSEMBLY INSTRUCTIONS


Follow these steps carefully to assemble your Coleshome Desk. It is recommended to have two people for assembly, though it can be done by one person.

Step 1: Assemble the Metal Frame

1. Unpack all metal frame components and lay them out.
2. Connect the vertical support bars to the horizontal crossbars using the provided screws. Ensure all connections are snug but do not fully tighten yet.
3. Attach the adjustable foot pads to the bottom of the desk legs.
4. Once the basic frame structure is complete, gently place it upright and ensure it is stable. Then, fully tighten all screws.



High quality board



Stable frame



**Adjustable
Foot pads**



Figure 2: Detail showing the stable metal frame construction and adjustable foot pads for leveling the desk on uneven surfaces.

Step 2: Attach the Desk Top Panels

1. Carefully place the desk top panels onto the assembled metal frame.
2. Align the pre-drilled holes in the desk top with the holes in the frame.
3. Secure the desk top panels to the frame using the appropriate screws. Tighten firmly.

Step 3: Assemble and Insert Fabric Drawers

1. For each fabric drawer, unfold it completely.
2. Insert the rigid cardboard bottom into the base of the unfolded drawer. This provides stability.
3. Attach the drawer handle to the front of the fabric drawer using the provided screws.
4. Repeat for all 8 drawers.
5. Slide the assembled fabric drawers into their respective slots in the desk frame.

8 Fabric Drawers for Easy Assembly



Figure 3: Step-by-step guide for assembling the fabric drawers: unfold, insert cardboard bottom, and attach handle.

5. USAGE

The Coleshome Desk is designed for versatile use in various settings, including home offices, studies, or as a vanity table.

- **Workstation:** The spacious tabletop (120 x 48 cm) can accommodate monitors, laptops, keyboards, and other office essentials.
- **Storage:** The eight fabric drawers provide ample storage for documents, stationery, personal items, and more. Each drawer has a maximum weight capacity of 5 kg.
- **Leveling:** Use the adjustable foot pads to ensure the desk is stable and level on uneven floors.



Figure 4: The Coleshome desk configured as a functional home office workstation, demonstrating its capacity for multiple screens and accessories.



Figure 5: The Coleshome desk adapted for use as a vanity table, showcasing its versatility for different room functions.

6. MAINTENANCE

- **Cleaning the Tabletop:** Wipe the tabletop with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the surface. Dry immediately with a clean cloth.
- **Cleaning Fabric Drawers:** Spot clean fabric drawers with a mild detergent and a damp cloth. Do not machine wash or submerge in water. Allow to air dry completely.
- **Frame Care:** Wipe the metal frame with a soft, dry cloth to remove dust.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause fading or damage to the desk materials.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly or uneven.	Uneven floor surface; loose screws; foot pads not adjusted.	Adjust the foot pads on the bottom of the desk legs until stable. Check and tighten all assembly screws.

Problem	Possible Cause	Solution
Drawers do not slide smoothly or fit properly.	Drawer not assembled correctly; obstruction in the slot; frame not square.	Ensure the cardboard bottom is fully inserted and the drawer is unfolded correctly. Check for any items obstructing the drawer slot. Verify the metal frame is assembled squarely and all screws are tight.
Missing or damaged parts.	Packaging error; shipping damage.	Do not proceed with assembly. Contact Coleshome customer support immediately for replacement parts.
Tabletop panels do not align flushly.	Frame not perfectly square; panels not correctly positioned during attachment.	Loosen the screws holding the tabletop panels slightly, adjust the panels for better alignment, then re-tighten. Ensure the frame is square before attaching the tabletop.

8. SPECIFICATIONS

- Model:** B01SY141901001UK
- Brand:** Coleshome
- Dimensions (L x W x H):** 120 x 48 x 76 cm
- Weight:** 15.6 Kilograms
- Material:** Metal (frame), High-quality Board (tabletop), Fabric (drawers)
- Number of Drawers:** 8
- Drawer Weight Capacity:** 5 kg per drawer
- Assembly Required:** Yes

9. WARRANTY AND CUSTOMER SUPPORT

For any questions, missing parts, or issues with your Coleshome Desk, please contact Coleshome customer support. Refer to your purchase documentation for specific warranty details and contact information. Please have your model number (B01SY141901001UK) and purchase date ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DSFS7Q6L>

More documents and user manuals: <https://manuals.plus/>