

[manuals.plus](#) /

› [RADLEY](#) /

› [RADLEY Coulis Magic Carousel Medium Bifold Purse S1317673 User Manual](#)

RADLEY S1317673

RADLEY Coulis Magic Carousel Medium Bifold Purse S1317673 User Manual

Comprehensive instructions for your RADLEY purse.

1. INTRODUCTION

This manual provides detailed instructions for the proper use, care, and maintenance of your RADLEY Coulis Magic Carousel Medium Bifold Purse, model S1317673. Please read this guide thoroughly to ensure optimal enjoyment and longevity of your product.

2. PRODUCT OVERVIEW

The RADLEY Coulis Magic Carousel Medium Bifold Purse is a stylish and functional accessory crafted from smooth leather. It features a unique applique and print design, secured with a press stud fastening. The interior is designed for efficient organization of cards, notes, and coins.

Key Features:

- Material:** Smooth leather construction.
- Design:** Applique and print detailing, featuring the 'Magic Carousel' theme.
- Closure:** Secure press stud fastening.
- Card Storage:** Ten (10) dedicated card slots.
- Slip Pockets:** Two (2) internal slip pockets for additional storage.
- Notes Compartment:** One (1) compartment for banknotes.
- Coin Pocket:** One (1) zipped coin pocket for secure storage of loose change.
- Dimensions:** Approximately 5.5 inches (W) x 3.5 inches (H) x 1 inch (D).

Product Images:




Figure 2.1: Front view of the purse. This image displays the exterior of the RADLEY Coulis Magic Carousel Medium Bifold Purse. It is pink with a decorative applique of a carousel dog and the phrase "There is magic in the Carousel" in script. The RADLEY LONDON logo is visible at the top center.



Figure 2.2: Back view of the purse. This image shows the plain back of the purse, highlighting the smooth pink leather finish and stitching details.



Figure 2.3: Interior view of the open purse. This image illustrates the internal organization, including multiple card slots on both sides, two slip pockets, and the embossed RADLEY LONDON logo.



Figure 2.4: Angled view of the open purse. This image provides a perspective of the purse's depth when open, clearly showing the zipped coin pocket and the notes compartment.

3. SETUP

Your RADLEY Coulis Magic Carousel Medium Bifold Purse is ready for immediate use upon receipt. No assembly or complex setup is required.

- 1. Unpacking:** Carefully remove the purse from its packaging.
- 2. Initial Inspection:** Inspect the purse for any signs of damage during transit. If any issues are found, please refer to the Warranty and Support section.
- 3. Dust Bag:** The purse comes with a Radley London dust bag. It is recommended to store the purse in this bag when not in use to protect it from dust and scratches.

4. OPERATING INSTRUCTIONS

This section details how to utilize the various compartments and features of your bifold purse.

4.1. Opening and Closing the Purse

- Opening:** Locate the press stud fastening on the front flap. Gently pull the flap to release the stud.
- Closing:** Align the front flap with the main body of the purse and press firmly on the stud until you

hear a click, indicating it is securely fastened.

4.2. Using Card Slots

- The purse features ten individual card slots. Insert standard-sized credit cards, debit cards, or identification cards into these slots.
- Avoid forcing multiple cards into a single slot to prevent stretching the leather or damaging the cards.

4.3. Utilizing Slip Pockets

- Two slip pockets are provided for items such as receipts, small notes, or additional cards that do not require individual slots.
- These pockets are located behind the card slots.

4.4. Notes Compartment

- The main compartment is designed to hold banknotes. Fold larger denominations if necessary to fit comfortably.

4.5. Zipped Coin Pocket

- Use the zipper to open and close the coin pocket. This pocket is ideal for securing loose change.
- Ensure the zipper is fully closed to prevent coins from falling out.

5. MAINTENANCE AND CARE

Proper care will help preserve the quality and appearance of your leather purse.

5.1. General Care

- **Avoid Overstuffing:** Do not overfill your purse, as this can stretch the leather and distort its shape.
- **Protect from Moisture:** Leather is susceptible to water damage. Avoid prolonged exposure to rain or high humidity. If it gets wet, gently blot with a clean, dry cloth and allow it to air dry naturally, away from direct heat.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the leather to fade or dry out.
- **Storage:** When not in use, store the purse in its provided dust bag in a cool, dry place. Stuff it lightly with tissue paper to help maintain its shape.

5.2. Cleaning

- **Surface Cleaning:** For light dirt or dust, wipe the leather gently with a soft, damp cloth.
- **Stains:** For more stubborn stains, use a specialized leather cleaner according to the product's instructions. Always test any cleaning product on an inconspicuous area first.
- **Conditioning:** Periodically apply a leather conditioner to keep the leather supple and prevent cracking.
- **Avoid Harsh Chemicals:** Do not use harsh chemicals, abrasive cleaners, or alcohol-based products, as these can damage the leather finish.

6. TROUBLESHOOTING

While the RADLEY Coulis Magic Carousel Medium Bifold Purse is designed for durability and ease of use, here are some common considerations:

- **Difficulty Closing the Press Stud:** Ensure the purse is not overfilled. Remove some contents if necessary to allow the stud to align and fasten properly.
- **Zipper Sticking:** If the coin pocket zipper becomes stiff, gently rub a small amount of graphite (from a pencil) along the teeth, then work the zipper back and forth. Avoid forcing the zipper.
- **Leather Appearance Changes:** Natural leather may develop a patina over time, which is a characteristic of genuine leather. Minor scratches can often be buffed out gently with a soft cloth or a leather conditioner.

7. SPECIFICATIONS

Feature	Detail
Brand	RADLEY
Model Number	S1317673
Product Name	Coulis Magic Carousel Medium Bifold Purse
Material	Smooth Leather
Color	Pink
Dimensions (W x H x D)	5.5" x 3.5" x 1" (14 cm x 8.9 cm x 2.5 cm)
Item Weight	6 ounces (170 grams)
Card Slots	10
Slip Pockets	2
Notes Compartments	1
Coin Pocket	1 (Zipped)
Closure Type	Press Stud

8. WARRANTY AND SUPPORT

Specific warranty details for your RADLEY Coulis Magic Carousel Medium Bifold Purse are typically provided at the point of purchase or can be found on the official RADLEY London website. Please retain your proof of purchase for any warranty claims.

For further assistance, product inquiries, or support, please visit the official RADLEY store on Amazon or their brand website:

RADLEY Amazon Store: [Visit the RADLEY Store](#)

Manufacturer: Radley London

© 2024 RADLEY London. All rights reserved. This manual is for informational purposes only.