Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM SDRePC48VD

T4TREAM Fluted Makeup Vanity Desk User Manual

Brand: T4TREAM | Model: SDRePC48VD

Important Safety Information

WARNING:

- Always unplug the vanity before assembly or disassembly.
- Be cautious of sharp edges and pinch points during assembly.
- Keep the vanity away from heat sources and liquids.
- Do not use the charging station with damaged cords or plugs.
- Always supervise children around the vanity.

Product Overview

The T4TREAM Fluted Makeup Vanity Desk is designed to enhance your daily beauty routine with its functional features and elegant design. It includes a large 35-inch HD lighted mirror, ample storage, and a convenient charging station.



Figure 1: T4TREAM Fluted Makeup Vanity Desk (Oak finish)

Key Features:

- **35-Inch Large HD Lighted Mirror:** Provides a true and accurate reflection with adjustable natural, warm, and cool light settings. Brightness can be adjusted by long-pressing the touch button.
- **Unique Slatted Panel Design:** Features fluted door fronts, gracefully curved side details, and elegant legs for a mid-century aesthetic.
- **Generous Storage Capacity:** Includes two large drawers with dividers, three small drawers, and a closed cabinet with adjustable shelves for organized storage of cosmetics and personal items.
- **Visible & Charging Station:** A transparent toughened glass tabletop offers a clear view of stored items in the drawers. A built-in charging station with AC outlets and USB ports is provided for electronic devices.

Specifications

Attribute	Detail

Brand	T4TREAM
Model Number	SDRePC48VD
Product Dimensions	15.6"D x 48"W x 54"H
Item Weight	145 pounds
Frame Material	Engineered Wood
Furniture Finish	Brass
Assembly Required	Yes
Country of Origin	China



Figure 2: Detailed product dimensions.

Setup and Assembly

The T4TREAM vanity desk requires assembly. Detailed installation instructions are included in the packaging. All parts and accessories are clearly identified with numbered stickers for easy recognition. A pack of spare parts is also supplied to account for any potential loss of hardware during assembly.

Assembly Tips:

- Review all instructions and identify all parts before beginning assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws.
- Ensure all connections are secure before use.



Figure 3: Overview of vanity desk components and internal storage layout, useful during assembly.

Operating Instructions

Lighted Mirror Operation:

The 35-inch HD mirror features integrated LED lighting with adjustable settings. To operate the mirror lights:

1. **Power On/Off:** Tap the touch control button on the mirror surface to turn the lights on or off.
2. **Change Light Mode:** Short-press the touch control button to cycle through three lighting modes: Cool Daylight, Natural Light, and Warm Light.
3. **Adjust Brightness:** Long-press the touch control button to continuously adjust the brightness level. Release the button when the desired brightness is achieved.



Figure 4: Touch control for the 35-inch HD lighted mirror, showing brightness adjustment and light modes.

Charging Station Usage:

The vanity desk includes a built-in charging station for your electronic devices. Locate the power outlets and USB port on the side of the desk.

- Plug in curling irons, hairdryers, beauty devices, or phone chargers into the available AC outlets or USB port.

- Ensure devices are compatible with the provided voltage and current.



Figure 5: Close-up of the built-in charging station with AC outlets and USB port.

Storage Organization:

Utilize the various storage compartments to keep your items organized:

- **Large Drawers:** The two large drawers feature removable dividers, ideal for categorizing trinkets, jewelry, or makeup tools. The transparent glass tabletop allows for easy visibility of contents.
- **Small Drawers:** The three smaller drawers provide additional space for cosmetics and personal items.
- **Side Cabinet:** The closed cabinet with adjustable shelves is suitable for storing frequently used cosmetics and other accessories, keeping them dust-free.



Figure 6: Transparent glass tabletop providing visibility into organized drawers.

Product Showcase Video:

Watch this official product video for a visual demonstration of the vanity desk's features and functionality.

Your browser does not support the video tag.

Video 1: Official product showcase of the 48-inch Fluted Vanity Desk, highlighting its design and features.

Maintenance

Proper care and maintenance will ensure the longevity and appearance of your vanity desk.

- **Cleaning Surfaces:**
    - For wood surfaces, wipe regularly with a soft, dry cloth. For stubborn marks, use a slightly damp cloth with a mild wood cleaner, then dry immediately.

- For glass surfaces, use a glass cleaner and a lint-free cloth to avoid streaks.
- Avoid abrasive cleaners or harsh chemicals that may damage the finish.

- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Spills:** Wipe up spills immediately to prevent staining or damage to the wood.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Protect the vanity from excessive moisture and direct sunlight.

Troubleshooting

If you encounter any issues with your vanity desk, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Mirror lights are dim or not working.	Power connection issue, light setting, or internal wiring problem.	◦ Ensure the vanity is properly plugged into a working power outlet. ◦ Try long-pressing the touch control button to adjust brightness. ◦ Short-press to cycle through light modes. ◦ If the issue persists, contact customer support.
Drawers do not slide smoothly or are misaligned.	Improper assembly or obstruction in the drawer slides.	◦ Check the assembly instructions to ensure all drawer slides are correctly installed and aligned. ◦ Remove the drawer and inspect the tracks for any debris or obstructions. ◦ Ensure the vanity is on a level surface.
Charging station is not providing power.	Vanity not plugged in, power strip issue, or device incompatibility.	◦ Verify the vanity's main power cord is securely plugged into a functional wall outlet. ◦ Ensure the device you are trying to charge is properly connected to the charging station. ◦ Test with a different device to rule out device-specific issues.

Warranty and Support

T4TREAM is committed to providing high-quality products. This vanity desk undergoes thorough quality checks before delivery. If you encounter any problems with your product, please do not hesitate to contact our customer support team. For assistance, please reach out to T4TREAM customer service through the retailer where the product was purchased or visit the official T4TREAM website for contact information. Please have your model number (SDRePC48VD) and purchase details ready when contacting support.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DSJDKLFC

More documents and user manuals: **https://manuals.plus/**