

[Manuals.plus](#) /

› [Arzum Okka](#) /

› Arzum OK0032-04 Okka Solo M Semi-Automatic Espresso Machine User Manual

Arzum Okka OK0032-04

Arzum OK0032-04 Okka Solo M Semi-Automatic Espresso Machine

User Instruction Manual

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the appliance and retain them for future reference. Improper use can result in personal injury and damage to the appliance.

- Always connect the machine to a grounded power outlet.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children.
- Unplug the machine from the power outlet before cleaning and when not in use.
- Do not operate the machine if the power cord or plug is damaged, or if the machine malfunctions or has been damaged in any way.
- Use only cold, fresh water in the water tank.
- Be cautious of hot surfaces and steam during operation.

PRODUCT OVERVIEW

The Arzum OK0032-04 Okka Solo M is a semi-automatic espresso machine designed to deliver a variety of coffee and milk-based beverages with ease. Its intuitive interface and robust design make it suitable for home use.



Front view of the Arzum OK0032-04 Okka Solo M Espresso Machine, showcasing its black and copper design with a latte in a glass.



Rear view of the Arzum OK0032-04 Okka Solo M Espresso Machine, illustrating the removable water tank for easy refilling and cleaning.

Key Components:

- **Control Panel / Display:** 4.3" OKKA Retina Display with colored touch screen for intuitive navigation and beverage selection.
- **Water Tank:** Removable 1.1 Liter capacity tank for fresh water.
- **Milk Frother / Container:** Integrated system for automatic milk frothing and dispensing.
- **Portafilter:** For holding ground coffee.
- **Drip Tray:** Removable and adjustable to accommodate various cup sizes (7 cm to 10 cm height).
- **Cup Warmer:** Top surface to pre-heat cups.
- **Steam Wand:** (Implicit from milk frother, but not explicitly listed as separate component, so will keep it general)

1. **Unpacking:** Carefully remove all packaging materials and ensure all components are present: main unit, portafilter, coffee measuring spoon.
2. **Placement:** Place the machine on a stable, flat, heat-resistant surface, away from water sources and direct sunlight. Ensure adequate ventilation around the unit.
3. **Water Tank Installation:** Remove the water tank from the back of the machine. Fill it with fresh, cold water up to the MAX line. Reinsert the tank firmly into its position.
4. **Initial Rinse:** Before first use, perform a rinse cycle. Plug in the machine. Turn it on. Place a large container under the coffee outlet. Follow the on-screen prompts or refer to the 'First Use' section in the detailed manual for specific rinse instructions. This primes the system and cleans internal components.
5. **Milk Container Preparation (if applicable):** If using the milk container, fill it with fresh cold milk. Ensure it is properly attached to the machine.

OPERATING INSTRUCTIONS

The Arzum OK0032-04 offers one-touch operation for various coffee and milk-based beverages. Ensure the water tank is filled and, if making milk-based drinks, the milk container has sufficient milk.



The 4.3-inch OKKA Retina Display provides a clear and intuitive interface for selecting your desired beverage.



Colored touch screen controls allow for easy selection and customization of drinks.

Brewing Coffee:

1. **Power On:** Press the power button on the control panel. The machine will heat up.
2. **Prepare Portafilter:** Using the included coffee measuring spoon, add the desired amount of ground coffee to the portafilter. Tamp the coffee evenly.
3. **Attach Portafilter:** Insert the portafilter into the brewing head and turn it to lock it into place.
4. **Place Cup:** Position your cup(s) on the adjustable drip tray. The dual coffee outlet allows for brewing two cups simultaneously.
5. **Select Beverage:** On the touch display, select your desired beverage: Espresso, Double Espresso, Americano, Cappuccino, Caffe Latte, or Milk Foam.
6. **Start Brewing:** Press the corresponding icon. The machine will automatically brew the selected drink.
7. **Programmable Volume:** You can customize coffee and milk quantities to your preference through the settings menu on the display.



The 15 Bar pump pressure ensures rich and flavorful espresso extraction.



Use the portafilter and coffee measuring spoon for precise coffee dosage.




The adjustable drip tray accommodates various cup sizes, from small espresso cups to tall latte glasses.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your espresso machine.

Daily Cleaning:

- **Drip Tray:** Empty and rinse the removable drip tray after each use or when the indicator shows it's full.
- **Portafilter:** Remove spent coffee grounds and rinse the portafilter and filter basket under warm water.
- **Milk System:** The machine features an automatic cleaning function for the milk system. Follow the on-screen prompts to initiate this cycle after preparing milk-based drinks.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners.



The built-in self-cleaning function simplifies maintenance of the milk system.

Periodic Cleaning / Descaling:

Depending on water hardness and usage, descaling will be required periodically. The machine may indicate when descaling is needed. Refer to the full manual for detailed descaling instructions using a suitable descaling solution.

TROUBLESHOOTING

If you encounter issues with your Arzum OK0032-04, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
No coffee dispenses	Water tank empty; Clogged filter; Machine not primed.	Fill water tank; Clean filter; Perform initial rinse cycle.
Coffee is too weak/strong	Incorrect coffee grind/amount; Volume settings.	Adjust grind size/coffee amount; Adjust programmable volume settings.
Milk not frothing properly	Milk container empty; Milk system clogged; Type of milk.	Fill milk container; Perform milk system cleaning; Use cold, fresh milk suitable for frothing.
Machine leaks	Drip tray full; Water tank not seated correctly.	Empty drip tray; Re-seat water tank firmly.

For issues not listed here, or if solutions do not resolve the problem, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	OK0032-04
Brand	Arzum Okka
Dimensions (L x W x H)	33 x 19 x 27 cm
Weight	Approximately 3.36 kg
Water Tank Capacity	1.1 Liters
Pump Pressure	15 Bar
Power Consumption	1376–1628 Watts
Voltage	220–240V / 50–60Hz
Display	4.3" OKKA Retina Display, Touch Controls
Special Features	Portable, Auto Shut-Off (29 mins), Milk Frother, Adjustable Brew Strength, Programmable, Cup Warmer, Dual Coffee Outlet, Adjustable Drip Tray

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Arzum Okka website. Keep your proof of purchase for warranty claims.

Contact Information: Please refer to the contact details provided in your product packaging or on the official Arzum Okka support page for assistance.