
[Manuals.plus](#) /

› [Philips](#) /

› Philips S2108 Portable Bluetooth Speaker Instruction Manual

Philips S2108

Philips S2108 Portable Bluetooth Speaker Instruction Manual

Model: S2108 (TAS2108BK/37)

INTRODUCTION

This manual provides essential information for the safe and efficient use of your Philips S2108 Portable Bluetooth Speaker. Please read these instructions carefully before using the product and retain them for future reference.



Image: Front view of the Philips S2108 Portable Bluetooth Speaker, showcasing its compact design and illuminated LED light panel.

WHAT'S IN THE BOX

- Philips S2108 Portable Bluetooth Speaker
- Quick Install Guide
- Safety Warranty Sheet
- Carrying Strap
- USB Charging Cable (USB-C)

PRODUCT OVERVIEW & KEY FEATURES

The Philips S2108 is a compact and versatile portable Bluetooth speaker designed for various environments. It offers robust sound and convenient features.

- **Powerful 5W RMS Sound:** Equipped with a 57mm full-range driver and passive radiator for punchy bass and clear audio.
- **True Wireless Stereo (TWS) Pairing:** Connect two identical S2108 speakers for an immersive stereo sound experience with synchronized LED lights.
- **Customizable LED Light Effects:** Features multiple lighting modes including multicolor, fading glow, and soft white night light.
- **Extended Playtime:** Up to 7 hours of music playback from a single charge, powered by a built-in 1800mAh rechargeable battery.
- **Bluetooth 5.3 & TF Card Playback:** Offers stable wireless streaming and direct music playback from a TF card.
- **Built-in Microphone:** Enables hands-free calling for convenience.



Image: The Philips S2108 speaker emphasizing its compact size and powerful sound output with a 10W max output power and 57mm full-range driver.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Use the provided USB-C charging cable. The charging port is located on the side of the speaker.

1. Connect the USB-C end of the cable to the speaker's charging port.
2. Connect the USB-A end of the cable to a compatible USB power adapter (not included).
3. A red indicator light will illuminate during charging. The light will turn off once charging is complete.

A full charge takes approximately 3.5 hours and provides up to 7 hours of playtime.



Image: The Philips S2108 speaker illustrating its battery life and charging details, including 7 hours of playtime and 1800mAh capacity.

2. Powering On/Off

- To power on: Press and hold the **Power button** (🔌) for 2 seconds. You will hear an audible tone and the LED indicator will light up.
- To power off: Press and hold the **Power button** for 2 seconds. You will hear an audible tone and the LED indicator will turn off.

3. Bluetooth Pairing

The speaker will automatically enter Bluetooth pairing mode when powered on for the first time or if no device is connected.

1. Ensure the speaker is powered on and the blue Bluetooth indicator light is flashing.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "Philips S2108" from the list.
4. Once connected, the blue Bluetooth indicator light will become solid.



Image: A woman smiling while connecting her Philips S2108 speaker to her smartphone, illustrating the ease of Bluetooth 5.3 pairing.

4. True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, you can pair two identical Philips S2108 speakers.

1. Ensure both S2108 speakers are powered on and not connected to any other Bluetooth device.

2. On one speaker (this will be the primary speaker), press and hold the **Bluetooth button** (🔵) for 3 seconds until you hear a tone.
3. The primary speaker will search for the secondary speaker. Once connected, you will hear a confirmation tone, and the LED lights on both speakers will synchronize.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described above.



Image: Two Philips S2108 speakers positioned outdoors, demonstrating True Wireless Stereo (TWS) pairing for a wider soundstage.

5. TF Card Playback

You can play music directly from a TF (microSD) card.

1. Insert a TF card with MP3 audio files into the TF card slot on the speaker.
2. The speaker will automatically switch to TF card playback mode.
3. Use the Play/Pause and Volume buttons to control playback.




Image: The Philips S2108 speaker highlighting its versatile connection options, including Bluetooth and TF card playback.

OPERATING INSTRUCTIONS

1. Music Playback Controls

- **Play/Pause:** Press the **Play/Pause button** (⏮️) to play or pause music.

- **Volume Up:** Press the **Volume + button** (🔊) to increase volume.
- **Volume Down:** Press the **Volume - button** (🔊) to decrease volume.
- **Next Track:** Press and hold the **Volume + button** for 2 seconds.
- **Previous Track:** Press and hold the **Volume - button** for 2 seconds.

2. LED Light Effects

The speaker features multiple LED light modes to enhance your listening experience.

- To cycle through light modes: Press the **Light Mode button** (usually integrated with another function or a dedicated button, refer to quick start guide for exact location).
- Available modes include multicolor, fading glow, and soft white night light.



Image: A woman adjusting the LED light effects on her Philips S2108 speaker, demonstrating the customizable lighting options.

3. Hands-Free Calling

The built-in microphone allows for convenient hands-free calls when connected via Bluetooth.

- **Answer Call:** Press the **Play/Pause button** once.
- **End Call:** Press the **Play/Pause button** once during a call.
- **Reject Call:** Press and hold the **Play/Pause button** for 2 seconds.



Image: A man engaged in a hands-free voice call using the Philips S2108 speaker, highlighting its built-in microphone for clear

communication.

MAINTENANCE

To ensure the longevity and optimal performance of your Philips S2108 speaker, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Exposure:** While designed for outdoor use, avoid prolonged exposure to heavy rain or submersion in water. Ensure the charging port cover is securely closed when not charging.

TROUBLESHOOTING

If you encounter issues with your speaker, refer to the following common solutions:

Problem	Possible Solution
Speaker does not power on	Ensure the battery is charged. Connect the speaker to a power source using the USB-C cable.
Cannot pair via Bluetooth	Ensure the speaker is in pairing mode (flashing blue LED). Turn off and on Bluetooth on your device. Move closer to the speaker. Forget the device on your phone and try pairing again.
No sound or low volume	Increase the volume on both the speaker and your connected device. Ensure the device is properly paired. Check if the speaker is muted.
Sound quality issues (e.g., glitches, muffled)	Ensure your device is within Bluetooth range. Avoid obstacles between the speaker and device. Disconnect and reconnect Bluetooth. Try with a different audio source.
TWS pairing fails	Ensure both speakers are S2108 models and not connected to other devices. Place speakers close to each other during pairing. Repeat the TWS pairing steps.

SPECIFICATIONS

Feature	Detail
Model Name	TAS2108BK/37
Speaker Type	Portable Speaker
Mounting Type	Tabletop Mount
Special Feature	USB Port, LED Light Effects, TWS Pairing, Built-in Microphone
Recommended Uses	Indoor/Outdoor
Compatible Devices	Laptop, MP3 Player, Smartphone, Tablet
Wireless Communication Technology	Bluetooth 5.3
Audio Output Mode	Stereo (with TWS)
Speaker Maximum Output Power	10 Watts (5W RMS)

Feature	Detail
Audio Driver Size	57 Millimeters
Power Source	Battery Powered
Battery Capacity	1800 Milliamp Hours
Playtime	Up to 7 Hours
Product Dimensions	5.39"D x 3.94"W x 3.94"H
Item Weight	1.26 pounds (0.57 Kilograms)
Control Method	Touch
UPC	840063205031

OFFICIAL PRODUCT VIDEOS

What It Really Sounds Like

Your browser does not support the video tag.

Video: A demonstration of the Philips S2108 speaker's sound quality and output.

Check Out This Portable Bluetooth Speaker

Your browser does not support the video tag.

Video: An overview of the Philips S2108 Portable Bluetooth Speaker, highlighting its features and portability.

WARRANTY AND SUPPORT

The Philips S2108 Portable Bluetooth Speaker comes with a limited warranty. Please refer to the included Safety Warranty Sheet for detailed terms and conditions. For product support, visit the official Philips website or contact their customer service.